Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alesis Recital PRO

Alesis Recital Pro - 88 Key Digital Piano Keyboard

Model: Recital PRO | Brand: Alesis

Keywords: Alesis, Recital, Pro, 88, Key, Digital, Piano, Keyboard, Hammer Action, Weighted Keys, 2x20W Speakers, 12 Voices, Record Mode, Lesson Mode, FX, Display

Product Overview

The Alesis Recital Pro is a full-featured digital piano designed for an authentic playing experience. It features 88 full-sized hammer-action weighted keys with adjustable touch response, allowing you to customize the feel to your preferred playing style. With 12 premium built-in realistic voices, including Acoustic Piano, Electric Piano, Organ, Synth, and Bass, the Recital Pro offers a versatile sound palette for any performance.

Equipped with two built-in 20W speakers and 128-note max polyphony, it delivers ultra-realistic sound. The piano also includes built-in effects such as Chorus, Modulation, and Reverb to enhance your sound.

For educational purposes, the "Lesson Mode" divides the 88 keys into two zones, facilitating simultaneous play for both student and teacher. A "Record Mode" allows you to capture and review your performances. The Recital Pro is powered by the included adapter or 6 D cell batteries (not included) for portability.

It also comes with a 3-month premium subscription to Skoove and 100 virtual lessons from Melodics, providing interactive online piano courses to help you develop your skills.



Image: The Alesis Recital Pro digital piano, showcasing its full 88-key layout and integrated music rest with a tablet.

What's in the Box

- Recital Pro Digital Piano
- Power Adapter
- Music Rest
- User Guide
- Safety & Warranty Manual

Setup Guide

1. Unpacking and Placement

Carefully remove all components from the packaging. Place the Alesis Recital Pro on a stable, flat surface or a compatible keyboard stand. Ensure adequate space around the instrument for comfortable playing and access to connections.

2. Attaching the Music Rest

Insert the included music rest into the slots located on the top panel of the digital piano. This provides a stable support for sheet music or a tablet.



Image: The Alesis Recital Pro with its music rest installed, ready for sheet music or a tablet.

3. Power Connection

Connect the included power adapter to the "POWER DC 12V" input on the rear panel of the Recital Pro. Plug the

other end of the adapter into a standard electrical outlet. Alternatively, for portable use, the unit can be powered by 6 D cell batteries (not included).

4. Connecting Peripherals (Optional)

- **Sustain Pedal:** Connect a 1/4" (6.35mm) sustain pedal (not included) to the "SUSTAIN" input on the rear panel for expressive playing.
- **Headphones:** For private practice, connect 1/4" (6.35mm) headphones to the "PHONES" output on the rear panel.
- **External Audio:** Use 1/4" (6.35mm) cables to connect the "LINE OUT" (R and L/MONO) outputs to an amplifier, mixer, or other sound system.
- **USB Connectivity:** Connect a standard USB cable from the "USB" port to a computer for MIDI connectivity and software integration.



Image: Detailed view of the rear panel connections, including power, sustain, line out, phones, and USB ports.

Operating Instructions

1. Power On/Off

Press the "POWER" button located on the top left of the control panel to turn the digital piano on or off. The display will illuminate upon power-up.

2. Adjusting Volume

Use the "MASTER VOLUME" knob to adjust the overall output volume of the digital piano. Turn clockwise to increase volume and counter-clockwise to decrease.



Image: The central control panel of the Recital Pro, highlighting the master volume knob and various function buttons.

3. Voice Selection

The Recital Pro offers 12 built-in voices. Use the "VOICE SELECT" buttons (Piano, Electric Piano, Organ, Synth, Bass, etc.) to choose your desired instrument sound. The selected voice will be displayed on the LCD screen.

4. Metronome

Press the "METRONOME" button to activate the built-in metronome. Use the "VALUE" knob to adjust the tempo. Press the button again to turn the metronome off.

5. Lesson Mode

Activate "LESSON MODE" to split the keyboard into two zones with the same pitch and voice. This is ideal for student-teacher interaction, allowing both to play simultaneously without reaching over each other.

6. Record Mode

Use the "RECORD" button to begin recording your performance. Press "PLAY" to listen back to your recorded piece. This feature is useful for self-assessment and practice.

Maintenance

To ensure the longevity and optimal performance of your Alesis Recital Pro, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the surface of the digital piano. Avoid using abrasive cleaners, waxes, or solvents, as these can damage the finish.
- **Key Care:** Keep the keys clean by wiping them with a slightly damp cloth. Do not use excessive moisture.
- **Storage:** When not in use, store the digital piano in a dry, dust-free environment. If storing for an extended period, consider covering it with a dust cover.
- **Avoid Extreme Conditions:** Do not expose the instrument to direct sunlight, extreme temperatures, high humidity, or excessive dust, as these can affect its electronic components and physical structure.
- **Transportation:** When moving the digital piano, ensure it is properly secured to prevent damage. If transporting over long distances, use appropriate protective casing.

Troubleshooting

If you encounter issues with your Alesis Recital Pro, refer to the following common troubleshooting steps:

- **No Sound:**
  - Ensure the power adapter is securely connected and the unit is powered on.
  - Check the "MASTER VOLUME" knob and ensure it is turned up.
  - If headphones are connected, disconnect them to check if sound comes from the built-in speakers.
  - Verify that external speakers/amplifiers (if used) are powered on and connected correctly.
- **Keys Not Responding:**
  - Ensure the unit is powered on.
  - Check if any specific mode (e.g., Lesson Mode with split keyboard) is active that might affect key response.
- **Distorted Sound:**
  - Lower the "MASTER VOLUME" to prevent clipping or distortion.
  - If connected to external audio equipment, check their volume levels and connections.
- **Metronome Not Working:**
  - Ensure the "METRONOME" button is pressed and the tempo is set to an audible rate using the "VALUE" knob.

For further assistance, consult the comprehensive User Guide (PDF) available online or contact Alesis customer support.

Specifications

Feature	Detail
Number of Keys	88
Key Action	Hammer Action Weighted Keys with Adjustable Touch Response
Built-in Voices	12 Premium Voices (Acoustic Piano, Electric Piano, Organ, Synth, Bass, etc.)
Speakers	2 x 20W Built-in Speakers
Polyphony	128-note Max Polyphony
Modes	Standard, Split, Layer, Record, Lesson Mode, Metronome
Connectivity	1/4" Sustain Pedal Input, 1/4" Stereo Headphone Output, Stereo 1/4" Line Outputs, USB-MIDI
Power Source	Included Power Adapter or 6 D Cell Batteries (not included)
Dimensions (D x W x H)	13.8"D x 51.6"W x 5.5"H
Item Weight	26 Pounds

Warranty and Support

The Alesis Recital Pro comes with a standard manufacturer's warranty. Please refer to the included Safety & Warranty Manual for detailed information regarding warranty coverage, terms, and conditions.
For technical support, troubleshooting, or additional product information, please visit the official Alesis website or refer to the User Guide (PDF) provided with your product. The User Guide contains comprehensive instructions and diagrams to assist you with setup, operation, and advanced features.
You can access the User Guide (PDF) directly via this link:Alesis Recital Pro User Guide

© 2025 Alesis. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B072FKLXRB

More documents and user manuals: **https://manuals.plus/**