Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PNI Escort HP 8000L

PNI Escort HP 8000L CB Radio with Extra 45 Antenna User Manual

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your PNI Escort HP 8000L CB Radio and the included PNI Extra 45 magnetic antenna. Please read this manual thoroughly before using the product to ensure proper function and to maximize your communication experience.

2. Product Overview

The PNI Escort HP 8000L is a compact and versatile CB radio designed for reliable two-way communication. It features AM/FM modulation, 40 channels, and both manual and automatic squelch control. The kit includes a PNI Extra 45 magnetic antenna, providing a complete communication solution.

2.1 Package Contents

- PNI Escort HP 8000L CB Radio Unit
- Microphone with channel UP/DOWN buttons
- PNI Extra 45 Magnetic CB Antenna (45 cm fiberglass)
- Mounting Bracket and Screws
- Power Cable with Cigarette Lighter Plug



Figure 2.1: PNI Escort HP 8000L CB Radio kit contents, including the radio unit, microphone, antenna, and accessories.

2.2 Radio Unit Controls and Connections



Figure 2.2: Front panel of the PNI Escort HP 8000L CB Radio with connected microphone. Key controls include Volume, Squelch (SQ), Automatic Squelch (ASQ), Channel Up/Down, and AM/FM mode selection.




Figure 2.3: Rear view of the PNI Escort HP 8000L CB Radio, illustrating the antenna connector and power input terminals.

3. Setup

3.1 Mounting the Radio

Select a suitable location for the radio unit that is easily accessible and does not obstruct driving. Use the provided mounting bracket and screws to secure the radio. Ensure adequate ventilation around the unit.

3.2 Antenna Installation

The PNI Extra 45 antenna features a magnetic base for easy attachment to a metallic surface, typically the vehicle roof. Ensure the mounting surface is clean and flat for optimal magnetic adhesion and performance.



Figure 3.1: The magnetic base of the PNI Extra 45 antenna, designed for secure attachment to vehicle surfaces.

Connect the antenna cable to the antenna connector on the rear of the CB radio unit (refer to Figure 2.3). Route the cable carefully to avoid damage or interference.

3.3 Power Connection

Connect the power cable to the 12V power input on the rear of the radio. The included power cable with a cigarette lighter plug can be used for convenient connection in a vehicle. Ensure the vehicle's ignition is off before connecting the power.

3.4 Microphone Connection

Plug the microphone connector into the designated port on the front panel of the CB radio.

3.5 Initial Configuration (Country Code)

Upon first use, it is essential to set the correct country code for your region to ensure the radio operates on the appropriate frequencies. For Italy, this typically involves a specific setting. Consult the quick start guide or perform the following steps (common for many CB radios):

1. With the radio powered off, press and hold the PTT (Push-To-Talk) button and the DOWN button on the microphone simultaneously.
2. While holding these buttons, power on the radio.
3. Release the buttons. The display should show a country code or setting.
4. Use the UP/DOWN buttons on the microphone to select the correct country code (e.g., 'd' for Italy).
5. Power off and then power on the radio normally to save the setting.

4. Operating Instructions

4.1 Powering On/Off

Rotate the VOL (Volume) knob clockwise to power on the radio. Continue rotating to adjust the listening volume. Rotate counter-clockwise until it clicks to power off.

4.2 Channel Selection

Use the UP and DOWN buttons on the microphone or the dedicated channel buttons on the radio's front panel to select your desired communication channel (1-40).

4.3 AM/FM Mode Selection

The radio supports both AM (Amplitude Modulation) and FM (Frequency Modulation) modes. Use the AM/FM switch on the front panel to select the appropriate modulation type for your communication.

4.4 Squelch (SQ) and Automatic Squelch (ASQ)

- **SQ (Manual Squelch):** Rotate the SQ knob to adjust the squelch level. This eliminates background noise when no signal is present. Adjust it just past the point where background noise disappears.
- **ASQ (Automatic Squelch):** The ASQ function automatically adjusts the squelch level. Rotate the ASQ knob to set the sensitivity of the automatic squelch. This provides a quieter listening experience without constant manual adjustment.

4.5 Transmitting

To transmit, press and hold the PTT (Push-To-Talk) button on the microphone. Speak clearly into the microphone. Release the PTT button to listen for a response.

4.6 Key Lock Function

The radio features a key lock function to prevent accidental changes to settings. Refer to the radio's front panel or specific instructions for activating and deactivating this feature.

5. Maintenance

5.1 Cleaning

Clean the radio unit and microphone with a soft, dry cloth. Do not use abrasive cleaners or solvents. Keep the antenna base clean to ensure good magnetic contact.

5.2 Antenna Care

Regularly inspect the antenna cable for any signs of wear or damage. Ensure the antenna is securely mounted. While the antenna is designed for outdoor use, prolonged exposure to extreme weather conditions may affect its lifespan.

5.3 General Handling

Avoid dropping the radio or subjecting it to strong impacts. Keep the unit away from excessive moisture and direct sunlight. The radio is not water-resistant.

6. Troubleshooting

6.1 No Power

- Check the power cable connection to the radio and the 12V source.
- Ensure the vehicle's cigarette lighter socket is functional.
- Verify the VOL knob is rotated clockwise to turn on the unit.

6.2 No Reception or Transmission

- Confirm the antenna is properly connected to the radio.
- Ensure the antenna is securely mounted on a metallic surface.
- Check that the squelch (SQ/ASQ) is not set too high, which can block weak signals.
- Verify the correct channel and AM/FM mode are selected.
- Ensure the country code setting is correct for your region.

6.3 Poor Audio Quality

- Adjust the volume and squelch levels.
- Check microphone connection and ensure you are speaking clearly into it.
- Ensure the antenna is properly installed and tuned (SWR).

7. Specifications

Feature	Specification
Brand	PNI
Model	Escort HP 8000L
Frequency Range	26.965 - 27.405 MHz
Number of Channels	40

Output Power	4 W
Modulation Type	AM/FM
Power Supply Voltage	12 V
Current Consumption	2 A (max)
Antenna Type	PNI Extra 45 (45 cm fiberglass with magnetic base)
Maximum Talk Range	Up to 8046 meters (8 km)
Dimensions (Radio Unit)	45 x 15.2 x 3.6 cm
Weight (Radio Unit)	800 grams
Water Resistance	Not water resistant

8. Warranty and Support

This product is covered by the standard warranty provided by the retailer. For specific details regarding warranty claims, returns, or technical support, please refer to your purchase documentation or contact the seller directly. For general Amazon return policies, please visit the Amazon Help page on returns and refunds.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B072J7QXG9

More documents and user manuals: **https://manuals.plus/**