Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SCS Sentinel OpenGate3

SCS Sentinel OpenGate 3 Sliding Gate Motorization System

Model: OpenGate3 (MCO0063-24V)

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of the SCS Sentinel OpenGate 3 Sliding Gate Motorization System. This system is designed to automate sliding gates up to 5 meters in length and weighing a maximum of 500 kg, offering enhanced convenience and security for your property.
Please read this manual thoroughly before proceeding with installation or operation to ensure correct setup and safe usage.

Package Contents

The SCS Sentinel OpenGate 3 system includes all necessary components for a complete installation. Please verify that all items listed below are present in your package:

- 1x Motor with P501 BI PCB1 electronic board
- 2x Remote Controls
- 1x Flashing Fire (Warning Light)
- 2x Photo Cells (Safety Sensors)
- 4m Rack (for gate movement)
- 1x Installation Template
- Screws and 1x Locking mechanism
- 1x Motor Mount Support
- Racing Goals (Limit Switches)
- 1x Instruction Manual (this document)



Figure 1: Overview of the SCS Sentinel OpenGate 3 kit, showing the motor unit, rack segments, flashing light, two remote controls, and photocells.



Figure 2: Detailed diagram illustrating the main components, dimensions, and key features of the OpenGate 3 system, including the motor, rack, flashing light, remote controls, and photocells. This diagram also highlights the 24V power, silent operation, reliability, and 3-year warranty.

Setup and Installation

The installation of the OpenGate 3 system involves three primary stages: mechanical installation, electrical connection, and programming/synchronization. It is recommended that installation be performed by a qualified professional.

1. Mechanical Installation

Securely mount the motor unit to a stable, level surface adjacent to the sliding gate. Ensure the motor is positioned correctly relative to the gate's movement path. Attach the rack segments along the bottom edge of the gate, ensuring proper alignment with the motor's gear. The rack should be installed such that there is a small clearance between the rack and the motor gear to allow for smooth operation and thermal expansion.

- Use the provided installation template to mark drilling points for the motor mount support.
- Install the motor mount support firmly.
- Mount the motor onto the support.
- Attach the rack segments to the gate, ensuring they are level and parallel to the ground.
- Position the racing goals (limit switches) at the desired open and closed positions of the gate.



Figure 3: An example of the OpenGate 3 motor unit correctly installed at the base of a sliding gate, demonstrating its discreet integration.

2. Electrical Connection

Connect the motor to a 24V power supply. Ensure all electrical connections are made according to local electrical codes and safety regulations. Connect the photocells and flashing light to the motor's electronic board (P501 BI PCB1) as per the wiring diagram provided in the full instruction manual (not included in this summary).

- Connect the main power supply to the motor unit.
- Wire the photocells across the gate opening to detect obstacles.
- Connect the flashing light for visual indication during gate operation.
- Ensure all wiring is properly insulated and protected from environmental elements.



Figure 4: The flashing warning light, an essential safety component that signals gate movement.

3. Programming and Synchronization

Once mechanical and electrical installations are complete, the system needs to be programmed. This involves setting the gate's travel limits, synchronizing the remote controls, and configuring operational parameters.

- **Learning Cycle:** Initiate the learning cycle to allow the motor to detect the gate's full open and closed positions.
- **Remote Control Pairing:** Follow the instructions in the detailed manual to pair the remote controls with the motor unit.
- **Parameter Configuration:** Adjust settings such as automatic closing time, slow-down speed, and obstacle detection sensitivity as needed.



Figure 5: One of the two remote controls included with the OpenGate 3 system, used for operating the gate.

Operating Instructions

The OpenGate 3 system offers a variety of operational modes and features for flexible gate control.

- **Remote Control Operation:** Pressing a button on the remote control will initiate gate movement (open or close). A second press during movement will stop the gate.
- **Total or Partial Opening:** The system can be configured for full gate opening or a partial opening (pedestrian access). Refer to the programming section of the full manual for configuration.
- **Slow-down at End of Race:** The gate motor automatically reduces speed at the end of its travel (both opening and closing) to ensure smooth and quiet operation and reduce mechanical stress.
- **Obstacle Detection:** The photocells detect obstacles in the gate's path. If an obstacle is detected during closing, the gate will stop or reverse. If detected during opening, the gate will stop.
- **Automatic Closing:** The system can be programmed to automatically close the gate after a set period of time following an opening cycle.
- **Manual Unlock:** In case of power failure or system malfunction, the gate can be manually unlocked and operated.

Refer to the motor unit for the manual release mechanism.

Maintenance

Regular maintenance ensures the longevity and reliable operation of your SCS Sentinel OpenGate 3 system. Perform the following checks periodically:

- **Cleanliness:** Keep the motor unit, rack, and photocells free from dirt, debris, and vegetation. Obstructions can impair performance and safety.
- **Lubrication:** Periodically check and lubricate the gate's wheels and hinges if applicable, as well as the motor's gear and rack, using appropriate lubricants.
- **Fasteners:** Inspect all mounting screws and fasteners for tightness. Tighten any loose connections.
- **Photocells:** Ensure the photocells are clean and properly aligned. Test their functionality regularly by placing an object in their path during gate operation.
- **Electrical Connections:** Visually inspect wiring for any signs of wear, damage, or corrosion. Ensure all connections are secure.

For any complex maintenance or repairs, contact a qualified technician.

Troubleshooting

This section addresses common issues you might encounter with your OpenGate 3 system. For more detailed troubleshooting, refer to the complete product manual.

Gate Does Not Respond to Remote Control

- **Check Remote Battery:** Replace the battery in the remote control.
- **Check Power Supply:** Ensure the motor unit is receiving power. Check circuit breakers.
- **Re-pair Remote:** The remote control might have lost its pairing. Follow the synchronization steps in the manual to re-pair it.

Gate Stops or Reverses Unexpectedly

- **Obstacle Detection:** Check if the photocells are obstructed or misaligned. Clean them and ensure a clear path.
- **Physical Obstruction:** Inspect the gate's path for any physical obstacles (e.g., debris, vegetation) that might be triggering the safety mechanism.
- **Limit Switches:** Ensure the racing goals (limit switches) are correctly positioned and not being triggered prematurely.

Gate Operates Slowly or with Difficulty

- **Mechanical Resistance:** Check the gate's wheels, hinges, and track for friction or damage. Ensure the gate slides freely manually.
- **Power Supply:** Verify that the motor is receiving adequate voltage (24V).
- **Motor Overload:** Ensure the gate weight does not exceed the maximum capacity of 500 kg.

Technical Specifications

Brand	SCS Sentinel

Model Number	OpenGate3 (MCO0063-24V)
Motor Voltage	24 V
Maximum Gate Length	5 meters
Maximum Gate Weight	500 kg
Mechanism Type	Rack
Product Dimensions	16.8 x 30.9 x 30.7 cm
Item Weight	14.1 kg
Included Components	Rack motor for sliding gate, 2 remote controls, 1 flashing fire, 2 photo cells, 4m stand, installation template, screws, locking, motor mount support, racing goals, instructions.
Power Source Type	AC
Colour	Dark-grey

Warranty and Support

The SCS Sentinel OpenGate 3 Sliding Gate Motorization System comes with a**3-year warranty**, ensuring reliability and peace of mind. This warranty covers manufacturing defects and ensures the product meets its specified performance standards.
For technical support, warranty claims, or further assistance, please refer to the contact information provided in the original product packaging or visit the official SCS Sentinel website.

© 2023 SCS Sentinel. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B072V6KZ8L

More documents and user manuals: **https://manuals.plus/**