Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard MG508

Billboard MG508 Bluetooth Wireless Over-Ear Earbuds User Manual

Model: MG508

Introduction

This manual provides instructions for the proper use and maintenance of your Billboard MG508 Bluetooth Wireless Over-Ear Earbuds. Please read this manual thoroughly before use to ensure optimal performance and safety.

Package Contents

- Billboard MG508 Bluetooth Wireless Earbuds
- Charging Cable
- User Manual (this document)
- Ear Cushions (Small, Medium, Large)

Product Overview

Familiarize yourself with the components and controls of your earbuds.



This image displays the Billboard MG508 earbuds, featuring an over-ear hook design for a secure fit during activities. The earbuds are white with black ear tips.



This image shows a close-up of the Billboard MG508 earbuds, highlighting the inline control module located on the cable. The module features buttons for power/pairing, volume/track navigation, and a built-in microphone. A charging port is also visible on the side of the control module.

Setup

1. Charging the Earbuds

1. Connect the charging cable to the micro-USB port on the inline control module.
2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The indicator light will illuminate during charging and turn off when fully charged.
4. A full charge takes approximately 1.5 hours.

2. Pairing with a Bluetooth Device

1. Ensure the earbuds are turned off.
2. Press and hold the multi-function button (usually the center button on the control module) until the indicator light flashes red and blue, indicating pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet), go to the Bluetooth settings and enable Bluetooth.

4. Search for available devices. The earbuds will appear as "MG508" or similar.
5. Select "MG508" to connect. Once paired, the indicator light will flash blue slowly or turn solid blue.
6. If prompted for a password, enter "0000".

Operating Instructions

Power On/Off

- **Power On:** Press and hold the multi-function button for approximately 3 seconds until the blue indicator light flashes.
- **Power Off:** Press and hold the multi-function button for approximately 5 seconds until the red indicator light flashes and then turns off.

Music Playback

- **Play/Pause:** Press the multi-function button once.
- **Volume Up:** Press the "+" button.
- **Volume Down:** Press the "-" button.
- **Next Track:** Press and hold the "+" button.
- **Previous Track:** Press and hold the "-" button.

Call Management

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for approximately 2 seconds.
- **Redial Last Number:** Double-press the multi-function button.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the earbuds. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the earbuds in a cool, dry place away from direct sunlight and extreme temperatures.
- **Ear Cushions:** Regularly check and clean the ear cushions. Replace them if they become worn or damaged.

Troubleshooting

Problem	Solution
Earbuds do not power on.	Ensure the earbuds are fully charged.
Cannot pair with device.	Ensure Bluetooth is enabled on your device and the earbuds are in pairing mode. Move earbuds closer to the device.
No sound or low volume.	Check volume levels on both the earbuds and your connected device. Ensure earbuds are properly paired.

Problem	Solution
Intermittent connection.	Move closer to your device. Avoid obstacles between the earbuds and the device.

Specifications

- **Model:** MG508
- **Connectivity:** Bluetooth Wireless
- **Wireless Range:** Up to 33 feet (10 meters)
- **Charging Time:** Approximately 1.5 hours
- **Play Time:** Up to 3 hours
- **Standby Time:** Up to 50 hours
- **Weight:** 2.08 ounces (59 grams)
- **Dimensions:** 1.25 x 6 x 6.5 inches (3.18 x 15.24 x 16.51 cm)
- **Included Components:** Headphones, Charging Cable, User Manual, Small/Medium/Large Earbuds

Safety Information

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Do not expose to extreme temperatures or direct sunlight.
- Do not immerse in water.
- Do not disassemble or attempt to repair the device yourself.
- Keep out of reach of children.
- Use only the provided charging cable.
- Listening at high volume levels for extended periods can cause hearing damage.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Billboard website.

© 2023 Billboard. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B073CCYWT4

More documents and user manuals: **https://manuals.plus/**