Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Billboard 486

BILLBOARD Wireless Bluetooth Headphones BB486 User Manual

Model: BB486

Introduction

Thank you for choosing the BILLBOARD Wireless Bluetooth Headphones, Model BB486. These over-ear headphones offer a versatile audio experience with Bluetooth connectivity, an integrated microphone for hands-free calls, FM radio, and microSD card playback capabilities. Designed for portability, their foldable structure makes them convenient for travel and storage.

Package Contents

- BILLBOARD Wireless Bluetooth Headphones (Model BB486)
- Instruction Manual
- Charging Cable (not explicitly listed but implied for Bluetooth headphones)

Product Features

- Wireless Bluetooth Connectivity
- Integrated Microphone for Hands-Free Calling
- Built-in FM Radio
- MicroSD Card Slot for MP3 Playback
- Foldable Design for Easy Portability
- Over-Ear Comfort
- Media Control Buttons

Controls and Indicators



Figure 1: Overview of BILLBOARD Wireless Bluetooth Headphones (BB486) with visible control panel.

The right earcup houses the primary control panel for the headphones. Familiarize yourself with the following buttons and indicators:

- **Power Button ( ):** Press and hold to power on/off the headphones.
- **Play/Pause Button (▶‖):** Press to play or pause audio. In call mode, press to answer/end a call.
- **Call Button ( ):** Press to answer incoming calls or end current calls.
- **Volume Up** / **Next Track Button (+ / >>|):** Short press to increase volume. Long press to skip to the next track.
- **Volume Down** / **Previous Track Button (- / |<<):** Short press to decrease volume. Long press to go to the previous track.

- **Mode Button (labeled "FM MP3"):** Press to switch between Bluetooth, FM Radio, and MicroSD card modes.
- **LED Indicator:** Displays charging status and Bluetooth pairing status.
- **Micro USB Charging Port:** For connecting the charging cable.
- **MicroSD Card Slot:** For inserting a MicroSD card for local music playback.

Setup

1. Charging the Headphones

1. Connect the Micro USB end of the charging cable to the charging port on the headphones.
2. Connect the USB-A end of the charging cable to a compatible USB power source (e.g., computer USB port, wall adapter).
3. The LED indicator will illuminate during charging and typically turn off or change color when fully charged.
4. Allow approximately 2-3 hours for a full charge before first use.

2. Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Press and hold the Power Button () for 3-5 seconds until the LED indicator flashes rapidly (usually blue and red), indicating pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, computer), go to the Bluetooth settings.
4. Search for available devices. The headphones should appear as "BB486" or "BILLBOARD BB486".
5. Select the headphones from the list to initiate pairing.
6. Once successfully paired, the LED indicator will typically flash slowly or turn solid blue, and you may hear an audible confirmation.
7. If prompted for a password, enter "0000".

Operating Instructions

Bluetooth Mode

- After successful pairing, audio from your connected device will play through the headphones.
- Use the Play/Pause button to control playback.
- Use the Volume Up/Down buttons for volume adjustment. Long press for next/previous track.
- For incoming calls, press the Call button to answer, and press again to end the call.

FM Radio Mode

1. With the headphones powered on, press the Mode button (labeled "FM MP3") until you hear an FM radio signal or static.
2. To auto-scan and save available stations, long press the Play/Pause button. The headphones will scan and store stations automatically.
3. Use the Volume Up/Down buttons (long press) to navigate between saved FM stations.

MicroSD Card Mode

1. Insert a MicroSD card (with MP3 audio files) into the MicroSD card slot on the headphones.
2. The headphones should automatically switch to MicroSD card mode and begin playing audio. If not, press the Mode button until MicroSD mode is activated.
3. Use the Play/Pause button to control playback.

4. Use the Volume Up/Down buttons (long press) to navigate between tracks.

Maintenance

- **Cleaning:** Wipe the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. Utilize the foldable design for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.
- **Water Exposure:** These headphones are not waterproof. Avoid exposure to water or excessive moisture.

Troubleshooting

Problem	Possible Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair with Bluetooth device.	◦ Ensure headphones are in pairing mode (LED flashing rapidly). ◦ Make sure Bluetooth is enabled on your device. ◦ Move headphones closer to your device. ◦ Forget/remove "BB486" from your device's Bluetooth list and try pairing again. ◦ Restart both the headphones and your device.
No sound or low volume.	◦ Increase volume on both the headphones and your connected device. ◦ Ensure headphones are properly paired and connected. ◦ Check if the audio source is playing.
Poor FM radio reception.	◦ Move to an open area away from interference. ◦ Perform an auto-scan again to find stronger signals.
MicroSD card not recognized.	◦ Ensure the MicroSD card is inserted correctly. ◦ Verify that the audio files on the card are in MP3 format. ◦ Try a different MicroSD card.

Specifications

Feature	Detail
Model Number	BB486
Connectivity Technology	Bluetooth

Feature	Detail
Ear Placement	Over Ear
Color	Rose Gold
Material	Plastic
Item Weight	4.8 ounces (approx. 0.136 kg)
Product Dimensions	7.5 x 3.5 x 8.5 inches
Special Features	Microphone Included, Wireless, FM Radio, MicroSD Card Playback
Control Type	Media Control

Warranty and Support

Specific warranty information and direct support contact details are not available in the provided product data. Please refer to the packaging or the official Billboard website for warranty terms and customer support information.

© 2023 Billboard. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B073M2YXTY

More documents and user manuals: **https://manuals.plus/**