Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 3202, FX3020, FX3030, K700, K750, SJ600, PJ600, CH600, CW600

Braun Blender Cap for Multiquick Combimax 5 K700 K750 3202 FX3030 - Instruction Manual

Official User Guide

1. Product Overview

This document provides instructions for the Braun Blender Cap, a genuine replacement part designed for specific Braun Multiquick and Combimax food processors and blenders. This cap ensures proper sealing and functionality of your appliance's blender bowl.



Figure 1: The Braun Blender Cap, a grey and clear plastic lid with a central opening for pouring or adding ingredients during operation.

Key features of this product include:

- Genuine Braun replacement part.
- Small chopper lid for Braun blenders.
- Designed for durability and a secure fit.

2. Compatibility

This blender cap is specifically designed for use with the plastic blender bowl of the following Braun food processor and blender models. Please verify your appliance's model number, typically found on the identification plate located under the appliance, to ensure compatibility.
Compatible Models:

- **Type 3202:**
  - FX3020
  - FX3030
  - K700
  - K750
- **Combimax Series:**
  - K700
  - K750
- **Multiquick 5 Series:**
  - SJ600
  - PJ600
  - CH600
  - CW600
  - FX3030
  - FX3020

If your model is not listed, please contact Braun customer support for assistance.

3. Setup and Installation

To install the Braun Blender Cap:

1. Ensure your blender or food processor is unplugged from the power outlet.
2. Place the plastic blender bowl securely onto the motor unit.
3. Align the blender cap with the top of the blender bowl. The cap is designed to fit snugly.
4. Press the cap down firmly until it is securely seated on the bowl. Ensure the pouring spout or any locking tabs (if present on your specific bowl) are correctly aligned and engaged.
5. The small central opening on the cap allows for adding ingredients during operation without removing the entire lid.

Always ensure the cap is properly secured before operating the appliance to prevent spills and ensure safe use.

4. Operating Instructions

The blender cap is an integral part of your Braun appliance's blending function. Once securely installed:

- **During Blending:** The cap provides a secure seal, preventing contents from splashing out during operation.
- **Adding Ingredients:** Use the small central opening to gradually add liquids or small ingredients while the appliance is running. This is particularly useful for emulsifying or achieving desired consistency.
- **Pouring:** After blending, the cap can be easily removed to pour out the contents.

Do not operate the appliance without the cap securely in place, especially when processing hot liquids.

5. Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your Braun Blender Cap.

- **Dishwasher Safe:** This blender cap is dishwasher safe, allowing for convenient and thorough cleaning. Place it on the top rack of your dishwasher.
- **Hand Washing:** For hand washing, use warm soapy water and a soft sponge. Rinse thoroughly under running water.
- **Drying:** Allow the cap to air dry completely before storing or reattaching to the blender bowl.

Avoid using abrasive cleaners or scouring pads, as these can scratch the surface of the cap.

6. Troubleshooting

If you encounter issues with your Braun Blender Cap, consider the following:

Problem	Possible Cause	Solution
Cap does not fit securely.	Incorrect model compatibility; debris on rim; cap or bowl warped.	Verify your appliance model number against the compatibility list. Clean the rim of both the cap and the blender bowl. If warped, replacement may be necessary.
Contents leak from under the cap.	Cap not seated properly; missing or damaged gasket (if applicable to your bowl); overfilling the bowl.	Ensure the cap is firmly pressed down and aligned. Check if your original blender bowl requires a separate gasket and if it's intact. Do not exceed the maximum fill line of your blender bowl.

7. Specifications

Attribute	Detail
Brand	Braun
Color	White
Product Dimensions (L x W x H)	15.2 x 2.2 x 16.9 cm (approx. 6 x 0.9 x 6.7 inches)
Item Weight	80 grams (approx. 2.8 ounces)
Dishwasher Safe	Yes
Material of Container (referring to compatible bowl)	Glass

Attribute	Detail
Model Number	Type 3202

Note: The product description states this cap is suitable for plastic blender bowls. The 'Material of Container: Glass' specification may refer to other compatible containers or general appliance specifications.

8. Warranty and Support

This product is subject to the standard return policy of 30 days for refund or replacement, as per the seller's terms. For any issues or inquiries regarding this Braun replacement part, please refer to your original appliance's user manual or contact Braun customer service directly.
For further assistance, please visit the official Braun website or contact their customer support line.

© 2024 Braun. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0742CKFM5

More documents and user manuals: **https://manuals.plus/**