Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun MQ727

Braun MultiQuick MQ727 4-in-1 Immersion Hand Blender

Instruction Manual

Model: MQ727

1. Introduction

This manual provides essential information for the safe and efficient operation of your Braun MultiQuick MQ727 4-in-1 Immersion Hand Blender. Please read these instructions thoroughly before first use and retain them for future reference. This appliance is designed for household use only.

The Braun MultiQuick MQ727 is a versatile kitchen tool featuring a powerful 400W motor and multiple attachments, including a blending shaft, 1.5-cup food processor, masher, whisk, and beaker. Its SmartSpeed Technology allows for intuitive speed control, making various food preparation tasks simpler and more efficient.

2. Product Overview and Components

Familiarize yourself with the main components of your Braun MultiQuick MQ727 Immersion Hand Blender:

- **Motor Body:** The main unit housing the powerful 400W motor and SmartSpeed control.
- **Blending Shaft:** Stainless steel shaft with ultra-hard blades and PowerBell System for efficient blending.
- **1.5-Cup Food Processor:** For chopping, mincing, and dicing ingredients.
- **Masher:** Attachment for mashing cooked vegetables.
- **Whisk:** For whipping cream, beating eggs, and mixing batters.
- **Beaker:** A measuring cup suitable for blending small quantities.



Figure 1: Braun MultiQuick MQ727 Immersion Hand Blender main unit.



Figure 2: The Braun MultiQuick MQ727 Immersion Hand Blender shown with all its included accessories: blending shaft, food processor, masher, whisk, and beaker.

3. Setup

Before first use, wash all parts that will come into contact with food. Refer to the 'Cleaning and Maintenance' section for detailed instructions.

3.1 Attaching and Detaching Accessories (EasyClick System)

1. To attach an accessory (e.g., blending shaft, whisk gear box, food processor lid), align the accessory with the motor body and push until it clicks into place.
2. To detach, press the EasyClick release buttons on the sides of the motor body and pull the accessory off.

4. Operating Instructions

Always ensure the appliance is unplugged before attaching or detaching accessories.

4.1 SmartSpeed Technology

The MultiQuick MQ727 features SmartSpeed Technology, allowing you to intuitively adjust blending power. The more you press the speed button, the higher the speed. This provides precise control without needing to stop and adjust settings.



Figure 3: The SmartSpeed button allows for variable speed control based on pressure.

4.2 Immersion Blending (Blending Shaft)

Use the blending shaft for pureeing soups, sauces, and baby food, or for mixing drinks and smoothies. The unique PowerBell System and SplashControl Technology minimize splashing.

1. Attach the blending shaft to the motor body.
2. Immerse the blending shaft into the ingredients. Ensure the liquid covers the blade guard.
3. Press and hold the SmartSpeed button to start blending. Adjust pressure for desired speed.
4. Move the blender gently up and down and in circles to ensure even blending.
5. Release the SmartSpeed button to stop.



Figure 4: Using the immersion blender to process avocado for guacamole.



Figure 5: The blending shaft immersed in a beaker, ideal for smoothies and small batches.

4.3 Food Processor (1.5-Cup)

The 1.5-cup food processor is ideal for chopping herbs, nuts, cheese, and vegetables.

1. Place the chopping blade onto the center pin of the food processor bowl.
2. Add ingredients to the bowl.
3. Place the food processor lid onto the bowl and attach the motor body to the lid until it clicks.
4. Press and hold the SmartSpeed button to process. Use short pulses for coarse chopping or continuous pressure for finer results.
5. Release the button to stop.



Figure 6: The 1.5-cup food processor attachment in use for chopping vegetables.

4.4 Whisking

Use the whisk attachment for whipping cream, beating egg whites, and mixing light batters.

1. Insert the whisk into the whisk gear box.
2. Attach the whisk gear box to the motor body.
3. Place the whisk into the ingredients.
4. Press and hold the SmartSpeed button to start whisking.
5. Release the button to stop.

Figure 7: The whisk attachment being used to mix a sauce in a pot.

4.5 Mashing

The masher attachment is designed for mashing cooked vegetables like potatoes, sweet potatoes, and carrots.

1. Attach the masher to the motor body.
2. Place the masher into the cooked ingredients.
3. Press and hold the SmartSpeed button to begin mashing.
4. Move the masher gently through the ingredients until desired consistency is achieved.

5. Release the button to stop.

5. Cleaning and Maintenance

Proper cleaning and maintenance will ensure the longevity and optimal performance of your appliance.

5.1 General Cleaning

- Always unplug the appliance before cleaning.
- The motor body should only be wiped with a damp cloth. Do not immerse it in water or other liquids.
- The blending shaft, whisk, masher, food processor bowl, and beaker are dishwasher safe. Alternatively, they can be washed by hand in warm soapy water.
- Exercise caution when handling the sharp blades of the blending shaft and food processor.
- Ensure all parts are thoroughly dried before storing.

6. Troubleshooting

If you encounter issues with your Braun MultiQuick MQ727, refer to the following common solutions:

- **Appliance does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check if the safety lock button (if applicable) has been pressed before operating the SmartSpeed button.
- **Motor runs but blades do not move:** Verify that the attachment is correctly secured to the motor body. Detach and reattach the accessory, ensuring it clicks into place.
- **Poor blending/chopping results:** Ensure ingredients are cut into appropriate sizes before processing. Do not overload the food processor bowl. For blending, ensure sufficient liquid is present.
- **Unusual noise or smell:** Immediately stop using the appliance and unplug it. Contact customer support if the issue persists after checking basic connections.

7. Specifications

Feature	Detail
Brand	Braun
Model Number	MQ727 (0X22111257)
Power Source	Corded Electric
Voltage	230 Volts
Special Feature	Multiple Attachments, Variable Speeds (SmartSpeed Technology)
Capacity (Beaker)	600 Milliliters
Included Components	1.5-Cup Food Processor, Masher, Whisk, Beaker
Blade Material	Stainless Steel
Material Type Free	PFOA Free
Product Dimensions	2.24 x 2.24 x 15.59 inches

Item Weight	1.87 pounds

8. Warranty and Support

Your Braun MultiQuick MQ727 Immersion Hand Blender comes with a limited warranty. For specific warranty terms, conditions, and registration, please refer to the warranty card included in your product packaging or visit the official Braun website.

For technical support, service, or to order replacement parts, please contact Braun customer service. Contact information can typically be found on the Braun website or in your product documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074KK8FK8

More documents and user manuals: **https://manuals.plus/**