Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC DC Adapter

PKPOWER AC DC Adapter User Manual

For Accuteck W-8260 and W-8260-86 Digital Shipping Postal Scales

Model: AC DC Adapter

1. Product Overview

This manual provides essential instructions for the safe and effective use of your PKPOWER AC DC Adapter. This adapter is designed to provide reliable power to compatible devices, specifically Accuteck W-8260 and W-8260-86 Digital Shipping Postal Scales.

Key features include:

- **Input Voltage:** 100-240V AC, 50-60Hz
- **Safety Certifications:** CE, FCC, RoHS compliant
- **Protection Features:** Over Voltage Protection (OVP), Over Current Protection (OCP), Short Circuit Protection (SCP)



Figure 1: Front view of the PKPOWER AC DC Adapter with its integrated power cable.

2. Safety Instructions

Please read and understand these safety instructions before using the adapter. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected devices.

- Use the adapter only with compatible devices as specified.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not disassemble, modify, or attempt to repair the adapter.
- Ensure the power outlet is easily accessible and properly grounded.
- Avoid placing heavy objects on the power cord.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

3. Setup

Follow these steps to properly set up your AC DC Adapter:

1. **Identify the Device:** Ensure the device you intend to power is an Accuteck W-8260 or W-8260-86 Digital Shipping Postal Scale.
2. **Connect to Device:** Locate the power input port on your Accuteck scale. Carefully insert the adapter's output connector into the scale's power input port. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the adapter's AC prongs into a standard 100-240V AC wall outlet.



Figure 2: Side view of the adapter, highlighting the AC power prongs for wall outlet connection.

4. Operating Instructions

Once properly connected, the adapter will supply power to your Accuteck Digital Shipping Postal Scale. The scale should power on or begin charging its internal battery, if applicable, according to its own operational design.

- Verify that the scale powers on or indicates charging.
- If the scale does not power on, refer to the Troubleshooting section.



Figure 3: Rear view of the adapter, showing the cable extending from the unit to the device connector.

5. Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter.

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a dry, soft cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is observed, discontinue use immediately.

6. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not power on.	Adapter not properly connected to power outlet or device.	Ensure both ends of the adapter are securely plugged in. Try a different power outlet.
Device still does not power on.	Incompatible device or faulty adapter/device.	Verify the device is an Accuteck W-8260 or W-8260-86. If issues persist, contact customer support.
Adapter feels unusually hot.	Overload or internal fault.	Immediately unplug the adapter from the power outlet and device. Discontinue use and contact customer support.

If troubleshooting steps do not resolve the issue, please contact PKPOWER customer support.

7. Specifications

Brand	PKPOWER
Model Type	AC DC Adapter

Input Voltage	100-240V AC, 50-60Hz
Compatible Devices	Accuteck W-8260, Accuteck W-8260-86 Digital Shipping Postal Scales
Safety Certifications	CE, FCC, RoHS
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Color	Black
Power Source	Corded Electric

8. Warranty and Support

PKPOWER products are designed for reliability. For any questions, concerns, or technical assistance, please contact our customer service team.

- **Customer Service:** Our friendly and reliable customer service team aims to respond to inquiries within 24 hours.
- Please refer to your purchase documentation for specific warranty details.

© 2023 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074WMN1H8

More documents and user manuals: **https://manuals.plus/**