Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC DC Adapter for Vstarcam T6835WIP T7838WIP

PK Power AC DC Adapter User Manual

For Vstarcam T6835WIP and T7838WIP Wireless IP Cameras

1. Introduction

This manual provides essential information for the safe and effective use of your PK Power AC DC Adapter. This adapter is designed to provide reliable power to compatible devices, specifically Vstarcam T6835WIP and T7838WIP Wireless IP Cameras. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, observe the following precautions:

- This adapter is intended for indoor use only. Do not expose it to rain, moisture, or extreme temperatures.
- Ensure the adapter's voltage and current ratings match the requirements of your device.
- Do not disassemble, modify, or attempt to repair the adapter. Refer all servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use or during electrical storms.
- Keep the adapter away from heat sources, direct sunlight, and flammable materials.
- Avoid placing heavy objects on the power cord or adapter.

3. Product Overview

The PK Power AC DC Adapter is a compact and efficient power supply unit. It features a standard US plug and a durable power cord designed for reliable performance.



Image 1: PK Power AC DC Adapter and power cord.

This adapter incorporates multiple protection features to safeguard your devices:

- **OVP (Over Voltage Protection):** Prevents damage from excessive voltage.
- **OCP (Over Current Protection):** Protects against damage from excessive current.
- **SCP (Short Circuit Protection):** Automatically shuts off power in case of a short circuit.



Image 2: Overview of the adapter's built-in protection mechanisms.

The adapter's compact design ensures it fits easily into various spaces.



Image 3: Product dimensions and cable length.

4. Setup

Follow these steps to set up your PK Power AC DC Adapter:

1. Ensure your Vstarcam T6835WIP or T7838WIP Wireless IP Camera is powered off.
2. Connect the adapter's output connector securely into the power input port of your Vstarcam IP Camera.
3. Plug the adapter's AC plug into a standard 100-240V wall outlet.
4. Verify that the connection is firm and the adapter is fully inserted into the outlet.

5. Operating Instructions

Once properly connected, the PK Power AC DC Adapter will supply continuous power to your Vstarcam IP Camera. The camera should power on automatically or can be turned on according to its own operating instructions.

- The adapter is designed for continuous operation within its specified limits.

- Always ensure adequate ventilation around the adapter to prevent overheating.

6. Maintenance

Proper maintenance ensures the longevity and performance of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

7. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on	Adapter not properly connected; Power outlet not functioning; Faulty adapter or device.	Ensure all connections are secure. Try plugging the adapter into a different, known-working outlet. Test the device with another compatible power source if available.
Adapter feels warm during use	Normal operation; Overload.	It is normal for adapters to generate some heat during operation. If the adapter feels excessively hot or emits a burning smell, unplug it immediately and discontinue use. Ensure adequate ventilation.
Intermittent power supply	Loose connection; Damaged cable.	Check all connections for tightness. Inspect the power cable for any visible damage. If damaged, replace the adapter.

8. Specifications

Technical specifications for the PK Power AC DC Adapter:

Feature	Detail
Input Voltage	100-240V AC, 50-60Hz
Wattage	18 Watts
Connector Type	Auxiliary
Compatible Devices	Vstarcam T6835WIP, T7838WIP Wireless IP Cameras
Color	Black
Certifications	CE, FCC, RoHS
Protection Features	OVP, OCP, SCP
Cable Length	1.2 meters (4 feet)

Feature	Detail
Adapter Dimensions (approx.)	1.18in (W) x 1.58in (D) x 2.92in (H)

9. Warranty and Support

PK-Power products are manufactured to high standards and undergo rigorous testing. For any inquiries or support needs, our customer service team is available to assist you.

- **Customer Service:** Our friendly and reliable customer service will respond to your inquiries within 24 hours.
- **Online Support:** For additional information or to contact support, please visit thePKPOWER Store on Amazon.

© 2025 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074WN9C3F

More documents and user manuals: **https://manuals.plus/**