Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

USARMT HTR-A18M

Instruction Manual

USARMT Replacement Remote Control for Haier LED TVs (Model: HTR-A18M)

Introduction Compatibility Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides instructions for the USARMT Replacement Remote Control, model HTR-A18M, designed for various Haier LED and LCD televisions. This remote is pre-programmed and requires no additional setup beyond battery installation.



Image: Front view of the USARMT HTR-A18M remote control. It is black with clearly labeled buttons for power, input, numbers, volume, channel, menu, navigation, and media playback.

2. Compatible TV Models

This remote control is compatible with the following Haier LED and LCD TV models:

- 32D3000
- LE32M600M20

- LE32F32200
- LE24M600M80
- LE24F33800
- LE32M600M80
- LE55F32800
- LE39F32800
- 65D3550
- LE39M600M80
- 40D3500M
- 48D3500
- LE48M600M80
- LE50M600M80
- 55D3550
- LE55M600M80
- LE58F3281

If your Haier TV model is not listed, please verify compatibility with the manufacturer or seller.

3. Setup

The USARMT HTR-A18M remote control is pre-programmed and does not require any manual setup or code entry. Simply install the batteries to begin operation.

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment.
4. Close the battery cover by sliding it back into place until it clicks securely.



Image: Back view of the USARMT HTR-A18M remote control with the battery compartment open, showing where two AAA batteries are inserted.

4. Operating Instructions

This section describes the functions of the buttons on your remote control.





Image: Close-up view of the buttons on the USARMT HTR-A18M remote control, showing the layout and labels of each function button.

Button	Function
Power (●)	Turns the TV on or off.
Input	Selects the input source (HDMI, AV, etc.).
USB	Accesses content from a connected USB device.
CC	Activates or deactivates Closed Captions.
0-9	Direct channel selection.
Recall	Switches to the previously viewed channel.
VOL (+/-)	Adjusts the volume level.
MUTE	Mutes or unmutes the TV audio.
CH (+/-)	Changes the TV channel up or down.
MENU	Opens the TV's main menu.
BACK	Returns to the previous menu or screen.
DISPLAY	Shows current channel information or status.
EXIT	Exits the current menu or function.
SAP	Selects Secondary Audio Program (if available).
SLEEP	Sets the sleep timer for the TV.
WIDE	Adjusts the screen aspect ratio.
AUDIO	Selects audio modes or tracks.
PICTURE	Adjusts picture settings (brightness, contrast, etc.).
Navigation Arrows (▲ ▼ ◄ ►)	Navigates through menus and options.
OK	Confirms selections in menus.
CH.LIST	Displays the channel list.
FAVORITE	Accesses favorite channels list.
Color Buttons (Red, Green, Yellow, Blue)	Functions vary depending on the TV menu or application.
Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next)	Controls media playback for compatible content (e.g., from USB).

5. Maintenance

Cleaning the Remote:

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Do not use abrasive cleaners or immerse the remote in water.

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA). Dispose of used batteries according to local regulations.

6. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with proper polarity (+/-).
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote and the TV's infrared sensor.
  - Ensure you are pointing the remote directly at the TV.
- **Some buttons not working:**
  - This may indicate low battery power; try replacing the batteries.
  - Ensure the remote is clean and there is no debris stuck under the buttons.
- **TV not turning on/off:**
  - Verify the TV is plugged into a power outlet and is not in standby mode due to a power outage.
  - Test the TV's power button directly on the TV itself.

If issues persist after following these steps, contact customer support.

7. Specifications

Feature	Detail
Model	HTR-A18M
Brand	USARMT (Replacement for Haier)
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Special Feature	Ergonomic, Pre-programmed
Item Weight	3.2 ounces

8. Warranty and Support

Return Policy:

This product is offered with a 30-day hassle-free return policy. Please refer to your purchase documentation for specific terms and conditions regarding returns and exchanges.

Customer Support:

For further assistance or inquiries, please contact the seller or manufacturer through the platform where the product was purchased.

© 2023 USARMT. All rights reserved. Haier is a registered trademark of its respective owner.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074XJ8HW9

More documents and user manuals: **https://manuals.plus/**