Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER TRA0003013

PK Power AC Adapter DC Charger for Korg EC350 Digital Piano (TRA0003013) User Manual

Model: TRA0003013

Introduction

This manual provides essential instructions for the safe and effective use of your PK Power AC Adapter DC Charger, specifically designed for the Korg EC350 Digital Piano. Please read this manual thoroughly before use and retain it for future reference.

Safety Instructions

- Ensure the adapter's voltage and current ratings match your device's requirements.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or repair the adapter. Refer servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.
- Ensure proper ventilation around the adapter during operation.

Package Contents

Verify that your package contains the following items:

- 1 x PK Power AC Adapter DC Charger
- 2 x Power Cords (as per product specifications)



Image 1: The PK Power AC Adapter DC Charger with its accompanying power cords. The main adapter unit is black and rectangular, connected to a DC output cable. Two separate AC input power cords are shown, one with a two-prong plug and the other with a three-prong plug, both coiled.

Setup

1. **Identify the Correct Power Cord:** Select the appropriate AC input power cord for your region and electrical outlet type.
2. **Connect AC Power Cord:** Plug one end of the selected AC power cord into the AC input port of the PK Power adapter.



Image 2: A close-up view of the PK Power AC Adapter with one of the AC input power cords connected to its input port. The adapter is black and rectangular, and the power cord is black with a two-prong plug.

3. **Connect DC Output Cable:** Plug the barrel connector of the adapter's DC output cable into the power input jack of your Korg EC350 Digital Piano. Ensure a secure connection.

4. **Plug into Wall Outlet:** Insert the AC power cord's plug into a standard wall electrical outlet.

Operating Instructions

Once the adapter is correctly connected to both the power outlet and your Korg EC350 Digital Piano, the piano should be ready to power on. Refer to your Korg EC350 Digital Piano's user manual for specific power-on procedures.

- Ensure all connections are firm before powering on your device.
- Always power off your Korg EC350 Digital Piano before disconnecting the adapter.



Image 3: The PK Power AC Adapter shown alongside both included AC input power cords. The adapter is black, and the two power cords are coiled, ready for connection. This image illustrates the complete set of components.

Maintenance

- **Cleaning:** Disconnect the adapter from the power source and your device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cables to prevent damage.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Adapter not properly connected to power outlet or device.	Ensure all connections are secure. Try a different power outlet.
Adapter feels unusually hot.	Poor ventilation or overloaded circuit.	Ensure adequate airflow around the adapter. Disconnect and allow to cool. If problem persists, discontinue use.

Problem	Possible Cause	Solution
Visible damage to adapter or cables.	Physical damage.	Discontinue use immediately to prevent electrical hazards. Contact customer support.

Specifications

- **Input:** 100-240V 50-60Hz
- **Connector Type:** Barrel connector
- **Compatible Devices:** Korg EC350 Digital Piano (TRA0003013)
- **Included Components:** 2 x Power Cords
- **Special Feature:** Portable, Lightweight
- **Specification Met:** CE, FCC, RoHS
- **Power Source:** Corded Electric
- **Main Power Connector Type:** 2 Pin

Warranty and Support

PK-Power products are certified to meet or exceed OEM specifications, including OVP (Over Voltage output Protection), OCP (Over Current output Protection), and SCP (Short Circuit output Protection) for safety.
For any questions, concerns, or support needs, our customer service team is available to assist you. Please allow up to 24 hours for a response.
For further assistance, please visit the PKPOWER Store on Amazon.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075G6SY4D

More documents and user manuals: **https://manuals.plus/**