Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER EMX512SC/EMX512

PK Power AC Power Cable Plug User Manual

Model: EMX512SC/EMX512

Introduction

This manual provides essential information for the safe and effective use of your PK Power AC Power Cable Plug. This cable is designed to provide reliable power connectivity for compatible audio equipment, specifically the Yamaha EMX512SC and EMX 512 Mixer Amps. Please read this manual thoroughly before use and retain it for future reference.

Safety Information

Always observe the following safety precautions to prevent electric shock, fire, or damage to the product or connected equipment:

- Ensure the power cable is fully inserted into both the power outlet and the device's power input.
- Do not use the cable if it is damaged, frayed, or has exposed wires.
- Avoid placing heavy objects on the cable or bending it sharply.
- Do not expose the cable to water, excessive moisture, or extreme temperatures.
- Disconnect the cable from the power source before cleaning or moving the connected equipment.
- This cable is designed for specific voltage and current ratings. Do not exceed these limits.

Product Overview

The PK Power AC Power Cable Plug is a standard power cord featuring a male plug for the wall outlet and a female receptacle for the device. It is designed to connect your compatible audio equipment to a standard AC power outlet.



Figure 1: PK Power AC Power Cable Plug

This image displays the black AC power cable. One end features a standard two-prong Type B male plug, suitable for North American wall outlets. The other end has a female C13 connector, which typically plugs into electronic devices like mixer amps. The cable is coiled for storage, highlighting its flexibility and compact design.

Setup

Follow these steps to properly set up your power cable:

1. Ensure your Yamaha EMX512SC or EMX 512 Mixer Amp is turned off.
2. Locate the power input port on your mixer amp.
3. Insert the female end of the PK Power AC Cable firmly into the power input port of the mixer amp.
4. Insert the male plug end of the PK Power AC Cable into a standard, grounded AC power outlet.
5. Once connected, you may turn on your mixer amp.



Figure 2: Cable ends for connection

This image provides an overhead view of the power cable, emphasizing the two distinct ends: the standard two-prong wall plug and the C13 female connector. The cable itself is black and appears durable, coiled loosely to show its length and flexibility. This view is useful for identifying the correct orientation for connection.

Operating Instructions

The PK Power AC Power Cable Plug is a passive component designed for power transmission. Once properly connected to your device and a power source, it will supply the necessary electrical current to operate your equipment. No further operational steps are required for the cable itself.

Maintenance

Proper care and maintenance will extend the life of your power cable:

- **Cleaning:** Disconnect the cable from all power sources before cleaning. Wipe the cable and connectors with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, coil the cable loosely. Avoid tight coiling or kinking, which can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the cable for any signs of damage, such as cuts, fraying, or bent prongs. If damage is found, discontinue use immediately and replace the cable.

Troubleshooting

If you experience issues with your power cable, consider the following common solutions:

Problem	Possible Cause	Solution
Device not powering on.	Cable not fully inserted.	Ensure both ends of the cable are securely plugged into the device and the wall outlet.
Device not powering on.	No power from outlet.	Test the outlet with another device or check your circuit breaker.
Device not powering on.	Damaged cable.	Inspect the cable for visible damage. If damaged, replace it immediately.

Specifications

Key specifications for the PK Power AC Power Cable Plug:

- **Input Voltage:** 100-240V 50-60Hz
- **Connector Type:** Male plug (Type B) to Female receptacle (C13)
- **Plug Format:** Type B (for the wall plug)
- **Color:** Black
- **Certifications:** CE / FCC / RoHS certified
- **Protection:** OVP (Over Voltage output Protection), OCP (Over Current output Protection), SCP (Short Circuit output Protection)
- **Compatible Models:** Yamaha EMX512SC, Yamaha EMX 512 Mixer Amp

Warranty Information

PKPOWER products are typically covered by a manufacturer's warranty. For specific details regarding the warranty period and terms for your AC Power Cable Plug, please refer to the product packaging or contact PKPOWER customer service directly. Keep your purchase receipt as proof of purchase.

Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact PKPOWER customer service. Our friendly and reliable customer service team aims to respond within 24 hours.

Manufacturer: PKPOWER

Please visit the official PKPOWER store on Amazon for more information or to contact support:PKPOWER Amazon Store

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075NKZH91

More documents and user manuals: **https://manuals.plus/**