Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bodum Bistro 11754-01EURO

Bodum Bistro 11754-01EURO Programmable Coffee Maker

Instruction Manual

Important Safeguards Product Overview Setup Operating Instructions Cleaning & Maintenance Troubleshooting Specifications Warranty & Support

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or coffee maker in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycles.
- This appliance is intended for household use only.

Product Overview

The Bodum Bistro Programmable Coffee Maker is designed to brew up to 12 cups (1.5 liters) of filter coffee. It features an innovative shower system for even water distribution and a permanent filter for convenience.



Image: Front view of the Bodum Bistro Programmable Coffee Maker, showcasing its sleek black design and glass carafe.

Key Features:

- **Innovative Shower System:** Ensures even saturation of coffee grounds for optimal flavor extraction.
- **Permanent Filter:** Eliminates the need for disposable paper filters.
- **24-Hour Programmability:** Set the coffee maker to brew at a desired time within a 24-hour period.
- **30-Minute Warm Hold Function:** Keeps coffee warm after brewing.
- **Borosilicate Glass Jug:** Durable glass carafe with a soft Santoprene handle for comfortable grip.

Components:

1. Water Reservoir with Lid
2. Shower Head

3. Filter Basket (with permanent filter)
4. Glass Carafe with Lid
5. Heating Plate
6. Control Panel (Program, Hour, Min buttons, Power button)
7. Digital Display

Setup

Unpacking and Initial Cleaning:

1. Carefully remove all packaging materials from the coffee maker.
2. Wash the glass carafe, its lid, and the permanent filter in warm, soapy water. Rinse thoroughly and dry. These parts are also dishwasher safe.
3. Wipe the exterior of the coffee maker with a damp cloth.
4. Place the coffee maker on a flat, stable, heat-resistant surface.

First Use (Cleaning Cycle):

Before brewing coffee for the first time, run a cleaning cycle to remove any manufacturing residues.

1. Fill the water reservoir with fresh, cold water up to the 12-cup (1.5 L) mark.
2. Ensure the permanent filter is in place in the filter basket, but do not add coffee grounds.
3. Place the empty glass carafe with its lid on the heating plate.
4. Plug the coffee maker into a suitable electrical outlet (220V).
5. Press the Power button to start a brewing cycle. Allow the full cycle to complete.
6. Discard the water from the carafe. Your coffee maker is now ready for use.

Operating Instructions

Brewing Coffee:


Program
Hour
Min
bodum
12
10
8
6
4

Image: The Bodum Bistro Programmable Coffee Maker on a counter, with two coffee cups, illustrating its use in a home setting.

1. Open the water reservoir lid and fill the reservoir with the desired amount of fresh, cold water. Refer to the water level markings.
2. Place the permanent filter into the filter basket. Add your preferred amount of ground coffee to the permanent filter. A general guideline is one tablespoon of coffee per cup (150ml). Adjust to taste.
3. Ensure the filter basket is properly seated and close the water reservoir lid.
4. Place the empty glass carafe with its lid on the heating plate.
5. Plug the coffee maker into the electrical outlet.
6. Press the Power button to begin the brewing process. The indicator light will illuminate.
7. Once brewing is complete, the coffee maker will automatically switch to the 30-minute warm hold function.
8. To turn off the coffee maker before the warm hold cycle ends, press the Power button again.

Setting the Program Timer (Delayed Brewing):

The 24-hour programmable timer allows you to set the coffee maker to start brewing automatically at a later time.

1. Prepare the coffee maker for brewing as described in steps 1-5 above (water, coffee, carafe in place).
2. Press the "Program" button. The display will flash.
3. Use the "Hour" and "Min" buttons to set the desired brew start time.
4. Press the "Program" button again to confirm the setting. The "Program" indicator light will illuminate, indicating that the delayed brew is set.
5. The coffee maker will automatically start brewing at the programmed time.
6. To cancel the programmed brew, press the "Program" button until the indicator light turns off.

Using the Keep Warm Function:

After brewing, the coffee maker automatically enters a 30-minute warm hold cycle. The heating plate will keep the coffee in the carafe warm during this period. After 30 minutes, the coffee maker will automatically shut off.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

Daily Cleaning:

1. Always unplug the coffee maker before cleaning and allow it to cool completely.
2. Remove the permanent filter and discard used coffee grounds. Rinse the filter under running water.
3. Wash the glass carafe and its lid in warm, soapy water. Rinse thoroughly. These parts are dishwasher safe.
4. Wipe the exterior surfaces of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
5. Do not immerse the main unit of the coffee maker in water or any other liquid.

Descaling:

Mineral deposits (limescale) can build up in your coffee maker over time, affecting performance. Descale your coffee maker every 2-3 months, or more frequently if you have hard water.

1. Fill the water reservoir with a mixture of white vinegar and water (1 part vinegar to 2 parts water). Do not exceed the 12-cup mark.
2. Place the empty carafe with its lid on the heating plate.

3. Run a full brewing cycle without coffee grounds.
4. After the cycle, turn off the coffee maker and let the vinegar solution sit in the carafe for 15-20 minutes.
5. Discard the solution and rinse the carafe thoroughly.
6. Run 2-3 cycles with fresh, cold water only to flush out any remaining vinegar taste or odor.

Troubleshooting

Problem	Possible Cause	Solution
Coffee does not brew.	• Coffee maker not plugged in. • Power button not pressed. • Program timer set incorrectly. • Water reservoir empty.	• Ensure the coffee maker is securely plugged into a working outlet. • Press the Power button. • Check the program settings and adjust if necessary. • Fill the water reservoir with water.
Coffee is too weak or too strong.	• Incorrect coffee-to-water ratio. • Coffee grounds too coarse/fine.	• Adjust the amount of coffee grounds to your preference. • Use medium-ground coffee for drip coffee makers.
Water overflows from filter basket.	• Too much coffee grounds. • Filter basket not seated correctly. • Clogged permanent filter.	• Reduce the amount of coffee grounds. • Ensure the filter basket is properly inserted. • Clean the permanent filter thoroughly.
Coffee maker leaks.	• Carafe not positioned correctly. • Water reservoir overfilled.	• Ensure the carafe is centered on the heating plate. • Do not fill water above the maximum fill line.

Specifications

Model: Bistro 11754-01EURO

Capacity: 1.5 Liters (approximately 12 cups)

Dimensions (L x W x H): 7.09 x 9.45 x 14.76 inches

Weight: 4.85 pounds

Voltage: 220V

Power Source: Electric

Coffee Input Type: Ground Coffee

Special Feature: Programmable (24-hour)

Warm Hold Function: 30 minutes

Exterior Finish: Stainless Steel and Soft Santoprene

Operation Mode: Fully Automatic

Human Interface Input: Buttons

Included Components: Permanent Filter, Glass Carafe

Dishwasher Safe Parts: Glass Carafe, Carafe Lid, Permanent Filter

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Bodum website. Keep your purchase receipt as proof of purchase.
Manufacturer: Bodum

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075S8MNYS

More documents and user manuals: **https://manuals.plus/**