Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC Power Cord

PKPOWER AC Power Cord User Manual

For Sharp GXCH150, GXCH50, QTCD111, QT-CD121, QTCD131, QTCD210C, QT-CD131C, QTCD210, QTCD114 CD Boombox Models

Introduction

This manual provides instructions for the safe and effective use of your PKPOWER AC Power Cord. This power cord is designed as a replacement or spare for various Sharp CD Boombox models, ensuring reliable power delivery to your device.

Please read this manual thoroughly before using the product to ensure proper setup and operation.

1. Setup Instructions

1. **Unpack the Power Cord:** Carefully remove the PKPOWER AC Power Cord from its packaging. Inspect the cord for any visible damage. Do not use if the cord or connectors appear damaged.
2. **Identify the Device Power Inlet:** Locate the AC power inlet on your Sharp CD Boombox. This is typically a two-prong or three-prong port designed for a standard power cable.
3. **Connect to Device:** Insert the device-end connector of the PKPOWER AC Power Cord firmly into the AC power inlet of your Sharp CD Boombox. Ensure a snug fit.
4. **Connect to Power Outlet:** Plug the wall-end connector of the power cord into a standard, grounded electrical wall outlet (100-240V, 50-60Hz). Ensure the outlet is easily accessible.



Image 1: The PKPOWER AC Power Cord, showing both the wall plug and the device connector.

Safety Precautions:

- Ensure the power outlet voltage matches the cord's specifications (100-240V).
- Do not force the plug into an outlet.
- Keep the power cord away from water, heat sources, and sharp objects.
- Avoid placing heavy objects on the cord.

2. Operating Instructions

Once the PKPOWER AC Power Cord is securely connected to both your Sharp CD Boombox and a live electrical outlet, your device is ready to receive power. Turn on your CD Boombox using its power button as you normally would.



Image 2: The PKPOWER AC Power Cord, coiled for storage, highlighting its compact design.

3. Maintenance

- **Cleaning:** Disconnect the power cord from both the device and the wall outlet before cleaning. Wipe the cord and connectors with a dry, soft cloth. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, coil the power cord loosely and store it in a dry, cool place away from direct sunlight and extreme temperatures. Avoid tight coiling or kinking, which can damage the internal wires.
- **Inspection:** Periodically inspect the power cord for any signs of wear, cuts, fraying, or damage to the insulation or connectors. If any damage is observed, discontinue use immediately and replace the cord.

4. Troubleshooting

Device Does Not Power On:

- **Check Connections:** Ensure the power cord is securely plugged into both the Sharp CD Boombox and the wall outlet.
- **Verify Power Outlet:** Test the wall outlet with another device to confirm it is supplying power. If the outlet is not working, try a different one.
- **Inspect Cord:** Examine the power cord for any visible damage. If damaged, replace the cord.
- **Device Power Button:** Confirm that the power button on your Sharp CD Boombox is pressed or switched to the 'On' position.

5. Product Specifications

- **Input Voltage:** 100-240V AC, 50-60Hz
- **Connector Type:** Male-to-Female (Standard US 2-prong wall plug to Figure-8 device connector)
- **Certifications:** CE / FCC / RoHS certified
- **Protection Features:**

- OVP (Over Voltage Output Protection)
- OCP (Over Current Output Protection)
- SCP (Short Circuit Output Protection)

- **Compatibility:** Designed for Sharp GXCH150, GXCH50, QTCD111, QT-CD121, QTCD131, QTCD210C, QT-CD131C, QTCD210, QTCD114 CD Boombox models.
- **Manufacturer:** PKPOWER
- **Date First Available:** September 12, 2017

6. Warranty and Support

PKPOWER products are tested by the manufacturer to match and/or exceed OEM specifications, ensuring quality and reliability.

For any questions, concerns, or support needs regarding your PKPOWER AC Power Cord, please contact our customer service. Our friendly and reliable customer service team aims to respond to inquiries within 24 hours.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B076CJ2YCG

More documents and user manuals: **https://manuals.plus/**