Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire FFMV1645TD

Frigidaire FFMV1645TD Over-The-Range Microwave Oven User Manual

Model: FFMV1645TD | Brand: Frigidaire

Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Frigidaire FFMV1645TD Over-The-Range Microwave Oven. Please read all instructions thoroughly before using your appliance to ensure proper function and to prevent potential hazards.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of burns, electric shock, fire, injury to persons, or exposure to excessive microwave energy.

- Read all instructions before using the appliance.
- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Ensure the appliance is properly grounded.
- Do not heat sealed containers, as they may explode.
- Supervise children closely when the appliance is in use.

Setup and Installation

This Frigidaire FFMV1645TD microwave is designed for over-the-range installation. Proper installation is crucial for safety and performance. It is recommended that installation be performed by a qualified installer.

Pre-Installation Checklist:

- Verify all components are present: microwave oven, mounting plate, top cabinet template, wall template, hardware bag, turntable.

- Ensure the mounting surface is structurally sound and capable of supporting the microwave's weight.
- Confirm electrical requirements: A dedicated 120V, 60Hz, 15 or 20 Amp grounded outlet is required.
- Measure cabinet dimensions to ensure proper fit. The microwave dimensions are approximately 29.87 inches (W) x 16.4 inches (D) x 15.25 inches (H).



Figure 1: Frigidaire FFMV1645TD Microwave with key dimensions: 29.87 inches width, 16.4 inches depth, and 15.25 inches height. This image illustrates the overall size for installation planning.

Installation Steps (Summary):

1. Attach the mounting plate to the wall studs, ensuring it is level and securely fastened.
2. Drill holes in the upper cabinet for the power cord and mounting bolts using the provided template.
3. Lift the microwave onto the mounting plate and feed the power cord through the hole.
4. Secure the microwave to the upper cabinet using the mounting bolts.
5. Connect the power cord to the grounded outlet.
6. Install the turntable and turntable support inside the microwave cavity.

Refer to the detailed installation guide included with your appliance for complete step-by-step instructions and safety warnings.

Operating Instructions

Your Frigidaire FFMV1645TD microwave oven offers various cooking functions for convenience and efficiency.



Figure 2: Front view of the Frigidaire FFMV1645TD Over-The-Range Microwave, showing the control panel and door handle.

Basic Microwave Cooking:

1. Place food in a microwave-safe container on the turntable.
2. Close the oven door securely.
3. Enter the desired cooking time using the number pad.
4. Press the "START" button. The oven will begin cooking at 100% power.
5. To adjust power level, press "Power Level" before "START" and select a level from 1-10.

Auto Defrost:

The Auto Defrost feature allows for quick and efficient defrosting of various food items based on weight.

1. Place frozen food on a microwave-safe dish.
2. Press the "Defrost" button.
3. Enter the weight of the food using the number pad.
4. Press "START". The oven will calculate the defrosting time and power level automatically.

Pre-set Cooking Functions:

Utilize the pre-set buttons for common items like Popcorn, Potato, and Beverage for optimized cooking results.

- **Popcorn:** Press the "Popcorn" button once for a standard bag.
- **Potato:** Press the "Potato" button and select the number of potatoes.
- **Beverage:** Press the "Beverage" button for a standard cup of liquid.

Always refer to the food packaging for specific cooking instructions and recommended microwave settings.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave oven.

Exterior Cleaning:

- Wipe the exterior surfaces with a soft cloth dampened with mild soap and water.
- For black stainless steel, use a non-abrasive cleaner specifically designed for stainless steel to avoid scratching.
- Dry thoroughly with a soft, clean cloth.

Interior Cleaning:

- Remove the turntable and turntable support. Wash them in warm, soapy water or in the dishwasher.
- Wipe the interior cavity with a damp cloth and mild detergent. For stubborn food splatters, place a bowl of water with lemon slices inside and microwave for 2-3 minutes to loosen residue, then wipe clean.
- Ensure the door seals and sealing surfaces are clean and free of food particles.

Filter Maintenance:

- The grease filters (located on the underside of the microwave) should be cleaned regularly, typically monthly, or as needed.
- Remove the filters by sliding them out. Wash them in hot, soapy water or in a dishwasher.
- Replace the filters once dry.

Troubleshooting

Before contacting service, review the following common issues and their solutions.

Problem	Possible Cause	Solution
Microwave does not start.	Door not closed properly; Power cord unplugged; Blown fuse/tripped circuit breaker.	Ensure door is firmly closed; Check power cord connection; Reset circuit breaker or replace fuse.
Food not cooking evenly.	Food not stirred/rotated; Turntable not rotating; Incorrect power level/cooking time.	Stir or rotate food during cooking; Ensure turntable is properly seated; Adjust cooking time/power.
Oven light not working.	Light bulb burned out.	Consult the service manual for instructions on replacing the light bulb, or contact qualified service personnel.
Excessive steam from vent.	High moisture content in food.	This is normal during cooking. Ensure proper ventilation.

If the problem persists after attempting these solutions, please contact Frigidaire customer support.

Specifications

Feature	Detail
Model Number	FFMV1645TD
Brand	Frigidaire
Capacity	1.6 Cubic Feet
Installation Type	Over-the-Range

Feature	Detail
Wattage	1000 watts
Color	Black Stainless Steel
Material	Stainless Steel
Product Dimensions (W x D x H)	29.87" x 16.4" x 15.25"
Special Features	Turntable, Auto Defrost
Included Components	Turntable
Certification	CDRH Approved

Warranty and Support

Frigidaire appliances typically come with a limited warranty covering defects in material and workmanship. For specific warranty details, including duration and coverage, please refer to the warranty card included with your product or visit the official Frigidaire website.
For technical assistance, troubleshooting beyond this manual, or to schedule service, please contact Frigidaire Customer Support:

- **Online Support:** Visit the official Frigidaire website (www.frigidaire.com) for FAQs, product registration, and service requests.
- **Phone Support:** Refer to your product registration materials or the Frigidaire website for the most current customer service phone numbers.

When contacting support, please have your model number (FFMV1645TD) and serial number ready.

© 2023 Frigidaire. All rights reserved.
This manual is for informational purposes only and may be subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B076VVFDPF

More documents and user manuals: **https://manuals.plus/**