Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER Universal 3.5mm Male-to-Male Auxiliary Cable (Compatible with Sharper Image EC-B145, EC-B160, EC-A115, EC-W100, EC-W160,

PK Power AUX Line in Cable User Manual

Model: Universal Auxiliary Cable

Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your PK Power AUX Line in Cable. This cable is designed to connect audio devices with a 3.5mm auxiliary input/output. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.
Compatible Models: The Sharper Image EC-B145, EC-B160, EC-A115, EC-W100, EC-W160, EC-P115, EC-A130 Speaker/Radio/Dock models.

Product Overview



Image Description: A black PK Power AUX Line in Cable, coiled neatly, showcasing both male 3.5mm connectors. The cable appears durable and flexible, ready for connection.



Image Description: The PK Power AUX Line in Cable, partially uncoiled, displaying its length and the two 3.5mm male connectors. This view emphasizes the cable's overall design and connector type.



Image Description: A close-up view of the two 3.5mm male connectors of the PK Power AUX Line in Cable. The connectors feature standard tip, ring, sleeve (TRS) configuration, indicating stereo audio compatibility.

Setup Instructions

1. **Identify Ports:** Locate the 3.5mm auxiliary input (AUX IN) port on your audio receiving device (e.g., Sharper Image Speaker/Radio/Dock) and the 3.5mm auxiliary output (AUX OUT or Headphone Jack) port on your audio source device (e.g., smartphone, MP3 player).
2. **Connect First End:** Insert one end of the PK Power AUX Line in Cable into the 3.5mm output port of your audio source device. Ensure it is fully seated.
3. **Connect Second End:** Insert the other end of the PK Power AUX Line in Cable into the 3.5mm input port of your audio receiving device. Ensure it is fully seated.
4. **Power On Devices:** Turn on both your audio source device and your audio receiving device.
5. **Select Input:** On your audio receiving device, select the "AUX" or "Line In" input source. Refer to your device's manual if you are unsure how to change input sources.

The cable is now set up for audio transmission.

Operating Instructions

Once the cable is connected and the correct input source is selected on your audio receiving device:

- **Play Audio:** Begin playing audio from your source device (e.g., music, podcast, video).
- **Adjust Volume:** Adjust the volume on both your audio source device and your audio receiving device to achieve the desired listening level. It is often recommended to set the source device volume to a high level (e.g., 75-90%) and control the main volume from the receiving device.
- **Disconnecting:** To disconnect, simply pull the connectors firmly from both devices. Avoid pulling on the cable itself to prevent damage.

Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to wipe the cable and connectors. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, coil the cable loosely. Avoid tight coiling or sharp bends, which can damage the internal wires. Store in a cool, dry place away from direct sunlight.
- **Handling:** Always grasp the connector housing when plugging or unplugging the cable. Never pull on the cable itself.
- **Environmental Conditions:** Avoid exposing the cable to extreme temperatures, humidity, or corrosive substances.

Troubleshooting

No Audio Output:

- Ensure both ends of the cable are fully inserted into their respective ports.
- Verify that both the audio source device and the audio receiving device are powered on.
- Check that the correct input source (AUX/Line In) is selected on your audio receiving device.
- Increase the volume on both the source device and the receiving device.
- Test the cable with different devices to rule out issues with the source or receiving equipment.

Static or Distorted Audio:

- Ensure connections are secure and free from debris.
- Try adjusting the volume levels on both devices. Overdriving the input can cause distortion.
- Check for any nearby electronic interference.
- Test with another cable if available to determine if the issue is with the cable or the devices.

Only One Channel of Audio (Left or Right):

- Ensure the 3.5mm connectors are fully inserted. A partial insertion can sometimes result in mono audio or missing channels.
- Check the audio settings on your source device to ensure stereo output is selected.
- Inspect the connectors for any visible damage or bent pins.

Product Specifications

Brand	PKPOWER
Connector Type	3.5mm Male to 3.5mm Male (TRS)
Connector Gender	Male-to-Male

Cable Type	Auxiliary Audio Cable
Compatibility	The Sharper Image EC-B145, EC-B160, EC-A115, EC-W100, EC-W160, EC-P115, EC-A130 Speaker/Radio/Dock models, and other devices with standard 3.5mm AUX ports.
Certifications	CE / FCC / RoHS certified (for PK-Power products in general)
UPC	716833333900

Warranty and Support

PK-Power products are tested by the manufacturer to match and/or exceed OEM specifications. For any inquiries or support needs, our customer service team is available to assist you.
Customer Service: Our friendly and reliable customer service will respond to you within 24 hours. Please refer to your purchase documentation for contact details or visit the official PKPOWER store on Amazon.
Return Policy: The standard return policy allows for returns within 30 days for refund or replacement. Please check your purchase details for specific terms.

© 2025 PKPOWER. All rights reserved.
This manual is for informational purposes only. PKPOWER is not responsible for any damages or injuries resulting from improper use of this product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07716FNVK

More documents and user manuals: **https://manuals.plus/**