Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HANGSUN FM180 / NECALON

Hangsun FM180 Foot Spa Bath Massager User Manual

Model: FM180 / NECALON

Product Overview

The Hangsun FM180 Foot Spa Bath Massager is designed to provide a comprehensive foot relaxation experience. It integrates multiple functions to soothe tired feet, promote circulation, and relieve stress.



Image: Top view of the Hangsun FM180 Foot Spa Bath Massager, showcasing its design and control dial.

Key features include:

- **Four Functions in One:** Vibration massage, Bubble massage, Infrared heat, and Water heat preservation.
- **Magnetic Therapy:** Designed to relax tense foot muscles and stimulate blood circulation.
- **Massage Rollers:** Two removable active massage rollers for deep foot massage.
- **Anti-Splash Design:** Removable splash guard to prevent spills.
- **Durable Construction:** Made with high-quality ABS material and IPX4 waterproof level.



Image: Diagram illustrating key features of the foot spa, including leakage protection, massage footbed, infrared lighting, massage rollers, bubble & vibration massage, and automatic thermostat.

Safety Information

Warning:

- Do not use the device near water or other liquids.
- Ensure the device is completely dry before using it.
- Avoid contact with electrical devices when your hands or feet are wet.
- Always unplug the unit before filling or emptying water, and before cleaning.
- Do not stand in the foot spa. Use only while seated.
- Keep out of reach of children.
- Consult a doctor before use if you have any medical conditions, especially diabetes, circulatory problems, or open wounds.

Setup

1. **Unpacking:** Carefully remove the foot spa from its packaging. Inspect the unit for any signs of damage.
2. **Placement:** Place the foot spa on a flat, stable, and dry surface. Ensure it is near an electrical outlet but away from any water sources.
3. **Filling with Water:** Ensure the unit is unplugged. Fill the foot spa with warm or cold water up to the indicated maximum fill line. Do not overfill.
4. **Optional Additives:** You may add foot salts or essential oils as desired, ensuring they are suitable for use with foot spas and do not cause excessive foaming.
5. **Plug In:** Once filled, plug the power cord into a suitable electrical outlet.



Image: Dimensions of the Hangsun FM180 Foot Spa, showing its height, width, and length, and indicating suitability for feet up to 12 inches.



Image: The Hangsun FM180 Foot Spa shown with its retail packaging, highlighting the product's presentation.

Operating Instructions

The Hangsun FM180 Foot Spa features a rotary switch to select different massage modes. Ensure your feet are clean before use.



Image: Detailed view of the Hangsun FM180 Foot Spa with key components labeled, including the splash guard, bubble strip, massage attachments, infrared light dots, pedicure attachments, foot rest with massage naps, and rotary switch.

1. **Power On:** With the unit plugged in and filled with water, turn the rotary switch to your desired setting.
2. **Select Mode:**
    - **OFF:** Turns the unit off.
    - **W+B:** Activates Water Heat Preservation and Bubble massage.
    - **M+IR:** Activates Massage Rollers and Infrared heat.
    - **W+B+M+IR:** Activates Water Heat Preservation, Bubble massage, Massage Rollers, and Infrared heat simultaneously.
3. **Foot Placement:** Gently place your feet into the foot spa. Ensure your feet are comfortably positioned on the footbed.
4. **Massage Rollers:** The two active massage rollers can be used by gently moving your feet back and forth over

them. These rollers are removable if you prefer not to use them.

5. **Duration:** Enjoy the foot spa for a recommended duration of 15-30 minutes.
6. **Power Off:** After use, turn the rotary switch to the "OFF" position and unplug the unit from the electrical outlet.



Image: Close-up view of the control panel, massage rollers, and infrared light on the Hangsun FM180 Foot Spa, illustrating the three working modes.



Image: A person's feet immersed in the Hangsun FM180 Foot Spa, demonstrating typical use in a home setting.

Maintenance

1. **Emptying Water:** After use, unplug the unit. Use the integrated pour spout to carefully empty the water.
2. **Cleaning:** Clean the foot spa with a soft cloth and mild detergent. Do not use abrasive cleaners or harsh chemicals. Rinse thoroughly with clean water.
3. **Drying:** Allow the unit to air dry completely before storing. Ensure no water remains in the basin or around electrical components.
4. **Storage:** Store the foot spa in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Ensure power cord is securely plugged into a working outlet. Test the outlet with another device. If problem persists, contact customer support.
Bubbles/Vibration not working.	Incorrect mode selected; blockage in air jets.	Check that the rotary switch is set to a mode that includes bubbles (W+B or W+B+M+IR). Ensure air jets are clear of debris.
Water temperature not maintained.	Incorrect mode selected; initial water temperature too low.	Ensure the rotary switch is set to a mode that includes water heat preservation (W+B or W+B+M+IR). The unit maintains temperature, it does not heat cold water rapidly. Start with warm water for best results.
Unit is noisy.	Normal operation of bubble/vibration functions.	Some noise is normal during operation, especially when bubbles and vibration are active. This is not typically a malfunction.

If you encounter issues not listed here, please refer to the support section or contact customer service.

Specifications

Feature	Detail
Brand	HANGSUN
Model Number	NECALON (FM180)
Product Dimensions	43 x 25 x 33 cm (1.31 kg)
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	Corded Electric
Special Features	Heat, Waterproof (IPX4)
Functions	Vibration massage, Bubble massage, Infrared heat, Water heat preservation
Use For	Foot

Warranty and Support

The Hangsun FM180 Foot Spa Bath Massager comes with a**One Year Warranty**, guaranteeing satisfaction with your

purchase.



Image: The Hangsun FM180 Foot Spa displayed alongside its packaging, featuring a "Guaranteed One Year Warranty Satisfaction" seal.

For product support, warranty claims, or further inquiries, please visit the official Hangsun website:

www.hangsun.eu

Please retain your proof of purchase for warranty purposes.

© 2024 HANGSUN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B077HRTT2M

More documents and user manuals: **https://manuals.plus/**