USARMT 5J.JAD06.001

USARMT Replacement Remote Control for BenQ Projectors

Model: 5J.JAD06.001

1. Introduction

This manual provides instructions for the USARMT replacement remote control, model 5J.JAD06.001, designed for use with various BenQ projector models. This remote is pre-programmed and requires no additional setup beyond battery installation.

2. Compatible Projector Models

This remote control is compatible with the following BenQ projector models:

- MW824ST, MX823ST, MW855UST, MW727, MW726, MW632ST
- MP623, MP624, MH680, MS517, MH630, TH682ST
- MS513, MS521P, MS504, MS614, MS517F, MS521
- MX620ST, MX505, MX522P, MX660, MX615, MX613ST
- MX518, MX520, MX618ST, MX662, MX661, MX504, MX505, MX522
- MS500, MS500+, MS510, MS513P, MS513P-V, MS614
- W1080ST, W1070, W1070+, MW663, MW516, MW821ST
- MX514, MX518F, MX662, EX7775ST, EP7635, MX666
- EP7330UST, EP7232, BW7635, ML8498, W1400, W1500, W750
- TH1070, HD227D, TH750, W1300, BX8730ST, DX806ST
- MX842UST, MW843UST, EP7730, MW721, TX766

3. Setup and Battery Installation

The USARMT replacement remote control is pre-programmed and does not require any additional setup or pairing with your BenQ projector. Simply install the batteries to begin operation.

3.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover open in the direction indicated by the arrow (if present).
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries.

4. Operating Instructions

The remote control provides full functionality for your BenQ projector. Refer to the image below for button layout and descriptions.





Figure 1: USARMT Replacement Remote Control Layout. This image displays the full layout of the remote control, showing all buttons and their labels.

4.1. Button Functions

Button	Function
ON (Red)	Powers on the projector.
OFF (Red)	Powers off the projector.
COMPUTER 1 / 2	Selects Computer 1 or Computer 2 input source.
VIDEO	Selects Video input source.
HDMI	Selects HDMI input source.
S-VIDEO	Selects S-Video input source.
NETWORK	Activates or deactivates network functions.
MENU / EXIT	Opens the projector's on-screen menu or exits the current menu.
AUTO	Automatically adjusts the image settings.
MODE / ENTER	Selects display modes or confirms menu selections.
ECO BLANK	Blanks the screen and activates Eco mode for power saving.
SOURCE	Cycles through available input sources.
LASER	Activates the laser pointer function (if available on projector).
MHL	Selects MHL input source.

Button	Function
Navigation Arrows (Up, Down, Left, Right)	Navigates through menu options and adjusts settings.
Volume Up/Down	Adjusts the audio volume.
Play/Pause, Stop, Fast Forward, Rewind	Controls media playback (if supported by projector).
ZOOM (+/-)	Adjusts the digital zoom level of the projected image.
PAGE (+/-)	Navigates through pages in presentations.
MIC/VOL (+/-)	Adjusts microphone volume (if applicable).
FREEZE	Pauses the current image on the screen.
ASPECT	Cycles through aspect ratio settings.
MUTE	Mutes or unmutes the audio.
NETWORK SETTING	Accesses network configuration settings.
QUICK INSTALL	Initiates quick installation or setup wizard.
SMART ECO	Activates or deactivates Smart Eco mode for optimized power consumption.

5. Maintenance

5.1. Cleaning the Remote Control

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, alcohol, or solvents, as these can damage the remote's finish or internal components.

5.2. Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Follow the battery installation steps outlined in Section 3.1. Dispose of used batteries according to local regulations.

6. Troubleshooting

Problem	Possible Cause	Solution
Remote control does not work.	◦ Batteries are dead or inserted incorrectly. ◦ Obstruction between remote and projector. ◦ Remote is too far from the projector. ◦ Infrared sensor on projector is blocked.	◦ Replace batteries with new ones, ensuring correct polarity. ◦ Remove any objects blocking the line of sight. ◦ Move closer to the projector. ◦ Ensure the projector's IR sensor is clean and unobstructed.

Problem	Possible Cause	Solution
Some buttons do not respond.	◦ Button malfunction. ◦ Projector does not support the specific function.	◦ Check if other buttons work. If not, replace batteries. ◦ Refer to your projector's manual to confirm supported features.

7. Specifications

- **Brand:** USARMT
- **Model:** 5J.JAD06.001
- **Connectivity Technology:** Infrared (IR)
- **Special Features:** Pre-programmed, Infrared
- **Compatible Devices:** BenQ Projectors
- **Max Number of Supported Devices:** 1
- **Item Weight:** Approximately 113.4 g (without batteries)

8. Warranty and Support

Specific warranty information for this USARMT replacement remote control is not provided in the product details. Please refer to the retailer or manufacturer's website for any available warranty terms or customer support contact information.