Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wahl HomePro Haircut Kit

Wahl HomePro Haircut Kit Instruction Manual

Model: HomePro Haircut Kit

Brand: Wahl

Introduction

Welcome to the Wahl HomePro Haircut Kit. This comprehensive 22-piece kit is designed to provide you with the tools necessary for achieving professional-quality haircuts and grooming at home. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

What's Included

Your Wahl HomePro Haircut Kit includes the following items:

- Multi-cut clipper (corded)
- Blade guard
- Durable storage case with handle
- Barber comb
- Styling comb
- Pocket comb
- Scissors
- Blade oil
- Cleaning brush
- 3 Hair clips
- Ten guide combs for various cutting lengths:
  - 1/8" (3mm)
  - 1/4" (6mm)
  - 3/8" (10mm)
  - 1/2" (13mm)
  - 5/8" (16mm)
  - 3/4" (19mm)
  - 7/8" (22mm)

- 1" (25mm)
- Left ear taper
- Right ear taper

- Illustrated instructions (English and Spanish)



Image: The Wahl HomePro 22-Piece Haircut Kit, showcasing the multi-cut clipper, various guide combs, scissors, combs, and other

accessories neatly arranged within its durable handled storage case.

Setup

1. **Unpack the Kit:** Carefully remove all components from the storage case.
2. **Initial Blade Oiling:** Before the first use, apply a few drops of the included Wahl clipper oil to the blades. Turn the clipper on for a few seconds to allow the oil to distribute evenly. This ensures smooth operation and extends blade life.

   Note: The clipper blades are high-carbon steel, precision ground to stay sharp longer. Regular oiling is crucial for maintaining this sharpness.
3. **Inspect Components:** Check all guide combs, the clipper, and accessories for any damage.
4. **Power Connection:** Ensure the clipper is switched off before plugging it into a suitable electrical outlet. This is a corded clipper and does not require batteries.

Operating Instructions

Attaching Guide Combs

Select the desired guide comb for your preferred hair length. Each comb is marked with its length (e.g., 1/8", 3mm). To attach, align the comb with the clipper blade and push firmly until it clicks into place. To remove, pull the comb away from the blade.

Adjusting the Taper Lever

The clipper features an adjustable taper lever located on the side. This lever allows you to fine-tune the cutting length without changing guide combs. Moving the lever up shortens the cut, while moving it down lengthens it. This is useful for blending and fading.

Haircutting Techniques

For best results, always cut against the direction of hair growth. Use smooth, overlapping strokes. Start with a longer guide comb than you think you need, and gradually work your way down to shorter lengths if desired. The ergonomic shape of the clipper makes it easy to hold and cut at different angles, providing comfort and control.

▶ **Watch video online**
Wahl Home Pro Hair Clipper Easy Haircuts at Hom

Video: A demonstration of the Wahl HomePro Hair Clipper in use, showing how to achieve easy haircuts at home. This video illustrates the clipper's features and basic haircutting techniques.

Maintenance

1. **Cleaning Blades:** After each use, turn off and unplug the clipper. Use the included cleaning brush to remove loose hairs from the blades.
2. **Oiling Blades:** To maintain optimal cutting performance and prevent rust, apply 2-3 drops of Wahl clipper oil to the blades after every few haircuts or as needed. Turn the clipper on for a few seconds to distribute the oil. Wipe off any excess oil.
3. **Storage:** Always replace the blade guard when the clipper is not in use. Store the clipper and all accessories in the durable storage case in a cool, dry place.

Troubleshooting

- **Clipper pulls hair or cuts poorly:**
  - Ensure blades are clean and properly oiled.
  - Check if the blades are aligned correctly. Refer to the full instruction manual for blade alignment procedures if necessary.
  - The guide comb might be clogged with hair; clean it thoroughly.
- **Clipper runs hot:**
  - Ensure blades are well-oiled. Lack of lubrication can cause friction and heat.
  - Avoid prolonged continuous use. Allow the clipper to cool down if it becomes excessively warm.
- **Clipper does not turn on:**
  - Check the power cord connection and the electrical outlet.
  - Ensure the ON/OFF switch is fully engaged.

Specifications

- **Model:** HomePro Haircut Kit
- **Power Source:** Corded Electric
- **Blade Material:** High-Carbon Steel
- **Minimum Cutting Length:** 1.0 hundredths in.
- **Maximum Cutting Length:** 10 mm (with included guide combs up to 25mm/1 inch)
- **Weight:** Approximately 0.762 kg (1.68 Pounds)
- **Dimensions:** 10.2 x 6.97 x 2.99 inches (Package Dimensions)
- **Special Features:** Multigroomer, Adjustable Taper Lever
- **UPC:** 043917924366

Safety Information

Please observe the following safety precautions:

- **Choking Hazard:** Keep all small parts and the clipper away from children under 3 years of age.
- **Burn Risk:** The clipper blades may become hot during extended use. Avoid direct contact with skin if the blades feel excessively warm to prevent burns.
- **Water Exposure:** This appliance is not waterproof. Keep the clipper away from water and do not use it near bathtubs, showers, basins, or other vessels containing water.
- **Intended Use:** This product is intended for home use only. Warranty may be void if used commercially.

Warranty and Support

Your Wahl HomePro Haircut Kit comes with a **Five-Year Limited Warranty**. For details regarding the warranty, please refer to the information provided within the product packaging. This warranty is valid in the U.S.A. only. Outside the U.S.A., please check with your local Wahl authorized distributor for warranty information.

Additionally, a **30-Day Money Back Guarantee** is offered.

For more great tips, ideas, and support, please visit the official Wahl website: wahlhaircuts.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078ZS7W8J

More documents and user manuals: **https://manuals.plus/**