Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coleman 2000026160

Coleman Coral Reef 4-Person Dome Tent

Model: 2000026160

Introduction Safety Information Setup Operation Maintenance Troubleshooting Specifications Warranty Support

Introduction

This manual provides instructions for the proper setup, operation, maintenance, and troubleshooting of your Coleman Coral Reef 4-Person Dome Tent, Model 2000026160. Please read all instructions carefully before using the tent to ensure safe and efficient use.

Safety Information

WARNING: Keep all flame and heat sources away from this tent fabric. The tent is made with flame-resistant fabric, which meets CPAI-84 specifications. It is not fireproof. If left in continuous contact with any flame source, the fabric will burn. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

- Do not use fuel-burning appliances inside or near the tent.
- Do not cook inside the tent.
- Do not store flammable liquids inside the tent.
- Ensure proper ventilation to avoid suffocation.
- Always secure the tent with all stakes and guy lines provided to prevent damage from wind.

Setup Instructions

The Coleman Coral Reef 4-Person Dome Tent is designed for lightweight and easy installation, typically assembling in approximately 8 minutes.

1. **Unpack and Layout:** Remove the tent from its carry bag. Unroll the tent body and lay it flat on the ground at your chosen campsite. Ensure the floor is spread out evenly.
2. **Assemble Poles:** Connect the shock-corded tent poles. The tent typically uses two main poles that cross over the top.
3. **Insert Poles:** Slide the assembled poles through the fabric sleeves on the tent body.
4. **Secure Poles:** Insert the ends of the poles into the pins located at each corner of the tent base. This will cause the

tent to take its dome shape.

5. **Attach Clips:** Secure the tent body to the poles using the plastic clips located along the tent fabric.
6. **Position Rainfly:** Drape the rainfly over the tent body, ensuring the door and window openings align.
7. **Attach Rainfly:** Secure the rainfly to the tent poles or base using the provided buckles, hooks, or elastic loops.
8. **Stake Down Tent:** Use the included stakes to secure all four corners of the tent to the ground. For added stability, stake out the guy lines attached to the rainfly.



Image: The Coleman Coral Reef 4-Person Dome Tent shown fully assembled, both with its protective rainfly and without, illustrating its dome structure.

Operation

The Coleman Coral Reef Dome Tent is designed for comfort and protection in various weather conditions, having been tested in rain and wind. It features a water-resistant design.

Doors and Zippers

The tent features a zippered door for entry and exit. Always use the zipper pulls to open and close the door smoothly. Avoid forcing zippers to prevent damage. Ensure zippers are fully closed to keep insects and moisture out.

Ventilation

The tent includes mesh windows and/or vents to provide airflow and reduce condensation. Open these as needed for ventilation. The rainfly can be adjusted to allow for airflow while still providing protection from rain.

Interior Storage

Utilize the interior mesh pockets for storing small, lightweight items such as phones, keys, or headlamps. This helps keep the tent floor clear and organized.



Image: A close-up view of an interior mesh storage pocket within the tent, holding sunglasses, a headlamp, and other small personal items for convenient organization.

Maintenance

Cleaning

To clean your tent, follow these instructions:

- **Spot Cleaning:** For small dirt spots, use a soft sponge or cloth with mild soap and cold water. Gently rub the affected area.
- **Hand Washing:** The tent fabric is suitable for hand washing. Do not machine wash or tumble dry, as this can damage the fabric and waterproof coatings.
- **Rinsing:** Rinse thoroughly with cold water to remove all soap residue.
- **Drying:** Always allow the tent to air dry completely before packing it away. Lay it out in a shaded area or hang it. Do not expose to direct sunlight for prolonged periods, as UV rays can degrade the fabric.
- **Avoid Harsh Chemicals:** Do not use bleach, harsh detergents, or solvents, as these can damage the tent's waterproof coating and fabric integrity.

Storage

Proper storage extends the life of your tent:

- Ensure the tent is completely dry before folding and storing to prevent mildew and odors.
- Fold the tent neatly and place it back into its original carry bag.
- Store the tent in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Tent Not Standing Firmly

Issue: The tent feels unstable or sags after setup.
Solution:

- Ensure all poles are fully assembled and correctly inserted into the corner pins.
- Verify that all fabric clips are attached to the poles.
- Make sure all tent corners and guy lines are securely staked into the ground. Adjust tension as needed.

Water Leaks

Issue: Water is entering the tent during rain.
Solution:

- Check that the rainfly is correctly positioned and fully extended over the tent body.
- Ensure all rainfly attachment points are secured.
- Inspect seams for any damage or areas where seam sealant may have worn off. Apply a seam sealer if necessary.
- Verify that windows and doors are fully zipped closed.

Zipper Malfunction

Issue: Zippers are sticking or not closing properly.
Solution:

- Gently pull the fabric taut around the zipper area to relieve tension.
- Clean any dirt or debris from the zipper teeth.
- Apply a zipper lubricant (e.g., silicone spray or zipper wax) to the teeth.
- Avoid forcing the zipper, as this can cause permanent damage.

Specifications

Feature	Detail
Brand	Coleman
Model Number	2000026160
Occupancy Capacity	4 Persons
Design	Dome Tent
Material	Plastic *(Note: This likely refers to pole material or specific components, main fabric is typically polyester/nylon)*
Color	Green
Seasons	All Weather
Water Resistance Level	Water Resistant
Installation Type	Freestanding
Closure Type	Zipper
Item Weight	9.3 Pounds (approximately 4.2 kg)

Assembly Required	Yes
UPC	076501135930

Warranty Information

Coleman products are manufactured to high-quality standards. For specific warranty details regarding your Coleman Coral Reef 4-Person Dome Tent, Model 2000026160, please refer to the warranty documentation included with your purchase or contact Coleman customer support directly. The product description states: "Ask about our warranties." Typically, Coleman offers a limited warranty against defects in materials and workmanship. Keep your proof of purchase for any warranty claims.

Customer Support

If you have any questions, require assistance with setup, or need to troubleshoot an issue not covered in this manual, please contact Coleman customer support.
For the most up-to-date contact information, please visit the official Coleman website or refer to the contact details provided in your product packaging.
You can also visit the **Coleman Brand Store on Amazon** for more product information and resources.

© 2023 Coleman. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0792M7MLX

More documents and user manuals: **https://manuals.plus/**