Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

eufy AK-T21041F2

eufy RoboVac 11+ User Manual

Model: AK-T21041F2

1. Introduction

The eufy RoboVac 11+ is an automated house-cleaning robot designed to simplify your cleaning routine. It efficiently tackles dust and debris on various floor types, allowing you to enjoy a cleaner home with minimal effort.

Its low-profile design enables it to clean under furniture, reaching hidden and hard-to-access areas. The RoboVac 11+ features upgraded wheels that can traverse over medium-pile carpets and climb thresholds up to 0.59 inches high, ensuring seamless movement between rooms.



Image: The eufy RoboVac 11+ in its sleek black design, ready for operation.



Image: The RoboVac 11+ demonstrating its premium materials with a sleek glass top, observed by a cat on a carpeted floor.

2. Setup

Before first use, ensure all packaging materials are removed from the RoboVac and its accessories. Place the charging base against a wall in an open, uncluttered area, ensuring there are no obstacles within 3 feet to the front and 1 foot to either side.

Connect the AC power adapter to the charging base and plug it into a wall outlet. For optimal battery life, always keep the RoboVac on the charging base when not in use.

The remote control requires 2 AAA batteries (included). Insert them according to the polarity markings inside the battery compartment.

For optimal performance, clear any cables or small objects from the floor that could entangle the RoboVac.

3. Operation

The RoboVac 11+ offers multiple cleaning modes and can be scheduled for automatic cleaning. It features an upgraded 3-Point Cleaning System, including a redesigned rolling brush, two side brushes, and powerful suction for a thorough clean.

BoostIQ™ Technology: This new feature automatically increases suction power when extra vacuuming strength is needed, such as when transitioning from hard floors to carpets. This ensures the best clean across different surfaces.



Image: Visual representation of the RoboVac 11+'s upgraded cleaning performance, highlighting its new Power Boost Technology (now BoostIQ), 2nd Gen 3-Point Cleaning System, and 1000Pa suction power.



Image: The RoboVac 11+ demonstrating its upgraded mobility, with a streamlined bumper design allowing it to glide effortlessly under furniture.



Image: The RoboVac 11+ on a carpet, illustrating its enhanced climbing wheels and ability to traverse ledges and clean medium-pile carpets.

Official Product Video: eufy RoboVac 11+ with Power Boost Tech

Your browser does not support the video tag.

Video: This video demonstrates the eufy RoboVac 11+ in action, showcasing its cleaning capabilities and the Power Boost Technology (now known as BoostIQ) as it navigates and cleans various surfaces.

Optimal Use Conditions:

- Use on low-pile carpet, tile, laminate, and hardwood floors.
- Not suitable for high-pile carpet or very dark-colored floors.
- Move cables out of the way to avoid entanglement.

4. Maintenance

Regular maintenance is crucial for the optimal performance and longevity of your RoboVac 11+. This includes cleaning

the dust collector, filters, side brushes, and rolling brush.

An enhanced inlet filter keeps large debris out, maintaining strong suction power. Regularly check and clean the filter to ensure efficient operation.



Image: A diagram illustrating the improved airflow and enhanced inlet filter design of the RoboVac 11+, which helps maintain strong suction power by preventing large debris from entering.

Cleaning Schedule:

- **Dust Collector:** Empty after each use.
- **Filter:** Clean weekly, replace every 2-3 months.
- **Side Brushes:** Clean monthly, replace every 3-6 months.
- **Rolling Brush:** Clean weekly, replace every 6-12 months.

5. Troubleshooting

If your RoboVac encounters an issue, refer to the following common solutions:

- **RoboVac gets stuck:** Ensure cables, small toys, or other obstacles are cleared from the cleaning path. The RoboVac may get stuck under furniture with low clearance; consider using boundary strips (sold separately) if this is a recurring issue in specific areas.
- **Reduced suction power:** Check and clean the dust collector and filter. Ensure the rolling brush and side brushes are free of tangled hair or debris.
- **RoboVac does not charge:** Ensure the charging base is properly plugged in and the power indicator light is on. Clean the charging contacts on both the RoboVac and the charging base.
- **Unusual noise:** Inspect the rolling brush and side brushes for any foreign objects or damage. Clean the wheels and ensure they rotate freely.

For more detailed troubleshooting steps or persistent issues, please refer to the full user guide or contact customer support.

6. Specifications

Brand	eufy
Model Number	AK-T21041F2
Special Feature	Bagless
Included Components	Brush, Remote Control, Charging Base, AC Power Adapter, Cleaning Tool, Extra High-Performance Filters, Extra Side Brushes
Filter Type	Disk
Battery Life	Up to 100 minutes (Standard mode on hardwood floors)
Power Source	Corded Electric
Batteries Required	1 Lithium Ion battery (for RoboVac), 2 AAA batteries (for remote)
Control Method	Remote
Compatible Devices	Amazon Echo
Form Factor	Robotic
Product Dimensions	12.8 x 12.8 x 3.35 inches
Item Weight	6.66 pounds
UPC	848061065367

7. Warranty and Support

The eufy RoboVac 11+ comes with a worry-free 12-month warranty, ensuring peace of mind regarding your purchase.

For comprehensive information, detailed instructions, and further assistance, please refer to the official User Guide:

Download Official User Manual (PDF)

You can also visit the official eufy store for product updates and additional support:

Visit the eufy Store

© 2024 eufy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0793JP3MK

More documents and user manuals: **https://manuals.plus/**