Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun LS5160

Braun Silk-Epil Lady Shaver LS5160 User Manual

Model: LS5160

Introduction

This manual provides important information regarding the safe operation, maintenance, and care of your Braun Silk-Epil Lady Shaver LS5160. Please read these instructions carefully before using the appliance and keep them for future reference.

The Braun Silk-Epil Lady Shaver LS5160 is designed for effortless hair removal and skin care. It features a 3-in-1 system that trims, exfoliates, and shaves, offering a comprehensive solution for smooth and radiant skin. The device is 100% waterproof, allowing for comfortable wet or dry use.

Product Overview



Image 1: The Braun Silk-Epil Lady Shaver LS5160, shown with its main body, the trimmer cap, and the exfoliation cap. The shaver features a light blue and white design with an ergonomic grip.

The Braun Silk-Epil Lady Shaver LS5160 is a versatile personal grooming device. Key components include:

- **Shaver Head:** Equipped with a foil and cutter block for efficient hair removal.
- **On/Off Switch:** For operating the device.
- **Battery Compartment:** Located at the base, for two AA batteries.
- **Trimmer Cap:** An attachment for precise trimming of hair.
- **Exfoliation Cap:** An attachment designed to gently remove dead skin cells.



Image 2: The Braun Silk-Epil Lady Shaver LS5160 displayed with all its included accessories, including the main shaver unit, the trimmer cap, the exfoliation cap, and two additional comb attachments for varying trim lengths.

Safety Information

- Keep the appliance dry when not in use.
- Do not use on irritated skin, open wounds, or if you have skin conditions. Consult a doctor if unsure.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use the appliance for its intended purpose as described in this manual.
- Ensure batteries are inserted with correct polarity.
- Remove batteries if the appliance is not used for an extended period.

Setup

Inserting Batteries

1. Ensure the shaver is switched off.
2. Twist the battery compartment cover at the bottom of the shaver counter-clockwise and remove it.
3. Insert two AA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.

4. Replace the battery compartment cover and twist clockwise until securely closed.

Note: Two AA batteries are included with your purchase.

Attaching/Detaching Caps

The shaver comes with a trimmer cap and an exfoliation cap. To attach a cap:

1. Ensure the shaver is switched off.
2. Align the desired cap with the shaver head.
3. Gently press the cap onto the shaver head until it clicks into place.

To detach a cap, gently pull it away from the shaver head.

Operating Instructions

The Braun Silk-Epil Lady Shaver LS5160 can be used for shaving, trimming, and exfoliating.

General Use

- Press the On/Off switch to turn on the shaver.
- Hold the shaver at a right angle (90°) to your skin.
- Stretch your skin with your free hand to ensure a smooth surface.
- Move the shaver slowly against the direction of hair growth.
- The shaver is 100% waterproof and suitable for both wet and dry use. For wet use, apply shaving foam or gel to your skin.

Shaving



Image 3: A detailed view of the Braun Silk-Epil Lady Shaver's head, showing the protective foil and the integrated trimmer blade, designed for a close and comfortable shave.

For a close shave, use the shaver head directly on your skin without any caps. Move the shaver gently over the desired area.

Trimming

Attach the trimmer cap for precise hair trimming. This is ideal for sensitive areas or for preparing longer hair before shaving.

1. Attach the trimmer cap to the shaver head.
2. Turn on the shaver.
3. Move the trimmer against the direction of hair growth, ensuring the cap maintains contact with the skin.

Exfoliating

Use the exfoliation cap to gently remove dead skin cells and promote smoother skin. This can be done before or after shaving.

1. Attach the exfoliation cap to the shaver head.
2. Turn on the shaver.
3. Gently glide the exfoliation cap over your skin in circular motions or short strokes.
4. Rinse your skin after exfoliating.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your Braun Silk-Epil Lady Shaver.

Cleaning the Shaver Head

1. Ensure the shaver is switched off and remove any attached caps.
2. Rinse the shaver head under running water. You can also use the included cleaning brush to remove trapped hairs.
3. Allow the shaver head to air dry completely before reattaching caps or storing.

Cleaning Caps

Rinse the trimmer and exfoliation caps under running water after each use. Allow them to air dry completely.

Battery Replacement

When the shaver's performance decreases, it's time to replace the AA batteries. Follow the "Inserting Batteries" steps in the Setup section.

Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Batteries are depleted or incorrectly inserted.	Replace batteries with new AA batteries, ensuring correct polarity.
Poor shaving performance.	Shaver head is clogged with hair or worn out.	Clean the shaver head thoroughly. If performance does not improve, consider replacing the shaver head (available separately).

Problem	Possible Cause	Solution
Skin irritation after use.	Incorrect shaving technique or sensitive skin.	Ensure skin is clean and dry (for dry shave) or properly lubricated with foam/gel (for wet shave). Move the shaver gently. Use the exfoliation cap regularly to prevent ingrown hairs. If irritation persists, discontinue use and consult a dermatologist.
Shaver makes unusual noise.	Hair trapped in the mechanism or damaged shaver head.	Clean the shaver head thoroughly. Inspect for any visible damage. If the noise persists, contact customer support.

Specifications

Feature	Detail
Model Name	Silk-Epil Lady Shaver LS5160
Item Model Number	4210201192619
Brand	Braun
Power Source	Battery Powered (2 x AA batteries)
Water Resistance	100% Waterproof (Wet & Dry use)
Included Components	Lady Shaver, Trimmer Cap, Exfoliation Cap, 2 AA Batteries
Product Dimensions	22.2 x 15.5 x 5.7 cm
Item Weight	248 g
Colour	Blue
Recommended Uses	Exfoliating, Shaving

Warranty and Support

Braun products are manufactured to the highest standards of quality, safety, and reliability. For detailed warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Braun website.
In case of any issues or questions regarding your Braun Silk-Epil Lady Shaver LS5160, please contact Braun Customer Service. Keep your proof of purchase for warranty claims.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079D3WY8Q

More documents and user manuals: **https://manuals.plus/**