Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun TexStyle 7 ProStyle 4661, TS735, 710, 720, 730

Braun Power Cable Terminal Block Instruction Manual

For TexStyle 7 and ProStyle Steam Irons (Models 4661, TS735, 710, 720, 730)

1. Introduction

This document provides essential instructions for the safe and correct installation, operation, and maintenance of your Braun replacement power cable terminal block. This component is designed for specific Braun TexStyle 7 and ProStyle steam iron models. Please read this manual thoroughly before attempting any installation or repair.

2. Safety Instructions

- **Electrical Hazard:** Always disconnect the steam iron from the main power supply before attempting any installation, maintenance, or repair. Failure to do so can result in electric shock, injury, or death.
- **Professional Installation Recommended:** Installation of this component involves working with electrical wiring. If you are not confident in your ability to perform this task safely, it is strongly recommended to seek assistance from a qualified technician.
- **Use Correct Tools:** Ensure you have the appropriate tools, such as insulated screwdrivers, for the task.
- **Inspect for Damage:** Before installation, carefully inspect the new power cable and terminal block for any signs of damage. Do not install if any damage is observed.
- **Secure Connections:** Ensure all electrical connections are secure and properly insulated to prevent short circuits.

3. Product Overview

The Braun replacement power cable terminal block is a complete assembly designed to restore power functionality to compatible steam irons. It includes the internal terminal block for connection within the iron and the external power cord with a Type F plug.



Figure 1: Braun Power Cable Terminal Block Assembly. This image displays the complete replacement power cable assembly. On the left is the white terminal block housing, showing internal wiring connections (blue, yellow/green). The grey braided power cable extends from this block, leading to a standard two-pin European Type F plug on the right.

Compatible Models:

- Braun TexStyle 7 ProStyle 4661 - 710
- Braun TexStyle 7 ProStyle 4661 - 720
- Braun TexStyle 7 ProStyle 4661 - 730
- Braun TexStyle 7 ProStyle 4661 - TS735TP

4. Setup and Installation

Follow these steps carefully to replace the power cable terminal block. Remember to prioritize safety.

1. **Disconnect Power:** Ensure the steam iron is unplugged from the electrical outlet.
2. **Allow to Cool:** If the iron was recently used, allow it to cool completely before handling.
3. **Access Internal Components:** Carefully open the iron's casing to access the existing power cable connection. This may require removing screws or clips. Refer to your specific iron model's service manual if available.
4. **Document Connections:** Before disconnecting the old cable, take a photograph or make a diagram of how the wires are connected to the terminal block. This will serve as a reference for the new installation.
5. **Remove Old Cable:** Disconnect the wires from the old terminal block and carefully remove the old power cable assembly.
6. **Install New Cable:** Connect the wires from the new power cable terminal block to the corresponding points inside the iron. Ensure the connections match your documentation from step 4 (e.g., live, neutral, earth).
7. **Secure Terminal Block:** Secure the new terminal block within the iron's casing, ensuring it is firmly in place and does not interfere with other components.
8. **Reassemble Iron:** Carefully close and secure the iron's casing. Ensure all screws and clips are properly fastened.
9. **Test Functionality:** Plug the iron into a suitable electrical outlet and perform a brief test to ensure it powers on correctly. Observe for any unusual smells, sounds, or sparks. If any issues arise, immediately unplug the iron and re-check the installation.

5. Operating

Once the power cable terminal block is correctly installed, the iron can be operated as usual. Ensure the power plug is fully inserted into a functional electrical outlet before use.

6. Maintenance

- **Regular Inspection:** Periodically inspect the power cable for any signs of wear, cuts, fraying, or damage. If damage is observed, discontinue use and replace the cable.
- **Cleanliness:** Keep the power cable and plug clean and free from dust or debris.
- **Proper Storage:** When not in use, store the iron with the cable neatly coiled, avoiding sharp bends or kinks that could damage the internal wires.

7. Troubleshooting

If the iron does not power on after replacing the power cable terminal block:

- **Check Power Outlet:** Ensure the electrical outlet is functional by testing it with another appliance.
- **Verify Connections:** Unplug the iron and carefully re-open the casing to verify that all wires are securely connected to the terminal block and that there are no loose connections or incorrect wiring.
- **Inspect for Internal Damage:** Look for any signs of internal damage to the iron's components that might have been overlooked during installation.
- **Professional Assistance:** If the issue persists, seek assistance from a qualified appliance repair technician.

8. Specifications

Feature	Detail
Brand	Braun
Product Dimensions	16.5 x 11.5 x 8.5 cm
Item Weight	0.3 Kilograms
Voltage	220 Volts (AC)
Connector Gender	Female to Male
Plug Type	Type F
Case Material Type	Plastic
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant

9. Warranty and Support

For warranty information regarding this replacement part, please refer to your original purchase documentation or contact the retailer from whom the part was acquired. For technical support or further assistance, please contact Braun customer service or visit the official Braun website.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07B6S8KBQ

More documents and user manuals: **https://manuals.plus/**