Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wsky H2

Wsky Portable Video Projector H2 User Manual

Model: H2

Introduction Product Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the Wsky Portable Video Projector H2. This manual provides essential information for the safe and efficient use of your projector. Please read it thoroughly before operation and retain it for future reference.

2. Product Overview

The Wsky Portable Video Projector H2 is designed for home entertainment, supporting HD 1080p resolution. It features an 84-LED projection technology for enhanced clarity and brightness, dual speakers for integrated audio, and multiple input interfaces for broad device compatibility.



Image: The Wsky Portable Video Projector H2, showcasing its ability to project high-definition content, such as a colorful underwater scene.

Key Features:

- **Improved 84-LED Projection Technology:** Offers 75% clearer and brighter images compared to standard 48-LED projectors. Ideal for dark environments.
- **Enhanced Viewing Experience:** Supports HD 1080p with a 16:9 aspect ratio and ±15° vertical keystone adjustment for screen sizes from 30 to 176 inches.
- **Dual Fan Design:** Efficient cooling system extends bulb lifespan.
- **Integrated Speakers:** Provides audio output without external speakers.
- **Multiple Device Compatibility:** Connects to PS4, Xbox One, Xbox 360, Wii-U, PC, external speakers, U-disk, hard disk via HDMI, VGA, Audio port, and USB. MHL cord support for iPad and iPhone.

3. Setup Guide

3.1 Unpacking and Placement

1. Carefully remove the projector and all accessories from the packaging.
2. Place the projector on a stable, flat surface. Ensure adequate ventilation around the unit.
3. Position the projector at an appropriate distance from the projection surface (wall or screen) to achieve the desired screen size. Refer to the specifications for recommended throw distances.

3.2 Power Connection

1. Connect the power adapter to the projector's power input port.
2. Plug the power adapter into a standard electrical outlet (100-240V).

3.3 Connecting Devices

The projector supports various input sources:



Image: Rear view of the Wsky Portable Video Projector H2, highlighting its multiple input ports for connecting various devices.

- **HDMI:** Connect your laptop, gaming console (PS4, Xbox), TV stick, or other HDMI-enabled devices using an HDMI cable.
- **VGA:** Connect older computers or laptops using a VGA cable.

- **USB:** Insert a USB drive (U-disk) or hard disk to play media files directly.*Note: Ensure the USB is inserted after the projector is powered on for proper recognition.*
- **AV:** Use the AV cable to connect devices with AV output.
- **Audio Out (3.5mm):** Connect external speakers or headphones for enhanced audio.
- **MHL:** Use an MHL cord (not included) to connect compatible iPad and iPhone devices.

4. Operation

4.1 Powering On/Off

1. Press the power button on the projector or the remote control to turn the unit on.
2. To power off, press the power button again.

4.2 Input Source Selection

After powering on, use the 'Source' button on the projector or remote control to select the desired input (e.g., HDMI1, HDMI2, VGA, USB, AV).

4.3 Image Adjustment



Image: The Wsky Portable Video Projector H2, highlighting its integrated dual speakers for an immersive audio experience.

- **Focus:** Rotate the focus ring on the projector lens until the image appears sharp and clear.
- **Keystone Correction:** Use the keystone adjustment dial (or menu option) to correct trapezoidal distortion if the projector is not perfectly perpendicular to the screen. The projector supports ±15° vertical keystone adjustment.
- **Aspect Ratio:** Adjust the aspect ratio (16:9 or 4:3) via the menu settings to match your content.

4.4 Audio Control

Adjust the volume using the volume buttons on the projector or remote control. For external audio, connect speakers or headphones to the 3.5mm audio output port.

5. Maintenance

5.1 Cleaning the Lens

Use a soft, lint-free cloth or lens cleaning paper to gently wipe the projector lens. Avoid using abrasive cleaners or excessive force, which can scratch the lens.

5.2 Ventilation



Image: The Wsky Portable Video Projector H2, illustrating its dual fan cooling system designed to reduce noise and maintain optimal operating temperature.

Ensure that the projector's ventilation openings are not blocked. The dual fan cooling system requires clear airflow to prevent overheating and prolong the device's lifespan.

5.3 Storage

When not in use, store the projector in a dry, dust-free environment. If storing for an extended period, consider using the original packaging or a protective case.

6. Troubleshooting

If you encounter issues with your projector, please refer to the following common solutions:

- **No Picture:**

- Check if the power cable is securely connected and the projector is powered on.
- Verify that the correct input source is selected (e.g., HDMI1, USB).
- Ensure the connected device (laptop, console) is powered on and outputting a signal.

- **Blurry Image:**
  - Adjust the focus ring on the lens until the image is clear.
  - Use the keystone correction to fix any trapezoidal distortion.
  - Ensure the projection distance is within the recommended range.
- **No Sound:**
  - Increase the volume on both the projector and the connected source device.
  - Check if external speakers or headphones are properly connected to the audio output.
  - Ensure the audio output setting on your source device is correctly configured.
- **USB Drive Not Recognized:**
  - Make sure the USB drive is inserted after the projector has been powered on.
  - Check the file format compatibility.

7. Specifications

Feature	Detail
Brand	Wsky
Model Number	H2
Display Resolution	1920 x 1080 (1080p Supported)
Display Type	LCD
Connectivity Technology	HDMI, MHL, USB, VGA
Contrast Ratio	2000:1
Light Source Operating Life	50,000 hours
Maximum Image Size	185 inches
Minimum Image Size	30 inches
Item Weight	2.8 pounds
Voltage	100-240V

8. Warranty and Support

8.1 Manufacturer Warranty

The Wsky Portable Video Projector H2 comes with a**2-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use.

8.2 Customer Support

For any product or service issues, please contact Wsky customer service immediately. We are committed to providing an excellent experience for all buyers and will assist you in resolving any quality concerns.

9. Product Videos

Wsky Outdoor Movie Projector

▶ **Watch video online**

Wsky Outdoor Movie Projector

Video: An official Wsky video demonstrating the Wsky Portable Video Projector H2 in an outdoor movie setting, showcasing its capabilities for external use.

© 2023 Wsky. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BPZTZL7

More documents and user manuals: **https://manuals.plus/**