Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Anker SoundBuds Sport

Anker SoundBuds Sport Bluetooth Neckband Headphones User Manual

Model: SoundBuds Sport

Introduction

Thank you for choosing the Anker SoundBuds Sport Bluetooth Neckband Headphones. These headphones are designed to provide a comfortable and secure fit for active lifestyles, featuring high-quality audio, an IPX4 waterproof rating, and a built-in microphone for hands-free calls. This manual will guide you through the setup, operation, and maintenance of your SoundBuds Sport headphones to ensure optimal performance and longevity.

Package Contents

Please check that all items are present in your package:

- Anker SoundBuds Sport Bluetooth Neckband Headphones
- Micro USB Charging Cable
- EarTips (various sizes)
- WingTips (various sizes)
- Cable Clip
- Travel Pouch
- User Manual (this document)

Setup

1. Charging Your Headphones

Before first use, fully charge your SoundBuds Sport headphones.

1. Connect the Micro USB charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB wall charger (not included) or a computer's USB port.
3. The LED indicator will glow red during charging and turn blue when fully charged. A full charge typically takes approximately 1.5 hours.

Note: Do not use the headphones while charging.

2. Wearing Your Headphones

For optimal sound quality and comfort, select the appropriate EarTips and WingTips for your ears.

- Attach the chosen EarTips and WingTips securely to the earbuds.
- Place the neckband around your neck and insert the earbuds into your ears.
- Adjust the neckband and earbuds for a snug and comfortable fit.

3. Bluetooth Pairing

Pair your SoundBuds Sport with your Bluetooth-enabled device.

1. Ensure the headphones are turned off.
2. Press and hold the Multi-function button (usually the Anker logo or a central button) for approximately 3-5 seconds until the LED indicator flashes blue and red alternately. This indicates pairing mode.
3. Enable Bluetooth on your device (smartphone, tablet, etc.).
4. Search for "Anker SoundBuds Sport" in your device's Bluetooth list and select it.
5. Once connected, the LED indicator will flash blue slowly.

Note: The headphones will automatically attempt to reconnect to the last paired device when powered on. If reconnection fails, repeat the pairing steps.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the Multi-function button for 2 seconds. The LED will flash blue.
- **Power Off:** Press and hold the Multi-function button for 3 seconds. The LED will flash red and then turn off.

Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press and hold the Volume Up (+) button for 2 seconds.
- **Previous Track:** Press and hold the Volume Down (-) button for 2 seconds.
- **Volume Up:** Press the Volume Up (+) button.
- **Volume Down:** Press the Volume Down (-) button.

Call Functions

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Transfer Call (Headphones to Phone):** During a call, press and hold the Multi-function button for 2 seconds.
- **Activate Voice Assistant (Siri, Google Assistant):** Double-press the Multi-function button.

Maintenance

- **Cleaning:** Gently wipe the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the headphones in the provided travel pouch to protect them from dust and damage. Avoid storing in extreme temperatures.
- **Water Resistance (IPX4):** The SoundBuds Sport are IPX4 rated, meaning they are resistant to splashing water from any direction. They are suitable for workouts and light rain but should not be submerged in water or exposed to heavy downpours. Ensure the charging port cover is securely closed to maintain water resistance.
- **Battery Care:** To preserve battery life, charge the headphones at least once every 3 months if not used regularly.

Troubleshooting

Cannot Pair with Device

- Ensure the headphones are in pairing mode (LED flashing blue and red).
- Make sure Bluetooth is enabled on your device and it is within 1 meter of the headphones.
- Clear the Bluetooth pairing history on your device and try pairing again.
- Restart both your device and the headphones.

No Sound or Intermittent Sound

- Check the volume levels on both the headphones and your connected device.
- Ensure the headphones are fully charged.
- Move closer to your device to avoid interference or obstacles.
- Try disconnecting and reconnecting the Bluetooth connection.

Headphones Not Charging

- Verify that the charging cable is securely connected to both the headphones and the power source.
- Try using a different Micro USB cable or power adapter.
- Ensure the charging port is clean and free of debris.

Specifications

Model Name	SoundBuds Sport
Bluetooth Version	Bluetooth 5
Playtime	Up to 8 hours
Waterproof Rating	IPX4
Charging Time	Approx. 1.5 hours
Weight	52 Grams
Battery Type	1 Lithium Polymer battery (included)
Lithium Battery Energy Content	1.3 Watt Hours

Warranty and Customer Support

Anker products are covered by a limited warranty from the date of purchase. For detailed warranty information, please refer to the official Anker website or contact customer support.

If you encounter any issues or have questions regarding your Anker SoundBuds Sport headphones, please do not hesitate to contact Anker Customer Support. You can find contact information on the official Anker website:

www.anker.com/support

Please have your model name (SoundBuds Sport) and ASIN (B07BRGQK4B) ready when contacting support.

© 2026 Anker Innovations Limited. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BRGQK4B

More documents and user manuals: **https://manuals.plus/**