Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bushnell 368820

Bushnell Phantom Golf GPS User Manual

Model: 368820

1. Product Overview

The Bushnell Phantom Golf GPS is a compact and easy-to-use device designed to provide accurate golf course distances. It comes preloaded with over 36,000 courses in more than 30 countries, offering essential front, center, and back distances, along with up to four hazard distances per hole. Its integrated BITE magnetic mount allows for convenient attachment to metal surfaces, and Bluetooth connectivity enables wireless course updates via the Bushnell Golf App.

Key Features

- Bluetooth for wireless course updates.
- Long battery life, supporting up to 2 rounds before recharging.
- Preloaded with 36,000+ courses in 30+ countries.
- User-friendly interface.
- Displays up to 4 hazard distances per hole.
- Automatic course recognition.
- Automatic hole advancement.
- Integrated BITE magnetic mount for secure attachment.
- Includes a clip holder for attachment to a bag or belt.
- Access to the Bushnell Golf App with purchase.



Figure 1: Bushnell Phantom Golf GPS, displaying course and shot information.

2. Getting Started

2.1 What's in the Box

Upon opening your Bushnell Phantom Golf GPS package, you should find the following items:

- Bushnell Phantom Golf GPS unit
- Instruction Manual (this document)
- USB Charging Cable
- Clip Holder

2.2 Initial Charging

Before first use, fully charge your Phantom Golf GPS. Connect the provided USB charging cable to the device and a USB power source (e.g., computer, wall adapter). A full charge typically takes a few hours. The device is designed to provide approximately 10 hours of battery life, sufficient for up to two rounds of golf.

2.3 Powering On/Off

To power on the device, press and hold the **PWR** button located on the top right side of the unit until the screen illuminates. To power off, press and hold the **PWR** button again until the screen turns off.



Figure 2: Rear view of the Phantom GPS, highlighting button layout.

3. Operating Your Phantom GPS

3.1 Basic Navigation and Controls

The Phantom GPS features several buttons for navigation:

- **PWR**: Power On/Off.
- **MENU**: Access the main menu for settings and options.
- **SHOT**: Measure shot distance. Press once at your starting point, then walk to your ball. The distance will be displayed.
- **UP**/**DOWN**: Scroll through menu options or change settings.
- **SELECT**: Confirm a selection or enter a submenu.

3.2 Course Recognition and Hole Advance

Once powered on, the Phantom GPS will automatically search for nearby golf courses. Select your course from the list using the **UP/DOWN** and **SELECT** buttons. The device will automatically advance to the next hole as you progress through your round.

3.3 Viewing Distances

The main display provides clear, easy-to-read distances to the front, center, and back of the green. To view hazard distances, navigate through the display modes using the **MENU** button or as indicated on screen.



Figure 3: Display showing shot distance measurement.



Figure 4: Display showing various hazard distances.

3.4 Using the BITE Magnetic Mount

The integrated BITE magnetic mount allows you to securely attach your Phantom GPS to any metal surface, such as a golf cart frame or a club. Ensure the device is firmly attached before moving.

3.5 Bluetooth Connectivity and Bushnell Golf App

Pair your Phantom GPS with your smartphone via Bluetooth to utilize the Bushnell Golf App. The app allows for wireless course updates, access to additional course information, and other features. Refer to the Bushnell Golf App's in-app instructions for detailed pairing and usage information.

4. Care and Maintenance

4.1 Battery Management

To maximize battery life, fully charge the device before each use. If storing the device for an extended period, ensure it is charged to at least 50% and recharge every few months to prevent deep discharge.

4.2 Cleaning

Clean the device with a soft, damp cloth. Avoid using abrasive cleaners or solvents, as these can damage the casing or screen. Ensure the charging port is free of debris.

4.3 Storage

Store your Phantom GPS in a cool, dry place away from direct sunlight and extreme temperatures. Protect the screen from scratches when not in use.

5. Troubleshooting

5.1 No GPS Signal

- Ensure you are in an open area with a clear view of the sky.
- Wait a few minutes for the device to acquire satellites.
- Check if the course data is up to date via the Bushnell Golf App.

5.2 Device Not Powering On

- Ensure the device is fully charged. Connect it to a charger and wait for a few minutes before attempting to power on again.
- Try a different USB charging cable or power source.

5.3 Incorrect Distances

- Verify that the correct course is selected.
- Ensure the device has a strong GPS signal.
- Update course data using the Bushnell Golf App.

6. Technical Specifications

Feature	Specification
Brand	Bushnell
Model Name	Phantom
Model Number	368820
Screen Size	2 inches
Display Type	LCD
Connectivity Technology	Bluetooth
Supported Satellite Navigation System	GPS
Map Type	North America (Preloaded courses for 30+ countries)

Feature	Specification
Battery Life	Approximately 10 hours
Item Weight	4 ounces
Item Dimensions (L x W x H)	0.4" x 3.1" x 5.6"
Included Components	GPS unit, instructions, charger
UPC	029757003232

7. Warranty and Customer Support

7.1 Warranty Information

The Bushnell Phantom Golf GPS is covered by a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the warranty card included with your product or visit the official Bushnell website.

7.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact Bushnell Customer Service. You can find contact information and additional resources on the official Bushnell website: www.bushnellgolf.com.

© 2023 Bushnell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CHXDNKB

More documents and user manuals: **https://manuals.plus/**