Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter

PK Power AC/DC Adapter Instruction Manual for Panasonic SL-S120, SL-S138 CD Players

Model: AC/DC Adapter

1. Introduction

This manual provides essential information for the safe and effective use of your PK Power AC/DC Adapter. This adapter is designed to provide reliable power to compatible devices, specifically Panasonic SL-S120 and SL-S138 Anti-Shock Memory Mash XBS Portable CD Players.

Please read these instructions carefully before using the product and retain them for future reference.



Image 1.1: Side view of the PK Power AC/DC Adapter, showing the power prongs and the attached cord.



Image 1.2: Top view of the PK Power AC/DC Adapter, highlighting the compact design and cord connection.

2. Setup

1. **Unpack the Adapter:** Carefully remove the AC/DC adapter from its packaging.
2. **Identify the Device Port:** Locate the power input port on your Panasonic SL-S120 or SL-S138 portable CD player. This is typically a circular DC input jack.
3. **Connect the Adapter:** Insert the connector end of the adapter cord firmly into the power input port of your CD player. Ensure a snug fit.
4. **Plug into Power Outlet:** Insert the two-prong plug of the AC/DC adapter into a standard wall power outlet (100-240V AC, 50-60Hz).
5. **Verify Connection:** Once connected, your CD player should receive power. Refer to your CD player's manual for specific power indicator lights.

3. Operating Instructions

The PK Power AC/DC Adapter functions as a direct power source for your compatible portable CD player. Once properly connected to both the device and a power outlet, it will supply the necessary electrical current for operation.

- **Power On/Off:** Use the power button on your Panasonic CD player to turn the device on or off. The adapter continuously supplies power when plugged in.
- **Battery Bypass:** This adapter allows you to operate your CD player without relying on batteries, or to conserve battery life when a wall outlet is available.
- **Unplugging:** To disconnect power, first turn off your CD player, then unplug the adapter from the wall outlet, and finally disconnect it from the CD player.

4. Maintenance

Proper care and maintenance will extend the life of your AC/DC adapter.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the

exterior. Do not use liquid cleaners or solvents.

- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cord to prevent damage.
- **Cord Care:** Do not bend, twist, or pull the power cord excessively. Inspect the cord periodically for any signs of damage, fraying, or exposed wires. If damage is found, discontinue use immediately.
- **Avoid Moisture:** Keep the adapter away from water, high humidity, and wet environments.

5. Troubleshooting

If you encounter issues with your adapter, refer to the following common solutions:

Problem	Possible Cause	Solution
Device not powering on.	Adapter not properly plugged into wall outlet or device.	Ensure both ends of the adapter are securely connected. Try a different wall outlet.
Device powers on intermittently.	Loose connection or damaged cord.	Check for loose connections. Inspect the cord for damage. If damaged, discontinue use and replace.
Adapter feels unusually hot.	Overload or internal fault.	Unplug immediately. Ensure the adapter is used with compatible devices only. If overheating persists, discontinue use.
Device not compatible.	Incorrect adapter for the device.	Verify your device model against the compatibility list in this manual.

If the problem persists after attempting these solutions, please contact customer support.

6. Specifications

- **Input:** 100-240V AC, 50-60Hz
- **Protection Features:** OVP (Over Voltage Output Protection), OCP (Over Current Output Protection), SCP (Short Circuit Output Protection)
- **Certifications:** CE, FCC, RoHS
- **Connector Type:** Auxiliary (specific to compatible devices)
- **Color:** Black
- **Power Source:** Corded Electric
- **Main Power Connector Type:** 2 Pin (US standard)

7. Compatibility

This PK Power AC/DC Adapter is specifically designed and tested for compatibility with the following portable CD player models:

- Panasonic SL-S120 Anti-Shock Memory Mash XBS Portable CD Player
- Panasonic SL-S138 Anti-Shock Memory Mash XBS Portable CD Player

Using this adapter with incompatible devices may result in improper function or damage to the device or adapter.

8. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the adapter to rain, moisture, or extreme temperatures.
- Do not disassemble or modify the adapter. Refer all servicing to qualified personnel.
- Avoid dropping or subjecting the adapter to strong impacts.
- Keep out of reach of children.
- Ensure the adapter is plugged into a properly grounded and accessible wall outlet.
- Unplug the adapter during lightning storms or when unused for long periods.
- The adapter is equipped with OVP, OCP, and SCP protection features to safeguard against over-voltage, over-current, and short-circuit conditions.

9. Warranty and Support

Warranty: This product comes with a 1-year manufacturer's warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support: For any questions, technical assistance, or warranty inquiries, please contact PKPOWER customer service. Our friendly and reliable customer service team aims to respond within 24 hours.

For more information, you may visit thePKPOWER Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CVB7RKC

More documents and user manuals: **https://manuals.plus/**