Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Giochi Preziosi LLU58000

L.O.L. Surprise! Bling Series Doll Instruction Manual

Model: LLU58000

Introduction

Welcome to the exciting world of L.O.L. Surprise! Bling Series dolls. This manual provides instructions on how to unbox, play with, and care for your new collectible doll and its accessories. Each L.O.L. Surprise! Bling Series ball contains a unique doll with shiny finishes and several surprises.

Safety Information

- **Recommended Age:** This product is suitable for children aged 3 years and older.
- **Choking Hazard:** Contains small parts. Not for children under 3 years. Adult supervision is recommended during play.
- **Water Play:** If using water features, ensure play is conducted in an appropriate area to prevent water damage.

Setup and Unboxing

The L.O.L. Surprise! Bling Series doll offers an unforgettable unboxing experience with 7 layers of surprises. Follow these steps to reveal your new doll and its accessories:

1. **Locate the Zipper:** Find the zipper-like strip on the outer layer of the L.O.L. Surprise! ball.
2. **Peel Back Layers:** Carefully peel back each layer to reveal a new surprise. Each layer will contain a clue or an accessory.
3. **Discover Surprises:**
    - **Layer 1:** Secret Message Sticker
    - **Layer 2:** Collectible Stickers
    - **Layer 3:** Bottle
    - **Layer 4:** Shoes
    - **Layer 5:** Outfit
    - **Layer 6:** Accessory (e.g., glasses, headband)
    - **Layer 7:** L.O.L. Surprise! Bling Series Doll



Image: The L.O.L. Surprise! Bling Series ball, designed to be hung or displayed. This is the initial packaging.



Image: A hand peeling back a layer of the L.O.L. Surprise! Bling Series ball, revealing a diagram of the 7 surprises inside, including a secret message, stickers, bottle, shoes, outfit, accessory, and the doll.

Operating and Play

Once all surprises are revealed, you can begin playing with your L.O.L. Surprise! Bling Series doll:

- **Dress Your Doll:** Put on the outfit, shoes, and accessories you found.
- **Water Surprise:** Feed your doll water from its bottle or bathe it to discover a unique water surprise (e.g., crying, spitting, tinkling, or color change).

- **Use the Ball as a Stand:** The L.O.L. Surprise! ball transforms into a doll stand. You can display your doll in it or hang it from a backpack or purse.
- **Collect Them All:** There are 12 unique characters in the Bling Series to collect.



Image: A L.O.L. Surprise! Bling Series doll, featuring silver glitter details, standing inside the clear pink half of its surprise ball, which functions as a display stand.



Image: A L.O.L. Surprise! Bling Series doll with black and white hair, wearing a pink glitter outfit and large pink glitter sunglasses, standing next to a matching pink glitter bottle.



Image: A L.O.L. Surprise! Bling Series doll with blue glitter hair, wearing a blue bikini top and pink skirt, along with pink sunglasses, standing next to a blue glitter bottle.

Maintenance and Care

- **Cleaning:** Wipe dolls and accessories with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** If dolls get wet, allow them to air dry completely to prevent mold or mildew.
- **Storage:** Store dolls and accessories in a clean, dry place away from direct sunlight to preserve colors and materials.

Troubleshooting

- **Doll Not Changing Color (Water Surprise):** Ensure the water temperature is appropriate. Some dolls react to cold water, others to warm water. Experiment with different temperatures.
- **Accessories Not Fitting:** Gently try to attach accessories. If an accessory seems too tight, ensure it is oriented correctly. Do not force parts, as this may cause damage.
- **Missing Parts:** If you believe a part is missing, please refer to the "Warranty and Support" section to contact customer service.

Specifications

Feature	Detail
Brand Name	Giochi Preziosi
Model Number	LLU58000
Manufacturer Part Number	LLU55000
Manufacturer Minimum Age	3.0 Months
Item Type Name	Bling - Assortment, Surprise
Included Components	Doll to collect
Material Type	Silicone Vinyl Plastic
Item Weight	100 Grams
Item Dimensions (L x W x H)	3.9 x 3.9 x 4.09 inches
Operation Mode	Manual
Assembly Required	No

Warranty and Support

For any questions, concerns, or to report missing parts regarding your L.O.L. Surprise! Bling Series doll, please contact Giochi Preziosi customer service. Refer to the packaging or the official Giochi Preziosi website for the most up-to-date contact information and warranty details.
Online Support: Visit Giochi Preziosi Official Website

© 2024 Giochi Preziosi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DD3SCC8

More documents and user manuals: **https://manuals.plus/**