Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO MOTKF-002

TRESKO Top Case XL 24L User Manual

Model: MOTKF-002

1. Product Overview

The TRESKO XL 24-liter top case is designed to significantly increase the cargo volume of your scooter or motorcycle. It is suitable for carrying a motorcycle helmet or groceries, allowing you to transport up to 5 kg of payload comfortably and securely. The universal support plate for the quick-release system can be mounted on any luggage rack. The case can be quickly removed or reattached with a simple turn.
The top case features a durable, easy-care matte black plastic surface. For convenient transport off the vehicle, it is equipped with a practical carrying handle. All necessary mounting materials are included in the delivery.



Figure 1: TRESKO Top Case XL 24L in closed position, showing the lock and included keys.

2. Setup and Installation

2.1. Package Contents

- 1 x TRESKO XL Motorcycle Top Case
- 1 x Support Plate (universal)
- 2 x Keys
- Mounting Hardware (bolts, washers, brackets)



Figure 2: Included mounting hardware and the universal support plate.

2.2. Mounting the Support Plate

The universal support plate is designed to be mounted on any standard luggage rack. You will need a male key and a combination key for assembly (not included). Follow these steps:

1. Position the support plate on your vehicle's luggage rack.
2. Align the mounting brackets and secure the plate using the provided bolts and washers. Ensure all connections are tight and secure.
3. Verify that the plate is stable and does not wobble before proceeding.



Figure 3: The top case detached from its universal mounting plate, ready for installation.



Figure 4: The TRESKO Top Case securely mounted onto the support plate on a vehicle.

3. Operating Instructions

3.1. Attaching and Detaching the Top Case

The top case features a quick-release system for easy attachment and detachment from the support plate. To attach, align the case with the plate and press down until it clicks securely into place. To detach, ensure the case is unlocked, then operate the quick-release mechanism (usually a lever or button near the lock) and lift the case off the plate. **Important:** Access to the quick-release system is only available when the top case is open. Once the top case is closed and locked, it is protected against unauthorized removal without tools.

3.2. Locking and Unlocking

The top case comes with two keys to secure your belongings. Insert a key into the lock and turn to lock or unlock the

case. When locked, the contents are protected against theft, and the case cannot be removed from the mounting plate.

3.3. Opening and Closing the Lid

To open the lid, unlock the case and lift the lid upwards. The case is equipped with foldable limiters that prevent the lid from opening too far, protecting the hinges from overload, especially in windy conditions. To close, simply push the lid down until it latches securely. Then, lock it with the key.



Figure 5: The TRESKO Top Case XL 24L with its lid open, revealing the spacious interior.



Figure 6: The TRESKO Top Case XL 24L lid open, showing the internal limiter straps that prevent over-extension.

4. Maintenance

The TRESKO Top Case is made from easy-care matte black plastic. To maintain its appearance and functionality:

- Clean the exterior with a damp cloth and mild soap. Avoid abrasive cleaners or solvents.
- Ensure the lock mechanism is free of dirt and debris. Lubricate with a small amount of graphite powder if it becomes stiff.
- Periodically check all mounting bolts and connections for tightness. Re-tighten if necessary to ensure secure attachment.
- The contents of the motorcycle case are protected against splashes during rainy days. However, avoid submerging the case in water.

5. Troubleshooting

- **Case not detaching easily:** Ensure the case is unlocked and the quick-release mechanism is fully engaged. Do not force it.
- **Lid opening too far:** The foldable limiters are designed to prevent this. If the lid opens excessively, inspect the limiter straps for damage or detachment.
- **Wobbling on luggage rack:** Check all mounting hardware for tightness. Ensure the support plate is securely fastened to the luggage rack and the top case is properly clicked into the quick-release system.

6. Specifications

Feature	Detail
Brand	TRESKO
Model	Top Case
Model Number	MOTKF-002
Capacity	24 Liters
Max Load	Approx. 5 kg
Item Weight	1 Kilogram
Material	Plastic
Color	Black
External Dimensions (L x W x H)	Approx. 37 x 33 x 28 cm
Internal Dimensions (L x W x H)	Approx. 36 x 33 x 27.5 cm
Support Plate Dimensions (L x W x H)	Approx. 34.5 x 31.5 x 5.5 cm
Reflector Size	Approx. 32 cm (length) x 9.5 cm (widest point)
Special Features	Waterproof, Reflective, Quick-release system, Carrying handle, Foldable limiters
Vehicle Service Type	Scooter, Motorcycle, Moped, Quad, ATV

7. Warranty and Support

For warranty information or technical support, please refer to the purchase documentation or contact the seller directly. Keep your proof of purchase for any warranty claims.
Seller: DWD-Company GmbH & Co. KG

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07DGG5L2D

More documents and user manuals: **https://manuals.plus/**