Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic ER-GN70-K

Panasonic ER-GN70-K Nose Hair Trimmer Instruction Manual

Model: ER-GN70-K

1. Product Overview

The Panasonic ER-GN70-K Nose Hair Trimmer is engineered for efficient and comfortable grooming of nose and ear hair. This device incorporates a powerful motor, precision dual-edge blades for effective cutting, and advanced cleaning functionalities including hair scrap suction and full washability, ensuring a hygienic and user-friendly experience.



Image 1: Panasonic ER-GN70-K Nose Hair Trimmer showcasing its waterproof design, powerful motor, hair scrap suction, smart cleaning, and dual-edge blades.

2. Key Features

- **Powerful Motor:** Equipped with a motor providing approximately 1.2 times the torque compared to previous models, ensuring powerful and smooth cutting of even thick or coarse hair.



Image 2: Illustration showing the powerful motor with approximately 1.2 times the torque for efficient hair cutting.

- **Dual-Edge Blades:** The innovative dual-edge blade system allows for efficient trimming from both the top and sides, ensuring comprehensive hair removal without direct skin contact, minimizing irritation.



Image 3: Diagram illustrating the dual-edge blade design, which cuts hair from both the top and sides for thorough trimming without skin contact.

- **Hair Scrap Suction:** An integrated suction mechanism effectively collects cut hair fragments, preventing them from scattering and making cleanup easier.



Image 4: Image demonstrating the hair scrap suction feature, which draws cut hairs into the unit for cleaner operation.

- **Smart Cleaning (Washable):** The trimmer is designed for easy cleaning. It can be rinsed directly under running water without needing to remove the blade, and the entire unit can be disassembled for more thorough washing.



Image 5: Visual guide showing how the trimmer can be easily rinsed under water for smart cleaning, without needing to remove the blade.

- **Waterproof Design:** Conforms to IPX7 waterproofing standards, allowing for safe and convenient wet cleaning.

3. Setup

Battery Installation

The Panasonic ER-GN70-K operates on two AAA batteries. Follow these steps for proper installation:

1. Twist the bottom cap of the trimmer counter-clockwise to open the battery compartment.
2. Insert two fresh AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
3. Replace the bottom cap by twisting it clockwise until it is securely fastened.



Image 6: The Panasonic ER-GN70-K Nose Hair Trimmer with its protective cap removed, ready for use or battery access.

4. Operating Instructions

Turning On/Off

To activate the trimmer, slide the power switch, located on the front of the unit, to the **"ON"** position. To turn off the device, slide the switch back to the **"OFF"** position.

Trimming Nose Hair

1. Ensure the trimmer is clean and the batteries are properly installed.
2. Gently insert the trimmer tip into the nostril. Avoid inserting too deeply to prevent discomfort or injury.
3. Move the trimmer slowly in a circular motion to effectively cut unwanted hair.
4. Repeat for the other nostril as needed.

Trimming Ear Hair

1. Carefully guide the trimmer around the outer ear and the opening of the ear canal to remove visible hair.
2. Do not insert the trimmer deeply into the ear canal.
3. Use caution and a mirror if necessary to ensure precise trimming.

General Usage Tips

- For optimal results, use the trimmer on dry hair.
- Do not press the trimmer firmly against the skin, as this may cause irritation.
- Clean the trimmer after each use to maintain hygiene and performance.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your trimmer.

Quick Rinse Cleaning (Smart Cleaning)

1. After each use, slide the power switch to the **"ON"** position.
2. Hold the trimmer head directly under running water. The unique "Smart Cleaning" system will flush out hair debris from the blades.
3. Continue rinsing for a few seconds until all visible hair fragments are removed.

Thorough Cleaning

1. Ensure the trimmer is turned **"OFF"**.
2. Twist and remove the outer blade assembly from the main body.
3. Rinse both the outer and inner blades thoroughly under running water. Use a small brush (if provided) to dislodge stubborn hair or debris.
4. The main body of the trimmer can also be rinsed under water due to its waterproof design.

Drying and Storage

- After cleaning, gently shake off any excess water from all parts.
- Allow all components to air dry completely before reassembling the trimmer.
- Store the trimmer in a cool, dry place, away from direct sunlight and high humidity.
- Periodically apply a small drop of clipper oil (not included) to the blades to maintain optimal performance and longevity.

6. Troubleshooting

If you encounter any issues with your Panasonic ER-GN70-K, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Batteries incorrectly inserted or depleted.	Check battery polarity and replace with new AAA batteries. Ensure battery compartment cap is securely closed.
Poor cutting performance or pulling hair.	Blades clogged with hair/debris or dull. Low battery power.	Perform a thorough cleaning of the blades. Replace batteries. If issues persist, contact customer support for blade replacement.
Excessive noise or vibration.	Blade assembly not correctly attached or foreign object present.	Ensure the blade assembly is securely twisted onto the main body. Check for and remove any foreign objects.

7. Specifications

Model: ER-GN70-K

Brand: Panasonic

Power Source: Battery Powered (2 x AAA batteries)

Features: Cordless, Washable, Dual-Edge Blades, Hair Scrap Suction, IPX7 Waterproof

Product Dimensions: Approximately 1.81 x 3.54 x 7.87 inches (4.6 x 9.0 x 20.0 cm)

Item Weight: Approximately 0.11 Kilograms (3.88 ounces)

Blade Material: Stainless Steel

Color: Black

8. Safety Information

- This device is intended for trimming nose and ear hair only. **Do not insert into ears or other body parts beyond the intended use.**
- Keep out of reach of children.
- Do not attempt to disassemble or repair the unit yourself, as this may void the warranty and pose a safety risk.
- Do not use if the blades are damaged, as this may cause injury.
- Always ensure the trimmer is clean and dry before storage.
- Do not use the trimmer in a shower or bath if the battery compartment is not fully sealed.

9. Warranty and Support

Warranty information for the Panasonic ER-GN70-K Nose Hair Trimmer is typically included with the product packaging. Please refer to the documentation provided at the time of purchase for specific warranty terms and conditions, including coverage duration and claim procedures.

For technical assistance, replacement parts, or service inquiries, please contact Panasonic customer support through their official website or the contact information provided in your product documentation. Always provide your model number (ER-GN70-K) when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FFGYWJ6

More documents and user manuals: **https://manuals.plus/**