Braun KG7070

Braun KG7070 Burr Grinder Instruction Manual

Model: KG7070

1. Introduction

The Braun KG7070 Burr Grinder is designed to provide a consistent and precise grind for various coffee brewing methods. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new coffee grinder.

Important Safety Information

- Read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Always unplug the grinder from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils away from moving blades during operation to prevent injury.
- Ensure all parts are correctly assembled before operating the grinder.
- This appliance is for household use only.

2. Product Components

Familiarize yourself with the parts of your Braun KG7070 Burr Grinder:

- **Bean Hopper:** Holds whole coffee beans.
- **Upper Burr Grinding Wheel:** Removable for cleaning.
- **Grind Setting Selector:** Adjusts the fineness of the grind.
- **Start/Stop Button:** Initiates and halts the grinding process.
- **Cup Selector:** Determines the quantity of coffee to be ground.
- **Grounds Container:** Collects the ground coffee.
- **Cleaning Brush:** For maintenance of the burrs and other parts.



Image: Exploded view showing the individual components of the Braun KG7070 Burr Grinder, including the bean hopper, burr grinding wheel, main unit, grounds container, and cleaning brush.

3. Setup

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present.
2. **Initial Cleaning:** Before first use, clean the bean hopper, grounds container, and upper burr grinding wheel with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.
3. **Assembly:** Place the upper burr grinding wheel back into position. Ensure the bean hopper and grounds container are securely in place.
4. **Placement:** Position the grinder on a stable, flat, and dry surface. Ensure the power cord is not obstructed and is within reach of an electrical outlet.



Image: The Braun KG7070 Burr Grinder fully assembled and ready for use, showcasing its stainless steel finish and clear bean hopper and grounds container.

4. Operating Instructions

1. **Fill the Bean Hopper:** Open the lid of the bean hopper and pour in whole coffee beans. Do not fill past the 'MAX' line. The hopper holds up to 16 ounces of whole beans.
2. **Select Grind Setting:** Rotate the grind setting selector dial to choose your desired fineness. The grinder offers 9 main settings and 6 intermediate options, allowing customization for drip coffee, espresso, French press, or other craft coffee styles.
3. **Select Cup Quantity:** Rotate the cup selector dial to choose the number of cups you wish to grind (from 2 to 12 cups). This ensures you grind the precise amount needed.
4. **Start Grinding:** Press the 'Start/Stop' button to begin the grinding process. The grinder will automatically stop once the selected quantity has been ground.
5. **Remove Grounds:** Once grinding is complete, carefully remove the grounds container. Pour the freshly ground coffee into your coffee maker.



Image: The Braun KG7070 Burr Grinder in operation, showing whole beans in the upper hopper and ground coffee collected in the lower container.



Image: A detailed view of the grinder's control panel, highlighting the grind setting dial, cup selector, and the illuminated start/stop

button.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your grinder. The easy-clean design features rounded edges, an antistatic coating, and a removable top burr.

1. **Unplug:** Always unplug the grinder before cleaning.
2. **Remove Grounds Container:** Empty any remaining ground coffee.
3. **Remove Bean Hopper and Upper Burr:** Carefully remove the bean hopper and then the upper burr grinding wheel.
4. **Clean Burrs:** Use the provided cleaning brush to remove any coffee particles from the upper and lower burr grinding wheels.
5. **Clean Grounds Container and Hopper:** Wash the grounds container and bean hopper with warm, soapy water. Rinse thoroughly and dry completely before reassembling.
6. **Wipe Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
7. **Reassemble:** Ensure all parts are dry and correctly reassembled before plugging in the grinder.





Image: The specially designed cleaning brush included with the Braun KG7070 Burr Grinder, used for removing coffee residue from the burrs and other components.

6. Troubleshooting

Problem	Possible Cause	Solution
Grinder does not start.	Not plugged in; bean hopper or grounds container not correctly seated; overheat protection activated.	Ensure the grinder is plugged in. Check that the bean hopper and grounds container are securely in place. If the unit is hot, allow it to cool down before restarting.
Inconsistent grind.	Burrs are dirty or clogged.	Clean the burr grinding wheels thoroughly using the provided brush.
Ground coffee static cling.	Natural static electricity with dry coffee grounds and plastic container.	The grounds container is made with antistatic materials to minimize this. Tap the container gently before opening to settle grounds. Use the cleaning brush to remove any clinging particles.
Grinder stops unexpectedly.	Overheat protection activated.	Allow the grinder to cool down for approximately 30 minutes before attempting to use it again.

7. Specifications

- **Model:** KG7070
- **Brand:** Braun
- **Color:** Stainless Steel
- **Product Dimensions:** 7.4"L x 5.2"W x 10.6"H
- **Item Weight:** 3.4 pounds
- **Voltage:** 116.67 Volts
- **Hopper Capacity:** 16 oz (whole beans)
- **Grind Settings:** 9 main settings + 6 intermediate options



Image: The Braun KG7070 Burr Grinder with its key dimensions (length, width, height) clearly labeled for reference.

8. Warranty and Support

Braun products are manufactured to the highest quality standards. For detailed warranty information, please refer to the

warranty card included with your product or visit the official Braun website. For customer support, service, or replacement parts, please contact Braun customer service through their official channels.

Manufacturer: Braun

Date First Available: August 10, 2018

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question