Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-M08

Joyroom Mini Mega Bass Bluetooth Speaker User Manual

Model: JR-M08

Introduction

This user manual provides detailed instructions for the operation and maintenance of your Joyroom Mini Mega Bass Aluminum Alloy Bluetooth Speaker (Model JR-M08). Please read this manual thoroughly before using the product to ensure proper function and longevity.

Product Overview



Figure 1: Front view of the Joyroom Mini Mega Bass Bluetooth Speaker, showcasing its compact, cylindrical design with a top speaker grille and metallic finish.

The Joyroom Mini Mega Bass Bluetooth Speaker is a compact, portable audio device designed for high-quality sound on the go. Featuring an aluminum alloy body, it offers robust construction and enhanced bass performance. It connects wirelessly via Bluetooth to smartphones and other compatible devices, and also supports audio playback via MicroSD card and charging via USB.

Key Features:

- Compact and portable design.
- Aluminum alloy construction for durability.
- Mega Bass sound output.
- Wireless Bluetooth connectivity.
- MicroSD card slot for direct audio playback.
- Built-in rechargeable battery.

Controls and Ports



Figure 2: Side view of the speaker, highlighting the Micro USB charging port and a MicroSD card slot for direct audio playback.

Familiarize yourself with the various controls and ports on your speaker:

- **Power Button:** Typically located on the bottom or side. Press and hold to turn on/off.
- **Micro USB Port:** Used for charging the speaker's internal battery.
- **MicroSD Card Slot:** Allows for direct playback of audio files from a MicroSD card.
- **LED Indicator:** Provides status information (e.g., charging, Bluetooth pairing, connected).

Note: Specific button functions (e.g., volume, play/pause) are often integrated into a single multi-function button or controlled via the connected device.

Setup and First Use

Charging the Speaker:

1. Connect the supplied USB charging cable to the Micro USB port on the speaker.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will typically illuminate red during charging and turn off or change color when fully charged.
4. Allow approximately 2-3 hours for a full charge before first use.

Bluetooth Pairing:



Figure 3: The speaker emitting a blue light from its base, indicating an active Bluetooth connection with a nearby smartphone.

1. Ensure the speaker is fully charged.
2. Press and hold the power button to turn on the speaker. The LED indicator will flash, indicating it is in pairing mode.
3. On your smartphone or Bluetooth-enabled device, navigate to the Bluetooth settings.
4. Search for available devices. The speaker will appear as "JR-M08" or "Joyroom Speaker".
5. Select the speaker from the list to pair. Once successfully paired, the LED indicator will typically stop flashing and remain solid blue, and you may hear an audible confirmation.
6. You can now play audio from your device through the speaker.

Operating the Speaker

Playing Audio via Bluetooth:



Figure 4: The Joyroom speaker positioned near a laptop and smartphone, demonstrating its use as an external audio output device for various media.

Once paired, simply start playing music or any audio content on your connected device. The sound will automatically be routed to the Joyroom speaker. Adjust volume directly from your connected device.

Playing Audio via MicroSD Card:

1. Insert a MicroSD card containing audio files (e.g., MP3) into the MicroSD card slot on the speaker.
2. The speaker should automatically detect the card and begin playing the first track.
3. *Note: Specific controls for track skipping or play/pause may vary and might be controlled via the speaker's multi-function button if available, or it might cycle through tracks automatically. Refer to product packaging for detailed button functions.*

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Exposure:** This speaker is not waterproof. Avoid exposure to water or high humidity.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is low or depleted.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; device Bluetooth is off; too far from speaker.	Ensure speaker is in pairing mode (flashing LED). Turn on Bluetooth on your device. Move device closer to speaker (within 10 meters). Forget previous pairings on your device and try again.
No sound from speaker.	Volume too low; speaker not connected; incorrect audio source.	Increase volume on both speaker and connected device. Ensure speaker is successfully paired. Check if audio is playing from MicroSD if inserted.
Poor sound quality.	Device too far; interference; low battery.	Move device closer. Avoid obstacles. Charge speaker.

Specifications

Feature	Detail
Model Number	JR-M08
Brand	Joyroom
Connectivity Technology	Bluetooth, USB
Speaker Type	Bluetooth Speakers
Power Source	Battery
Nominal Output / Max Output	5 - 10 Watt

Feature	Detail
Approximate Dimensions (W x D x H)	8.7 cm x 8.8 cm x 4.8 cm
Product Weight	0.5 kg
Material	Aluminum Alloy

Warranty and Support

Joyroom products are manufactured to high quality standards. For warranty information and technical support, please refer to the warranty card included with your purchase or visit the official Joyroom website. Keep your purchase receipt as proof of purchase for warranty claims.
For further assistance, you may contact Joyroom customer service through their official channels.

© 2024 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GBRM45Y

More documents and user manuals: **https://manuals.plus/**