Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AIDITIYMI AA59-00784A

AIDITIYMI AA59-00784A Replacement Remote Control User Manual

FOR SAMSUNG LED TELEVISIONS

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your AIDITIYMI AA59-00784A replacement remote control. This remote is designed to function as a direct replacement for various Samsung LED TV models, including those originally using remote models AA59-00784C, AA59-0784B, and BN59-01043A. No programming or pairing is required for its use; simply install batteries and begin operation.

Setup

1. Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image: Back of the remote control with the battery cover removed, illustrating the correct orientation for AAA battery insertion.

2. Initial Use

Once batteries are installed, the remote control is ready for immediate use with compatible Samsung LED TVs. No additional programming or pairing steps are required.

Operating Instructions

Point the remote control directly at your Samsung LED TV's infrared receiver. Ensure there are no obstructions between the remote and the TV.



Image: Front view of the remote control, displaying the layout of all buttons.

Button Functions Overview

Button	Function
POWER (TV)	Turns the TV on or off.
SOURCE	Selects the input source (e.g., HDMI, AV).
STB POWER	Turns the Set-Top Box on or off.
STB MENU	Accesses the Set-Top Box menu.

Button	Function
STB GUIDE	Displays the Set-Top Box program guide.
Number Buttons (0-9)	Direct channel selection.
PRE-CH	Returns to the previous channel.
VOL +/-	Adjusts the volume level.
MUTE	Mutes or unmutes the TV sound.
CH +/-	Changes the TV channel.
CH LIST	Displays the channel list.
MENU	Accesses the TV's main menu.
GUIDE	Displays the TV program guide.
TOOLS	Accesses quick settings or tools menu.
INFO	Displays information about the current program.
Directional Pad (Up, Down, Left, Right)	Navigates through menus and options.
ENTER (Center Button)	Confirms selections.
RETURN	Returns to the previous screen or menu.
EXIT	Exits the current menu or application.
Colored Buttons (A, B, C, D)	Context-sensitive functions, often for interactive services or specific menu options.
SEARCH	Initiates a search function.
STATUS	Displays TV status information.
MORE	Accesses additional functions or options.
E-MANUAL	Accesses the TV's electronic manual.
RECOMMEND	Accesses recommended content.
CC (Closed Caption)	Toggles closed captions on or off.
Playback Controls (Rewind, Play/Pause, Fast Forward, Stop)	Controls media playback.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage. Store the remote in a cool, dry place away from direct sunlight and extreme

temperatures.

- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are installed correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective operating range (up to 32 feet) and pointing the remote directly at the TV.
- **Some buttons not working:**
  - This remote is a replacement and may not support all advanced functions of certain Smart TVs or specific external devices. Verify if the button function is standard for a basic TV remote.
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris.
- **TV responds intermittently:**
  - Batteries may be low; replace them.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the TV's IR receiver.

Specifications

Feature	Detail
Brand	AIDITIYMI
Model Name	AA59-00784A
Model Number	AIDITIYMI-AA59-00784A-ADSN01
Connectivity Technology	Infrared (IR)
Compatible Devices	Samsung LED Televisions
Battery Type	AAA
Number of Batteries Required	2 (AAA)
Button Quantity	52
Maximum Range	32 feet (approx. 10 meters)
Item Weight	3 ounces (approx. 85 grams)
Color	Black
Special Feature	Ergonomic design

Compatible Samsung LED TV Models

This remote control is compatible with a wide range of Samsung LED TV models, including but not limited to:

- UN32F5500
- UN32F5500AF
- UN32F5500AFXZA
- UN32F6300
- UN32F6300AFXZA
- UN32F6350A
- UN32F6350AF
- UN32F6350AFXZA
- UN40F5500
- UN40F5500AFXZA
- UN40F6300
- UN40F6300AFXZA
- UN40F6350A
- UN40F6350AF
- UN40F6350AFXZA
- UN46F5500
- UN46F5500AFXZA
- UN46F6300
- UN46F6300AFXZA
- UN46F6350A
- UN46F6350AF
- UN46F6350AFXZA
- UN50F5500
- UN50F550AF
- UN50F5500AFXZA
- UN50F6300
- UN50F6300AFXZA
- UN50F6350A
- UN50F6350AF
- UN50F6350AFXZA
- UN55F6300
- UN55F6300AFXZA
- UN55F6350A
- UN55F6350AF
- UN55F6350AFXZA
- UN60F6300
- UN60F6300AFXZA
- UN60F6350A
- UN60F6350AF
- UN60F6350AFXZA
- UN65F6300
- UN65F6300AFXZA
- UN65F6350A

- UN65F6350AF
- UN65F6350AFXZA
- UN65F6300AF
- UN60F6300AF
- UN55F6300AF
- UN50F6300AF
- UN46F6300AF
- UN40F6300AF
- UN32F6300AF
- UN46F5500AF
- UN40F5500AF

Warranty Information

This AIDITIYMI remote control comes with a **1-Year Warranty** from the manufacturer. Please retain your purchase receipt for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

Support

For any questions or assistance regarding your AIDITIYMI AA59-00784A remote control, please contact the seller or manufacturer directly through the platform where the purchase was made. They will be able to provide further support and resolve any issues you may encounter.

© 2023 AIDITIYMI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GRVWNZH

More documents and user manuals: **https://manuals.plus/**