Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HANGSUN MG460

HANGSUN Handheld Neck Back Massager MG460 User Manual

Model: MG460 | Brand: HANGSUN

Introduction

Thank you for choosing the HANGSUN Handheld Neck Back Massager MG460. This manual provides essential information for the safe and effective use of your new massager. Please read it thoroughly before operation and retain it for future reference.

Important Safety Information

To reduce the risk of electric shock, burns, fire, or injury, always follow these basic safety precautions:

- Always unplug the massager before use.
- Do not use the massager while sleeping or in the bath.
- Keep the massager away from water.
- Do not use the massager on broken skin or areas with inflammation.
- Consult a doctor before use if you have any health conditions or are pregnant.
- Always follow the user instructions for safe and effective use.

Product Features

The HANGSUN MG460 massager is designed for deep tissue percussion massage, offering versatile relief for various body parts. Key features include:

- **Powerful Motor:** Delivers up to 3500 pulses per minute for deep, soothing massage.
- **Dual Head Percussion:** More effective for targeted deep massage and muscle pain relief compared to single-head massagers.
- **Wide Range Variable Speed Control:** Multiple speed settings to customize your massage experience.
- **Interchangeable Massage Nodes:** Includes 3 sets of nodes for varied massage sensations.
- **Ergonomic Design:** Comfortable handle for easy grip and a 98-inch extra-long power cord for extended reach.



Figure 1: Key features of the HANGSUN MG460 massager.

Setup

Before first use, ensure all packaging materials are removed. The massager operates via a corded electric connection. No assembly is required for the main unit, but massage nodes are interchangeable.

1. **Unpack:** Carefully remove the massager and all accessories from the packaging.
2. **Attach Massage Nodes:** Select the desired massage node set. Align the nodes with the dual percussion heads and gently push them into place until secure. To change, pull the nodes off and replace with another set.
3. **Connect to Power:** Plug the 98-inch extra-long power cord into a standard electrical outlet.



Figure 2: HANGSUN MG460 massager with interchangeable nodes.



Figure 3: Different types of massage nodes for customized experience.

Operating Instructions

The massager is designed for ease of use with intuitive controls.

1. **Power On/Off:** Locate the ON/OFF button on the handle. Press it to turn the massager on or off.
2. **Adjust Speed:** Use the speed control button (often a slider or +/- buttons) to select your desired intensity. The massager offers multiple speeds, up to 3500 pulses per minute.
3. **Apply to Body:** Gently place the massage heads on the desired body area. The ergonomic handle allows for easy reach to the neck, shoulders, back, legs, and feet. Move the massager slowly over the muscles.
4. **Recommended Usage:** Use for short periods on each area, typically 10-15 minutes, to avoid over-stimulation.



Figure 4: Massager controls and dimensions.



Figure 5: Example of using the massager on the neck and shoulder.



Figure 6: Example of using the massager on the leg.

▶ **Watch video online**
Hangsun Back Massager MG400 Electric Double Head

Video 1: Demonstration of the HANGSUN MG460 massager's features and usage.

Maintenance

Proper maintenance ensures the longevity and performance of your massager.

- **Cleaning:** Always unplug the massager before cleaning. Wipe the unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** Store the massager in a cool, dry place, away from direct sunlight and out of reach of children. Avoid wrapping the power cord tightly around the unit.

Troubleshooting

If you encounter any issues with your massager, refer to the following common solutions:

- **Massager not turning on:** Ensure the power cord is securely plugged into both the massager and a working electrical outlet.
- **Weak massage intensity:** Check the speed setting and adjust it to a higher level if needed. Ensure the massage nodes are properly attached.
- **Unusual noise:** Discontinue use immediately and check for any obstructions or damage to the massage heads. If the issue persists, contact customer support.

Specifications

Model Number	MG460-US
Brand	HANGSUN
Power Source	Corded Electric
Material	Plastic
Product Dimensions	6.3 x 17.72 x 6.89 inches
Item Weight	3.22 Pounds
Use For	Back, Leg, Shoulder, Whole Body

Warranty and Support

For information regarding product warranty, returns, or customer support, please refer to the documentation included with your purchase or contact HANGSUN customer service directly. Protection plans may be available for purchase separately.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GWTF4JT

More documents and user manuals: **https://manuals.plus/**