Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun SI3041GR

Braun TexStyle 3 SI3041GR Steam Iron User Manual

Model: SI3041GR

Introduction

Welcome to your new Braun TexStyle 3 SI3041GR steam iron. This manual provides essential information for safe and effective use, maintenance, and troubleshooting to help you achieve excellent ironing results.

Important Safety Instructions

- Always unplug the iron from the power outlet before filling with water, emptying the water tank, or cleaning.
- Do not leave the iron unattended while it is switched on or connected to the mains.
- Keep the iron and its power cord out of reach of children and persons with reduced physical, sensory, or mental capabilities.
- Do not immerse the iron in water or any other liquid.
- Use the iron only for its intended purpose, which is ironing fabrics.
- Ensure the voltage indicated on the iron's rating plate matches your local mains voltage before connecting.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Place the iron on a stable, heat-resistant surface when not in use.

Product Overview

Familiarize yourself with the components of your Braun TexStyle 3 SI3041GR steam iron.



A full view of the Braun TexStyle 3 SI3041GR steam iron, showcasing its turquoise and white design, ergonomic handle, and the SuperCeramic soleplate.



A close-up view of the iron's control panel, including the steam buttons, spray button, self-clean button, and the temperature dial.

1. **Water Inlet:** For filling the water tank.
2. **Spray Nozzle:** For moistening fabrics.
3. **Steam Buttons:** For continuous steam and steam shot.
4. **Self-Clean Button:** For descaling the iron.
5. **Temperature Dial:** To select the desired heat setting.
6. **Water Tank (270ml):** Transparent tank for water.
7. **FreeGlide 3D SuperCeramic Soleplate:** High-quality ceramic soleplate for smooth gliding.
8. **Precision Tip:** For reaching difficult areas.
9. **Power Cord:** With flexible cord protector.

Setup and First Use

1. Filling the Water Tank

Ensure the iron is unplugged. Open the water inlet cover and fill the 270ml water tank with tap water up to the 'MAX' mark. For areas with very hard water, a mixture of 50% tap water and 50% distilled water is recommended. Do not use perfumed water, water from tumble dryers, or other additives, as these can damage the iron or stain fabrics.

2. Plugging In

Plug the iron into a suitable grounded mains socket. The indicator light will illuminate, signaling that the iron is receiving power.

3. Initial Heating

Set the temperature dial to the maximum setting. Allow the iron to heat up for approximately 35 seconds until the indicator light turns off. This indicates that the iron has reached the desired temperature.

4. First Use (Steam Ironing)

During the first use, a slight odor or smoke may occur. This is normal and will disappear after a short period. Iron an old piece of fabric to ensure no residue is left on the soleplate before ironing your garments.

Operating Instructions

1. Temperature Settings

Rotate the temperature dial to select the appropriate heat setting for your fabric type. Always refer to the garment's care label for specific guidance. It is recommended to start with lower temperatures for delicate fabrics and increase as needed.

- **Low Temperature:** Synthetics, Silk
- **Medium Temperature:** Wool
- **High Temperature:** Cotton, Linen

2. Steam Functions

The TexStyle 3 SI3041GR offers various steam options for effective wrinkle removal.

Continuous Steam (45 g/min)

For continuous steam, ensure the temperature dial is set within the steam zone (usually indicated by a steam symbol on the dial). The iron will automatically produce a steady flow of steam when hot enough.

Shot of Steam (150 g/min)

Press the steam shot button (located on the handle) for an extra burst of steam to tackle stubborn creases. Wait a few seconds between shots to allow the steam chamber to refill for optimal performance.

Vertical Steam

Hold the iron vertically and press the steam shot button to remove wrinkles from hanging garments, curtains, or drapes. Ensure the iron is at a high temperature setting for optimal vertical steam performance.

3. FreeGlide 3D SuperCeramic Soleplate





A detailed view of the FreeGlide 3D SuperCeramic soleplate, highlighting its curved design and steam vents for smooth gliding in all directions.

The unique FreeGlide 3D SuperCeramic soleplate features a curved design that allows for effortless gliding over buttons, pockets, and zippers in all directions, including backwards. Its high-quality ceramic coating ensures durability, even heat distribution, and scratch resistance.

4. Precision Tip

The precision tip design allows for easy access to difficult areas like collars, cuffs, and around buttons, ensuring thorough and precise ironing results.

Care and Maintenance

1. Cleaning the Soleplate

After each use, allow the iron to cool completely. Wipe the soleplate with a damp cloth to remove any residue or starch buildup. Do not use abrasive cleaners, metal scouring pads, or harsh chemicals, as these can damage the soleplate's coating.

2. Self-Clean Function

To maintain optimal steam performance and prevent limescale buildup, use the self-clean function regularly (e.g., once a month, or more frequently in areas with very hard water).

1. Fill the water tank to the 'MAX' level.
2. Set the temperature dial to the maximum setting.
3. Plug in the iron and wait for the indicator light to turn off, signaling it has reached maximum temperature.
4. Unplug the iron from the power outlet.
5. Hold the iron horizontally over a sink.
6. Press and hold the self-clean button. Hot water and steam will be expelled from the soleplate, flushing out impurities and limescale.
7. Gently shake the iron back and forth until the water tank is empty.
8. Plug the iron back in and let it heat up again to dry the soleplate.
9. Once cooled, unplug and store the iron.

3. Storage

Always store the iron upright on its heel rest, with the water tank empty and the power cord neatly wrapped, once it has completely cooled down.

Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet faulty; temperature dial set to minimum.	Check power connection; try another outlet; set temperature to desired level.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam vents blocked; limescale buildup.	Fill water tank; increase temperature to steam zone; perform self-clean; clean soleplate.
Water drips from soleplate.	Temperature too low for steam; iron tilted too much; water tank overfilled.	Increase temperature to steam zone; keep iron horizontal during steam use; do not overfill water tank.
White flakes coming from soleplate.	Limescale buildup.	Perform self-clean function. Use a mixture of 50% tap water and 50% distilled water in hard water areas.

Technical Specifications

Model: SI3041GR

Power: 2350 Watts

Voltage: 240 Volts

Water Tank Capacity: 270 ml

Continuous Steam Output: 45 g/min

Steam Shot: 150 g/min

Soleplate Material: SuperCeramic

Special Features: FreeGlide 3D Technology, Precision Tip, Vertical Steam, Self-Clean

Dimensions (L x W x H): Approximately 19 x 20 x 36.5 cm

Weight: Approximately 750 g

Warranty and Customer Support

Braun products are manufactured to high-quality standards. For detailed warranty information specific to your region, please refer to the warranty card included with your product or visit the official Braun website. For technical assistance, spare parts, or any other inquiries, please contact Braun customer support in your region.

You can find more information and support atwww.braunhousehold.com.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HGDH9Y2

More documents and user manuals: **https://manuals.plus/**