Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mayer MMAF88

MAYER MMAF88 Air Fryer User Manual

Model: MMAF88 | Capacity: 3.5 Liters

1. Introduction

Thank you for choosing the MAYER MMAF88 Air Fryer. This appliance is designed to cook your favorite foods and snacks with little to no oil, providing a healthier alternative to traditional deep frying. By using rapid hot air circulation, the air fryer cooks food evenly and efficiently, resulting in crispy exteriors and tender interiors. Please read this manual thoroughly before first use to ensure safe and optimal operation.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the frying basket and pan are correctly inserted before operation.

- Do not block the air inlet or air outlet openings.
- Do not overfill the basket.

3. Product Components

Familiarize yourself with the main parts of your MAYER MMAF88 Air Fryer:

Main Unit: Contains the heating element and fan for hot air circulation.

Control Panel: Features a temperature dial, timer dial, power indicator light, and heating indicator light.

Frying Pan: The outer container that holds the frying basket.

Frying Basket: The removable inner basket where food is placed for cooking. It has a non-stick coating and perforations for air circulation.

Handle: For safely pulling out the frying pan and basket.



Image 1: Front view of the MAYER MMAF88 Air Fryer, showing the main unit, control dials, and handle.



Image 2: The MAYER MMAF88 Air Fryer with its frying basket detached from the main unit, illustrating the removable components.

4. Setup and First Use

4.1 Unpacking

1. Carefully remove the air fryer and all packaging materials from the box.
2. Remove any stickers or labels from the appliance.
3. Wipe the exterior of the appliance with a damp cloth.

4.2 Initial Cleaning

Before first use, clean the frying pan and basket thoroughly.

- Pull the handle to slide the frying pan and basket out of the air fryer.
- Separate the basket from the pan by pressing the release button.
- Wash the basket and pan in hot, soapy water using a non-abrasive sponge. Alternatively, they are dishwasher safe.
- Rinse thoroughly and dry all parts completely.
- Wipe the inside and outside of the appliance with a damp cloth.

4.3 Placement

- Place the air fryer on a stable, level, heat-resistant surface.
- Ensure there is at least 10 cm (4 inches) of free space on the back and sides of the appliance, and 10 cm (4 inches) above it, to allow for proper air circulation.

- Do not place the appliance against a wall or other appliances.

4.4 First Use (Preheating)

It is recommended to run the air fryer empty for about 10 minutes before first use to burn off any manufacturing residues and eliminate initial odors.

- Plug the power cord into a grounded wall outlet.
- Turn the temperature dial to 200°C.
- Turn the timer dial to 10 minutes. The power and heating indicator lights will illuminate.
- After 10 minutes, the timer will ring, and the appliance will switch off.
- Allow the appliance to cool down completely before proceeding.

5. Operating Instructions

5.1 Controls Overview

- **Temperature Dial:** Adjusts the cooking temperature from 80°C to 200°C.
- **Timer Dial:** Sets the cooking time from 0 to 30 minutes. The appliance automatically switches off when the timer reaches zero.
- **Power Indicator Light:** Illuminates when the appliance is plugged in and the timer is set.
- **Heating Indicator Light:** Illuminates when the heating element is active and turns off when the set temperature is reached. It will cycle on and off during cooking to maintain temperature.

5.2 Cooking Process

1. Place the air fryer on a stable, level, heat-resistant surface.
2. Carefully pull the frying pan out of the air fryer.
3. Place the ingredients into the frying basket. Do not exceed the MAX fill line or overfill the basket, as this can affect cooking results and damage the appliance.
4. Slide the frying pan back into the air fryer. Ensure it clicks securely into place.
5. Plug the power cord into a grounded wall outlet.
6. Turn the temperature dial to the desired temperature. Refer to the cooking guide below for recommendations.
7. Turn the timer dial to the desired cooking time. The power and heating indicator lights will illuminate.
8. During cooking, some foods may require shaking or turning for even results. To do this, pull out the frying pan, shake or turn the food, and then slide the pan back in. The air fryer will resume cooking automatically.
9. When the cooking time has elapsed, the timer will ring, and the appliance will automatically switch off. The indicator lights will turn off.
10. Carefully pull out the frying pan. Use oven mitts as the pan and food will be hot.
11. Empty the contents of the basket into a serving dish. For larger or delicate items, use tongs to remove them.
12. Unplug the appliance from the wall outlet and allow it to cool down before cleaning.

5.3 Cooking Guide

The following table provides general guidelines for cooking various types of food. Cooking times and temperatures may vary based on food quantity, size, and desired crispiness. Adjust as needed.

Food Item	Quantity	Temperature	Time (approx.)	Shake/Turn

Food Item	Quantity	Temperature	Time (approx.)	Shake/Turn
Frozen Fries (thin)	300-500g	180°C	15-20 min	2-3 times
Frozen Chicken Nuggets	200-400g	180°C	10-15 min	1-2 times
Fresh Chicken Drumsticks	2-4 pcs	190°C	20-25 min	1-2 times
Vegetables (broccoli, bell peppers)	200-300g	170°C	10-15 min	1-2 times
Spring Rolls	4-6 pcs	200°C	8-12 min	1 time

6. Maintenance and Cleaning

Clean the air fryer after every use. Always unplug the appliance and allow it to cool down completely before cleaning.

6.1 Cleaning the Frying Pan and Basket

- Separate the frying basket from the pan.
- Wash the basket and pan in hot, soapy water using a non-abrasive sponge. For stubborn food residue, soak the pan and basket in hot water with some dish soap for about 10 minutes.
- Alternatively, the basket and pan are dishwasher safe.
- Ensure all parts are thoroughly rinsed and dried before reassembling or storing.

6.2 Cleaning the Main Unit

- Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the surface.
- To clean the interior, including the heating element, use a non-abrasive sponge or brush to remove any food residue. Do not immerse the main unit in water or any other liquid.

6.3 Storage

- Ensure the air fryer is completely cool and clean before storing.
- Store the appliance in a dry, cool place.

7. Troubleshooting

If you encounter any issues with your air fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Timer is not set.	Ensure the power cord is securely plugged into a grounded outlet. Turn the timer dial to the desired cooking time.
Food is not cooked evenly.	Too much food in the basket. Food not shaken/turned.	Reduce the amount of food per batch. Shake or turn food halfway through cooking.

Problem	Possible Cause	Solution
White smoke coming from the appliance.	Greasy residue from previous use. High fat content food.	Clean the frying pan and basket thoroughly after each use. For high-fat foods, drain excess oil from the pan during cooking.
Food is not crispy.	Not enough oil (for some foods). Temperature too low or time too short.	Lightly brush or spray food with a small amount of oil. Increase temperature or cooking time.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Detailed technical specifications for the MAYER MMAF88 Air Fryer:

Specification	Value
Model	MMAF88
Brand	Mayer
Capacity	3.5 Liters
Wattage	1400 watts
Voltage	240 Volts
Material	Aluminium
Control Method	Dial (Manual)
Dimensions (L x W x H)	34 x 34 x 33 cm
Item Weight	5.3 Kilograms
Special Features	Temperature Control



Image 3: Dimensional diagram of the MAYER MMAF88 Air Fryer, indicating a height of 31 cm (12 inches).

9. Warranty and Support

The MAYER MMAF88 Air Fryer comes with a standard manufacturer's warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration of coverage. Keep your purchase receipt as proof of purchase.

For technical support, service, or warranty claims, please contact Mayer customer service. You can typically find contact information on the manufacturer's official website or on the product packaging.

For more information, visit the official Mayer website:www.mayer.sg

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JH3V1CH

More documents and user manuals: **https://manuals.plus/**