Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Shark V2945Z

Shark V2945Z 12-inch Rechargeable Floor and Carpet Sweeper User Manual

Model: V2945Z | Brand: Shark

1. Introduction

The Shark V2945Z 12-inch Rechargeable Floor and Carpet Sweeper is designed for efficient cleaning of various floor types. This lightweight and cordless sweeper features a 12-inch motorized brush roll with two speed settings, making it suitable for picking up dirt, pet hair, and debris from both hard floors and carpets. Its low-profile head and swivel steering enhance maneuverability, allowing access under furniture and into tight spaces. The handle also folds for extended reach. This manual provides essential information for the safe and effective use and maintenance of your sweeper.

2. Safety Information

- Read all instructions before using the appliance.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only as described in this manual.
- Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Always turn off the appliance before connecting or disconnecting the charger.
- Store the appliance indoors in a cool, dry area.

3. Package Contents

Ensure all components are present in your package:

- Shark V2945Z Sweeper Unit
- Rechargeable Battery
- Charger

- Brush Roll (pre-installed)

4. Setup

4.1 Initial Charging

Before first use, fully charge the sweeper. Connect the charger to the charging port on the sweeper and plug it into a standard electrical outlet. A full charge typically takes approximately 7 hours. The charging indicator light will confirm the charging status.

4.2 Battery Installation (if not pre-installed)

If the battery is not pre-installed, locate the battery compartment, typically on the underside of the sweeper head. Insert the rechargeable battery, ensuring it clicks securely into place. Close the compartment cover.

4.3 Handle Assembly

Attach the handle sections by aligning and pushing them together until they lock. Ensure the handle is firmly connected to the sweeper head.

5. Operating Instructions

5.1 Power On/Off

To turn the sweeper on, press the power button located on the sweeper head. Press it again to turn the unit off.

5.2 Speed Settings

The Shark V2945Z features two speed settings for optimal cleaning on different surfaces. Use the appropriate speed setting for your floor type:

- **Low Speed:** Ideal for delicate hard floors and light debris.
- **High Speed:** Recommended for carpets and heavier debris.

5.3 Cleaning Different Surfaces

The sweeper is designed for use on both hard floors (such as laminate, tile, and hardwood) and low-pile carpets. Adjust the speed setting as needed.



Image: The Shark V2945Z sweeper effectively cleaning a carpeted area.

5.4 Maneuverability and Reach

Utilize the swivel steering for easy navigation around furniture. The low-profile head allows access under tables and chairs. For extended reach into difficult areas, the handle can be folded.



Image: The sweeper's flexible handle and low profile allow it to reach under furniture for thorough cleaning.

5.5 Edge Cleaning

The sweeper is equipped with an edge cleaning squeegee to efficiently pick up dirt and debris from corners and along wall edges.



Image: The sweeper's design allows for effective cleaning along edges and in corners.

6. Maintenance

6.1 Emptying the Dust Cup

The sweeper features an easy-to-empty dust cup. To empty, locate the release mechanism (often a button or tabs) on the sweeper head, detach the dust cup, and dispose of the collected debris. Reattach the dust cup securely after emptying.



Image: A hand demonstrates the easy removal and emptying of the sweeper's dust cup.

6.2 Cleaning the Brush Roll

Periodically inspect the motorized brush roll for tangled hair or debris. To clean, turn off the sweeper, remove the brush roll cover (if applicable), and carefully remove any obstructions. A hair removal tool may be included or can be used to cut away tangled hair. Ensure the brush roll is reinstalled correctly.

6.3 Recharging the Battery

When the battery indicator shows low power, recharge the sweeper using the provided charger. It is recommended to keep the sweeper charged when not in use to ensure it's always ready for quick clean-ups.

7. Troubleshooting

- **Sweeper not turning on:** Ensure the battery is fully charged and correctly installed. Check if the power button is pressed firmly.
- **Reduced suction/pickup:** Empty the dust cup. Check the brush roll for obstructions (tangled hair, large debris) and clean it. Ensure the brush roll is spinning freely.

- **Battery not charging:** Verify the charger is properly connected to both the sweeper and a working electrical outlet. Ensure the charger is the correct model (XA2700).
- **Unusual noise:** Turn off the sweeper and inspect the brush roll and dust cup area for any foreign objects or damage.

8. Specifications

Feature	Specification
Brand	Shark
Model Name	V2945Z
Special Feature	Lightweight
Filter Type	Foam
Is Cordless?	Yes
Recommended Uses	Carpet, Hard Floor
Form Factor	Stick
Color	Purple
Battery Description	Rechargeable battery with approximately 12 volts
Item Weight	4.2 pounds
Number of Speeds	2
UPC	748926535724

9. Warranty & Support

This Certified Refurbished product comes with a minimum 90-day warranty. For warranty claims, replacement parts, or further support, please contact Shark customer service or visit their official website. Refer to the product packaging for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JLRHXXV

More documents and user manuals: **https://manuals.plus/**