Briggs & Stratton 104M02-0197-F1

Briggs & Stratton 725EXi Series Gas Engine User Manual

Model: 104M02-0197-F1

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Briggs & Stratton 725EXi Series Single Cylinder Air-Cooled 4-Cycle Gas Engine. This engine is designed for dependable power and ease of use, featuring advanced engineering for a lighter, quieter, and smoother operating experience. Key features include the ReadyStart no-prime starting system, Magnetron Electronic Ignition, and DuraLube Splash Lubrication.



Figure 1: Briggs & Stratton 725EXi Series Gas Engine. This image shows the engine from a top-front perspective, highlighting its compact design and the prominent 725EXi branding.

Safety Information

Always read and understand all safety warnings and instructions before operating the engine. Failure to do so can result in serious injury or death.

- **Fuel Safety:** Gasoline is highly flammable. Always refuel in a well-ventilated area with the engine off and cool. Do not smoke or allow open flames near the engine.
- **Hot Surfaces:** The engine and muffler become very hot during operation and remain hot for a period after shutdown. Avoid contact to prevent burns.
- **Moving Parts:** Keep hands, feet, and clothing away from moving parts such as the flywheel and fan.
- **Ventilation:** Operate the engine in a well-ventilated area. Engine exhaust contains carbon monoxide, a colorless, odorless, and deadly gas.
- **Proposition 65 Warning:** This product can expose you to chemicals including engine exhaust, which is known to the State of California to cause cancer, and carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Setup and Preparation

Unpacking

Carefully remove the engine from its packaging. Inspect for any shipping damage. Retain packaging for future transport or storage.

Adding Engine Oil

The 725EXi Series engine features 'Check and Add' technology, meaning you typically do not need to change the engine oil. Simply check the oil level before each use and add oil as needed.

- Place the engine on a level surface.
- Locate the oil fill cap/dipstick (often yellow or black, with an oil can symbol).
- Remove the cap/dipstick, wipe it clean, and reinsert it without threading.
- Remove again and check the oil level. It should be at the 'FULL' mark.
- If low, slowly add recommended engine oil (refer to engine label for type, typically SAE 30 or 10W-30) until the 'FULL' mark is reached. Do not overfill.
- Securely replace the oil fill cap/dipstick.




Figure 2: Engine Side View. This side view of the engine displays important warning labels, emission control information, and a QR code for

additional product details. The oil fill cap is also visible on the top right.

Adding Fuel

Use clean, fresh, unleaded gasoline with an octane rating of 87 or higher. Do not use E85 or gasoline containing more than 10% ethanol.

- Ensure the engine is off and cool.
- Locate the fuel tank cap (often black, with a fuel pump symbol).
- Slowly remove the fuel cap to release any pressure.
- Fill the fuel tank, leaving a small space at the top for expansion. The fuel tank capacity is approximately 0.25 gallons. The angled fuel neck allows for less spilling and easier filling.
- Securely replace the fuel cap.



Figure 3: Engine Top View. A top-down view of the engine, clearly showing the fuel cap on the right and the air intake grille.

Mounting the Engine

Ensure the engine is securely mounted to the equipment according to the equipment manufacturer's instructions. Proper mounting is crucial for safe operation and engine longevity.

Operating Instructions

Starting the Engine

The 725EXi Series engine features the ReadyStart system, which eliminates the need for priming or choking. Simply pull the starter cord.

- Ensure the engine has adequate oil and fuel.
- Make sure the equipment is in a safe operating position.
- Grasp the starter handle firmly.
- Pull the starter cord slowly until resistance is felt, then pull quickly and smoothly to start the engine.
- Allow the engine to warm up for a few moments before engaging the equipment.

Stopping the Engine

To stop the engine, refer to your equipment's operating instructions. Typically, this involves releasing the operator presence control bar or moving the throttle to the 'STOP' position.

During Operation

Monitor the engine for unusual noises, vibrations, or performance issues. Ensure proper ventilation and avoid operating in enclosed spaces.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your engine. Always perform maintenance with the engine off and cool, and disconnect the spark plug wire to prevent accidental starting.

Oil Maintenance

As mentioned, the 725EXi Series engine uses 'Check and Add' technology. Regularly check the oil level and add oil as needed. A full oil change is generally not required under normal operating conditions.

Air Filter Cleaning/Replacement

A clean air filter is crucial for engine performance and longevity. Check the air filter regularly and clean or replace it as necessary.

- Locate the air filter cover (usually on the side of the engine).
- Remove the cover and carefully remove the air filter element.
- If foam, wash in liquid detergent and water, squeeze dry, then saturate with engine oil and squeeze out excess.
- If paper, tap gently to remove loose dirt. Replace if heavily soiled or damaged.
- Reinstall the filter and cover.

Spark Plug Inspection

Inspect the spark plug annually or every 50 hours of operation.

- Disconnect the spark plug wire.
- Use a spark plug wrench to remove the spark plug.
- Check for fouling, wear, or damage. Clean or replace as needed.
- Ensure the gap is set correctly (refer to engine specifications or spark plug manufacturer's recommendations).
- Reinstall the spark plug and reconnect the wire.

Cleaning the Engine

Keep the engine clean, especially the cooling fins and air intake areas, to prevent overheating. Use a brush or compressed air to remove debris.



Figure 4: Engine Side Profile. A side profile of the engine, illustrating the exhaust system and other key components.

Troubleshooting

This section provides solutions to common operational issues. For problems not listed, consult a qualified service technician.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Engine will not start	No fuel; Stale fuel; Low oil level; Fouled spark plug; Loose spark plug wire; Air filter clogged; Ignition system issue.	Add fresh fuel; Drain and refill with fresh fuel; Add oil to correct level; Clean/replace spark plug; Reconnect spark plug wire; Clean/replace air filter; Consult service center for ignition issues.
Engine runs rough or stalls	Stale fuel; Clogged fuel filter; Dirty air filter; Fouled spark plug; Carburetor issues.	Drain and refill with fresh fuel; Replace fuel filter; Clean/replace air filter; Clean/replace spark plug; Consult service center for carburetor issues.
Engine lacks power	Dirty air filter; Low oil level; Overheating; Incorrect engine speed.	Clean/replace air filter; Add oil to correct level; Ensure proper cooling and ventilation; Check equipment for proper load.
Excessive vibration	Loose mounting bolts; Damaged engine components.	Check and tighten all mounting bolts; Consult service center for internal damage.

Specifications

Key specifications for the Briggs & Stratton 725EXi Series Gas Engine, Model 104M02-0197-F1:

Attribute	Value
Engine Type	Single Cylinder, Air-Cooled, 4-Cycle Gas Engine
Displacement	163cc
Model Number	104M02-0197-F1
Product Dimensions	17.5 x 14.75 x 14.75 inches
Item Weight	22.9 pounds
Country of Origin	USA

Warranty and Support

Your Briggs & Stratton 725EXi Series engine is backed by a two-year limited consumer warranty. This warranty covers defects in material and workmanship under normal use and service.

For warranty service, technical support, or to locate an authorized service dealer, please visit the official Briggs & Stratton website or contact their customer service directly. Always have your engine model and serial numbers available when seeking support.

For more information, visit: www.briggsandstratton.com

© 2025 Briggs & Stratton. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question