Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome iB99GQC

iHome Bluetooth Foldable Headphones User Manual

Model: iB99GQC

Introduction

This manual provides essential information for the safe and efficient use of your iHome Bluetooth Foldable Headphones. Please read this manual thoroughly before using the product and retain it for future reference.

Safety Information

- Do not expose the headphones to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not disassemble or attempt to repair the headphones yourself. This will void the warranty.
- Clean the headphones with a soft, dry cloth. Do not use liquid cleaners.
- Prolonged listening at high volume levels may cause hearing damage. Adjust volume to a safe level.

Package Contents

- iHome Bluetooth Foldable Headphones
- USB Charging Cable
- User Manual (this document)

Product Overview



Figure 1: iHome Bluetooth Foldable Headphones in their compact, folded state. The headphones feature a gray body with bright green accents on the earcups, indicating the iHome branding and control areas. The foldable design allows for easy storage and transport.

The iHome Bluetooth Foldable Headphones are designed for portability and wireless audio enjoyment. They feature a compact, foldable design, making them ideal for travel and daily use. The headphones connect wirelessly via Bluetooth to your compatible devices.

Key Components:

1. Power/Multi-function Button
2. Volume Up/Next Track Button

3. Volume Down/Previous Track Button
4. Microphone
5. LED Indicator Light
6. USB Charging Port
7. Adjustable Headband
8. Foldable Hinges

Setup

Initial Charging

1. Before first use, fully charge your headphones.
2. Connect the small end of the USB charging cable to the USB charging port on the headphone earcup.
3. Connect the larger end of the USB charging cable to a powered USB port (e.g., computer, USB wall adapter).
4. The LED indicator light will illuminate during charging and change color or turn off when charging is complete. Refer to the LED Indicator section for specific light behaviors.

Operating Instructions

Power On/Off

- To Power On: Press and hold the Power/Multi-function Button for approximately 3 seconds until the LED indicator light flashes.
- To Power Off: Press and hold the Power/Multi-function Button for approximately 3 seconds until the LED indicator light turns off.

Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power/Multi-function Button for approximately 5-7 seconds until the LED indicator light flashes rapidly (often alternating blue and red), indicating pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, computer), go to the Bluetooth settings.
4. Search for available devices. The headphones should appear as "iHome Headphones" or similar.
5. Select the headphones from the list to connect. Once successfully paired, the LED indicator light will typically slow its flash or turn solid blue.
6. If prompted for a passcode, enter "0000".

Note: The headphones will automatically attempt to reconnect to the last paired device when powered on, if that device is within range and has Bluetooth enabled.

Controlling Audio and Calls

Function	Action
Play/Pause Music	Short press the Power/Multi-function Button.

Function	Action
Next Track	Long press the Volume Up Button.
Previous Track	Long press the Volume Down Button.
Volume Up	Short press the Volume Up Button.
Volume Down	Short press the Volume Down Button.
Answer/End Call	Short press the Power/Multi-function Button during an incoming call.
Reject Call	Long press the Power/Multi-function Button during an incoming call.
Activate Voice Assistant (Siri/Google Assistant)	Double-press the Power/Multi-function Button.

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the headphones. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. Utilize the foldable design for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.

Troubleshooting

Problem	Possible Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair with device.	◦ Ensure headphones are in pairing mode (rapidly flashing LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move headphones closer to your device. ◦ Forget/remove "iHome Headphones" from your device's Bluetooth list and try pairing again. ◦ Restart both the headphones and your device.
No sound or low volume.	◦ Increase volume on both the headphones and your connected device. ◦ Ensure headphones are properly paired and connected. ◦ Try playing different audio sources.

Problem	Possible Solution
Intermittent connection.	◦ Move closer to your device; avoid obstacles between headphones and device. ◦ Avoid strong electromagnetic interference from other devices. ◦ Ensure headphones are fully charged.

Specifications

Feature	Detail
Model Number	iB99GQC
Connectivity	Bluetooth 5.0
Frequency Range	20 Hz - 20,000 Hz
Material	Thermoplastic Elastomer (TPE)
Water Resistance Level	Water Resistant
Item Weight	10.4 ounces
Package Dimensions	7.75 x 6.75 x 3.5 inches
Manufacturer	iHome
UPC	047532913316

Warranty and Support

iHome products are designed with quality and reliability in mind. For information regarding warranty coverage and support, please refer to the warranty card included with your purchase or visit the official iHome website. Typically, products come with a limited warranty covering defects in materials and workmanship for a specified period from the date of original purchase.

For technical assistance or customer service inquiries, please contact iHome customer support through their official channels. Keep your proof of purchase for warranty claims.

Return Policy: This product may be eligible for a refund or replacement within 30 days of purchase, subject to the retailer's return policy.

© 2024 iHome. All rights reserved.
Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07KWG48B7

More documents and user manuals: **https://manuals.plus/**