Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GTR8724

GEEPAS 11 in 1 Grooming Kit User Manual

Model: GTR8724

Introduction

Thank you for choosing the GEEPAS 11 in 1 Grooming Kit. This manual provides essential information for the safe and effective use of your new grooming device. Please read these instructions carefully before first use and keep them for future reference.



The GEEPAS 11 in 1 Grooming Kit, showcasing the main trimmer unit on its charging stand, surrounded by its various interchangeable heads and comb attachments.

Important Safety Instructions

To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions:

- Do not immerse the main unit in water. The trimmer heads are washable, but the main body is not.
- Keep the appliance away from water sources when charging.
- Do not use the appliance with a damaged cord or plug.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Children should be supervised to ensure they do not play with the appliance.
- Only use the charger supplied with the appliance.
- Unplug the appliance before cleaning or maintenance.

- Do not open the appliance housing; there are no user-serviceable parts inside.

Package Contents

Your GEEPAS 11 in 1 Grooming Kit includes the following items:

- Main Trimmer Unit
- Hair Clipper Head
- Beard Trimmer Head
- Precision Trimmer Head
- Nose/Ear Trimmer Head
- Shaver Head
- 4 x Hair Clipper Combs (3mm, 6mm, 9mm, 12mm)
- 1 x Beard Trimmer Comb
- Charging Stand
- BS Adaptor (Charger)
- Cleaning Brush
- Lubricating Oil



An exploded view of the GEEPAS 11 in 1 Grooming Kit, showing the main trimmer unit and all its interchangeable heads and comb attachments separately.

Setup and Charging

Initial Charging

1. Before first use, fully charge the grooming kit for approximately 8-10 hours.
2. Connect the BS adaptor to the charging stand.
3. Place the main trimmer unit onto the charging stand. Ensure it is seated correctly.
4. The LED indicator on the charging stand will illuminate to show that the device is charging.
5. Once fully charged, the LED indicator may change color or turn off, depending on the model. Disconnect the charger from the power outlet.

Attaching and Detaching Heads

1. To attach a head: Align the desired head with the main trimmer unit and push it down until it clicks securely into place.
2. To detach a head: Hold the main trimmer unit firmly and gently pull the attached head upwards to remove it.
3. Ensure the trimmer is switched off before changing heads.

Operating Instructions

General Operation

- Ensure the desired attachment head is securely fitted.
- Press the power button to turn the trimmer on.
- Press the power button again to turn the trimmer off.

Using Specific Heads



Demonstration of various grooming functions: Micro Head Shaver for fine details, Precision Trimmer for clean lines, Nose/Ear Trimmer for unwanted hair, and Electric Shaver for a smooth finish.

- **Hair Clipper Head:** Attach one of the 4 hair clipper combs (3mm, 6mm, 9mm, 12mm) to achieve desired hair length. Move the trimmer against the direction of hair growth.
- **Beard Trimmer Head:** Use with the beard trimmer comb for maintaining beard length, or without the comb for closer trimming and shaping.

- **Precision Trimmer Head:** Ideal for creating sharp lines, detailing, and intricate styling around the beard, mustache, and sideburns.
- **Nose/Ear Trimmer Head:** Gently insert the trimmer into the nostril or ear canal. Move it in a circular motion to trim unwanted hair. Do not insert too deeply.
- **Shaver Head:** For a clean, close shave on smaller areas or for finishing touches. Hold the shaver flat against the skin and move in short, gentle strokes.

Maintenance and Cleaning

Cleaning the Trimmer Heads

1. Ensure the trimmer is switched off and unplugged from the charger.
2. Detach the trimmer head from the main unit.
3. Use the provided cleaning brush to remove any loose hairs from the blades and inside the head.
4. The trimmer heads (excluding the main unit) can be rinsed under running water. Ensure they are completely dry before reattaching or storing.
5. Do not rinse the main trimmer unit under water.

Lubrication

After cleaning and drying, apply a small drop of the provided lubricating oil to the blades of the hair clipper, beard trimmer, and precision trimmer heads. Run the trimmer for a few seconds to distribute the oil evenly. This helps maintain blade performance and longevity.

Storage

Store the grooming kit and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

Troubleshooting Guide

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is discharged.	Charge the trimmer for the recommended time.
Trimmer pulls hair or cuts poorly.	Blades are dirty or not lubricated.	Clean the blades and apply lubricating oil.
Trimmer makes unusual noise.	Head not properly attached or foreign object.	Ensure head is securely attached. Clean the head for any obstructions.
Charging indicator not working.	Charger or charging stand issue.	Check connections. Ensure adaptor is plugged into a working outlet.

Product Specifications

- **Model:** GTR8724
- **Power Source:** Battery Powered (Rechargeable)

- **Battery Type:** 2 x 600mAh AA batteries (internal)
- **Input DC:** 3V
- **Blade Material:** Steel or Metal
- **Product Dimensions (LxWxH):** 6 x 23.6 x 16.2 cm
- **Item Weight:** 640 g
- **Specific Uses:** Hair, Beard, Shaving, Nose, Ear



Product packaging highlighting key features and the model number GTR8724, along with the brand logo.

Warranty and Support

Warranty Information

This product comes with a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details. Keep your purchase receipt as proof of purchase.

Customer Support

For any questions, concerns, or technical assistance regarding your GEEPAS 11 in 1 Grooming Kit, please contact GEEPAS customer support. You can find contact details on the official GEEPAS website or on your product packaging.

Official Website: www.geepas.com

Product Barcode (UPC): 6294015504910

© 2023 Geepas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07KZJ541X

More documents and user manuals: **https://manuals.plus/**