Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta A88J130

Konica Minolta TN016 (A88J130) Black Toner Cartridge User Manual

Model: TN016 (A88J130) | Brand: Minolta

Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your OEM Konica Minolta TN016 (A88J130) Black Toner Cartridge. Designed for optimal performance, this genuine Konica Minolta product ensures high-quality prints and reliable operation with compatible Konica Minolta bizhub PRO 1100 devices.

Product Overview



Image: The Konica Minolta TN016 black toner cartridge, shown inside its original brown cardboard packaging. The box features the Konica Minolta logo and "TONER TN016" branding.



Image: A full view of the Konica Minolta TN016 toner cartridge's brown cardboard packaging. The box displays the brand logo, "TONER TN016", and product information.



Image: The Konica Minolta TN016 black toner cartridge itself, removed from its packaging. It is a cylindrical, grey-colored unit with a white cap on one end.



Image: A close-up front view of the Konica Minolta TN016 toner cartridge box, clearly showing the "TONER TN016" label and the Konica Minolta logo.

Key Features:

- **Genuine Konica Minolta Product:** Ensures compatibility and optimal performance with specified devices.
- **High Page Yield:** Estimated yield of up to 82,000 pages, suitable for high-volume printing environments.
- **Consistent Quality Output:** Delivers sharp, professional-quality black prints.
- **Compatibility:** Specifically designed for use with Konica Minolta bizhub PRO 1100 printers.
- **Manufacturer Part Number:** A88J130, TN-016.

Setup and Installation

Follow these general steps for installing the toner cartridge. Refer to your printer's specific user manual for detailed instructions, as procedures may vary slightly by model.

1. **Power Off Printer:** Ensure the printer is turned off and unplugged before beginning installation to prevent electrical hazards.
2. **Open Access Door:** Locate and open the toner cartridge access door on your Konica Minolta bizhub PRO 1100 printer.
3. **Remove Old Cartridge (if applicable):** If replacing an empty cartridge, carefully grasp the old cartridge and pull it straight out of the printer. Dispose of it according to local regulations.
4. **Unpack New Cartridge:** Remove the new Konica Minolta TN016 toner cartridge from its packaging. Avoid touching the drum or electrical contacts.
5. **Shake Cartridge:** Gently shake the new toner cartridge horizontally 5-6 times to distribute the toner evenly inside.
6. **Remove Protective Seals:** Carefully remove any protective tapes, seals, or covers from the cartridge as indicated in your printer's manual.
7. **Insert New Cartridge:** Align the new cartridge with the slot in the printer and slide it in firmly until it clicks into place. Do not force it.
8. **Close Access Door:** Close the toner cartridge access door securely.
9. **Power On Printer:** Plug in and power on your printer. The printer may perform a calibration or initialization process.

Operation

Once the Konica Minolta TN016 toner cartridge is correctly installed, your printer is ready for operation. The cartridge functions automatically as part of the printing process.

- **Printing:** Send print jobs from your computer or device as usual. The printer will draw toner from the cartridge to create images and text on paper.
- **Toner Level Monitoring:** Most Konica Minolta printers provide a way to monitor toner levels through the printer's control panel or software utility. Monitor these levels to anticipate when a replacement cartridge will be needed.
- **Page Yield:** This cartridge is designed to yield approximately 82,000 pages. Actual yield may vary significantly based on content of printed pages and other factors.

Maintenance

Proper handling and storage can extend the life and maintain the quality of your toner cartridge.

- **Storage:** Store new, unused toner cartridges in their original sealed packaging in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handling:** When handling the cartridge, avoid touching the photosensitive drum (usually a green or blue cylinder) as oils from your skin can damage it and affect print quality.
- **Disposal:** When the cartridge is empty, dispose of it responsibly. Many manufacturers and retailers offer recycling programs for used toner cartridges.
- **Printer Cleaning:** Regularly clean your printer according to its manual to prevent toner buildup, which can affect print quality and printer longevity.

Troubleshooting

If you encounter issues with your toner cartridge or print quality, consider the following common troubleshooting steps:

- **Poor Print Quality (Faded, Streaky, or Missing Areas):**
  - Check toner level: The cartridge may be low on toner.
  - Shake cartridge: Remove the cartridge and gently shake it horizontally to redistribute remaining toner.
  - Clean printer components: Refer to your printer manual for instructions on cleaning the print head or other relevant components.
  - Replace cartridge: If issues persist, the cartridge may be empty or defective.
- **"Toner Low" or "Replace Toner" Message:**
  - This indicates the cartridge is nearing or has reached the end of its life. Prepare a replacement.
  - Ensure the cartridge is properly seated. Remove and reinsert it firmly.
- **Cartridge Not Recognized:**
  - Ensure the cartridge is correctly installed and fully seated.
  - Check for any protective tapes or seals that may not have been fully removed.
  - Clean electrical contacts on the cartridge and in the printer with a lint-free cloth.
  - Restart the printer.

If these steps do not resolve the issue, consult your Konica Minolta printer's user manual or contact Konica Minolta customer support.

Specifications

Attribute	Detail
Brand	Minolta
Manufacturer	Konica Minolta
Model Number	A88J130
Part Number	TN-016
Color	Black
Page Yield	Up to 82,000 pages
Item Weight	4.74 pounds (approx. 2.15 kg)
Package Dimensions	21 x 7.6 x 5 inches (approx. 53.34 x 19.3 x 12.7 cm)
Compatible Devices	Konica Minolta bizhub PRO 1100 Printer
Included Components	1 x Toner Cartridge

Warranty and Support

This OEM Konica Minolta toner cartridge is backed by Konica Minolta's standard warranty for genuine consumables. For specific warranty terms, conditions, and support, please refer to the documentation included with your printer or visit the official Konica Minolta website.

For technical assistance or inquiries regarding your Konica Minolta products, please contact Konica Minolta customer support directly.

Konica Minolta Official Website: www.konicaminolta.com

© 2024 Konica Minolta. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07L147XL7

More documents and user manuals: **https://manuals.plus/**