Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bosch 06008A7D70

Bosch AdvancedAquatak 140 High Pressure Washer User Manual

Model: 06008A7D70

1. Introduction

Thank you for choosing the Bosch AdvancedAquatak 140 High Pressure Washer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new pressure washer. Please read these instructions carefully before use and keep them for future reference. Proper use and care will ensure long-lasting performance and safety.

2. Safety Information

Always observe basic safety precautions to reduce the risk of fire, electric shock, and personal injury. High-pressure washers can be dangerous if not used correctly.

- **Read all instructions:** Familiarize yourself with the controls and proper use of the pressure washer.
- **Wear appropriate safety gear:** Always wear safety glasses, hearing protection, and protective footwear.
- **Never point the spray gun at people or animals:** The high-pressure jet can cause serious injury.
- **Ensure stable footing:** The recoil force of the spray can cause you to lose balance.
- **Do not operate near electrical outlets or equipment:** Risk of electric shock.
- **Check connections:** Ensure all hoses and connections are securely fastened before starting.
- **Use only approved accessories:** Using unapproved accessories may result in injury or damage to the unit.
- **Disconnect power before maintenance:** Always unplug the unit from the power source before performing any maintenance or cleaning.

3. Product Overview

The Bosch AdvancedAquatak 140 is a powerful high-pressure washer designed for various cleaning tasks. It features a robust motor, integrated hose reel, and telescopic handle for ease of use and storage.




BOSCH
AdvancedAquatak 140



Figure 1: Front view of the Bosch AdvancedAquatak 140 High Pressure Washer, showing the integrated hose reel, telescopic handle, and main controls.

Key Components:

- **High-Pressure Hose Reel:** For convenient storage and deployment of the high-pressure hose.
- **Telescopic Handle:** Adjustable handle for comfortable transport and compact storage.
- **Water Inlet:** Connection point for the garden hose.
- **High-Pressure Outlet:** Connection point for the high-pressure hose.
- **On/Off Switch:** Controls the power to the unit.
- **Spray Gun and Lance:** For directing the high-pressure water jet.
- **Nozzles:** Various nozzles for different cleaning applications (e.g., fan jet, rotary jet).

4. Setup

Follow these steps to prepare your pressure washer for first use.

4.1 Unpacking and Assembly

1. Carefully remove all components from the packaging.
2. Extend the telescopic handle to its operating position.
3. Attach any loose accessories such as the spray gun holder or power cable hook, if not pre-assembled.

4.2 Water Connection

Ensure your water supply is clean and free of debris. A minimum flow rate of 480 l/h is recommended for optimal performance.



Figure 2: Connecting the garden hose to the water inlet of the pressure washer. Ensure a tight, leak-free connection.

1. Connect a standard garden hose (not supplied) to the water inlet on the pressure washer. Ensure the connection is secure to prevent leaks.
2. Connect the high-pressure hose to the high-pressure outlet on the unit and to the spray gun.
3. Turn on the water supply fully.

4.3 Power Connection

1. Ensure the On/Off switch is in the 'Off' position.
2. Plug the power cable into a suitable grounded electrical outlet.

4.4 Priming the Pump

Before starting the motor, it is crucial to prime the pump to remove any air and prevent damage.

1. With the water supply on, hold the spray gun open (trigger pressed) for approximately 30 seconds to allow water to flow through and expel air.
2. Once a steady stream of water emerges from the nozzle, the pump is primed.

5. Operating Instructions

This section details how to safely and effectively operate your pressure washer.

5.1 Starting the Unit

1. Ensure the water supply is fully open and the pump is primed.
2. Turn the On/Off switch to the 'On' position. The motor will start.
3. Press the trigger on the spray gun to begin spraying. The motor will only run when the trigger is pressed (auto stop/start function).

5.2 Using Nozzles and Attachments

Select the appropriate nozzle for your cleaning task. Different nozzles provide varying spray patterns and intensities.

- **Fan Jet Nozzle:** Ideal for general cleaning, rinsing, and larger surfaces.
- **Rotary Jet Nozzle:** Provides a powerful, concentrated spray for stubborn dirt and grime. Use with caution on delicate surfaces.
- **Detergent Nozzle/System:** For applying cleaning detergents. Follow detergent manufacturer's instructions.



Figure 3: Demonstrating the use of the pressure washer for cleaning a vehicle. Always maintain a safe distance from the surface being cleaned.

5.3 Cleaning Techniques

- Start cleaning from a distance of approximately 30 cm (12 inches) and gradually move closer if needed, especially on sensitive surfaces.
- Use sweeping motions to ensure even cleaning.
- For vertical surfaces, clean from bottom to top to prevent streaks.

5.4 Shutting Down

1. Release the spray gun trigger.
2. Turn the On/Off switch to the 'Off' position.
3. Turn off the water supply.
4. Press the spray gun trigger to release any remaining pressure in the system.
5. Disconnect the power cable from the outlet.

6. Disconnect the garden hose and high-pressure hose.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your pressure washer.

6.1 Cleaning the Water Inlet Filter

The water inlet filter prevents debris from entering the pump. Clean it regularly, especially if you notice reduced water flow.

1. Ensure the unit is off and disconnected from power and water supply.
2. Unscrew the water inlet connection.
3. Remove the filter and rinse it under running water.
4. Reinsert the clean filter and reattach the water inlet connection.

6.2 Storage

Proper storage protects your pressure washer from damage.



Figure 4: Winding the high-pressure hose onto the integrated reel for neat storage. The telescopic handle can also be retracted.

- Drain all water from the pump, hoses, and spray gun. Run the unit for a few seconds with the water supply off and trigger pressed to expel remaining water.
- Wind the high-pressure hose onto the integrated reel.
- Retract the telescopic handle for compact storage.
- Store the unit in a dry, frost-free location.

6.3 Winterization

If storing in freezing temperatures, winterize the unit to prevent damage from ice expansion.

1. Completely drain all water as described in 'Storage'.
2. Consider using a pump protector or non-toxic antifreeze solution specifically designed for pressure washers. Follow the product's instructions for application.

7. Troubleshooting

This section addresses common issues you might encounter and their solutions.

Problem	Possible Cause	Solution
Motor does not start	No power supply On/Off switch in 'Off' position Thermal overload activated	Check power connection and circuit breaker Turn switch to 'On' Allow unit to cool down for 15-30 minutes
No water or low pressure	Water supply off or restricted Water inlet filter clogged Air in pump Nozzle clogged	Turn on water supply, check hose for kinks Clean water inlet filter Prime the pump (see Section 4.4) Clean nozzle with a pin or needle
Water leaks	Loose connections Damaged O-rings or seals	Tighten all hose connections Inspect and replace damaged O-rings/seals
Motor runs continuously (no auto stop)	Air in pump Leak in system Spray gun trigger not fully released	Prime the pump Check for leaks in hoses and connections Ensure trigger is fully released

If the problem persists after attempting these solutions, please contact Bosch customer service.

8. Specifications

Technical data for the Bosch AdvancedAquatak 140 High Pressure Washer.

- **Model Number:** 06008A7D70
- **Brand:** Bosch
- **Item Weight:** 17.55 kg
- **Power:** 2200 W (as per product description, though not in specifications list directly)
- **Max Pressure:** 140 bar (as per product description)
- **Max Flow Rate:** 480 l/h (as per product description)
- **Hose Length:** 8m (as per feature bullets)
- **Manufacturer:** BOSCH

9. Warranty and Support

Bosch products are manufactured to high quality standards and come with a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Bosch website.
For technical support, spare parts, or service inquiries, please contact your local Bosch service center or visit the Bosch website for contact information.
Online Resources: Bosch Garden Tools Official Website

© 2023 Bosch. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MQ9HHS2

More documents and user manuals: **https://manuals.plus/**