**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Geepas GO2413

# Geepas Oven Toaster/Hot Plate 60L GO2413 User Manual

Model: GO2413

## 1. Introduction

Thank you for purchasing the Geepas Oven Toaster/Hot Plate 60L GO2413. This appliance is designed for versatile cooking, combining the functions of an oven, toaster, and hot plates. To ensure safe and efficient operation, please read this instruction manual thoroughly before first use and retain it for future reference.

## 2. Important Safety Instructions

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the toaster oven is covered or touching flammable material, including curtains, drapes, walls, and the like, when in operation.

- Do not place any of the following materials in the oven: paper, cardboard, plastic, and similar items.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.
- Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.

## 3. Product Overview

The Geepas Oven Toaster/Hot Plate GO2413 is a multi-functional kitchen appliance featuring a 60-liter oven capacity and integrated hot plates on top. It is designed for baking, toasting, grilling, and cooking with its various heating elements and rotisserie function.




**Figure 1:** Front view of the Geepas Oven Toaster/Hot Plate 60L GO2413. The image shows the appliance with a roasted chicken on a rotisserie spit inside the oven, and two hot plates visible on the top surface. Control knobs are located on the right side panel.

### Components and Controls:

- **Oven Door:** Tempered glass door for viewing cooking progress.
- **Oven Cavity:** 60-liter capacity with stainless steel heating elements.
- **Hot Plates:** One large (1200W), one medium (900W), and one small (350W) hot plate on the top surface.
- **Temperature Control Knob:** Adjusts oven temperature from 100°C to 250°C.
- **Function Selector Knob:** Selects oven heating modes (e.g., top heating, bottom heating, top+bottom, convection, rotisserie, or combinations).
- **Hot Plate Selector Knob:** Activates and selects combinations of hot plates.
- **Timer Knob:** Sets cooking time up to 60 minutes with a bell signal.
- **Indicator Light:** Illuminates when the oven or hot plates are in operation.
- **Rotisserie Spit:** For roasting whole poultry or large cuts of meat.
- **Baking Tray & Wire Rack:** Standard accessories for baking and grilling.

## 4. Setup and First Use

1. **Unpacking:** Carefully remove the appliance and all accessories from the packaging. Remove any protective films or stickers.

2. **Placement:** Place the oven on a stable, heat-resistant, and level surface. Ensure there is adequate ventilation around the appliance (at least 10-15 cm clearance on all sides). Do not place it near flammable materials.
3. **Cleaning:** Wipe the interior and exterior surfaces with a damp cloth. Wash all accessories (baking tray, wire rack, rotisserie spit) in warm soapy water, rinse, and dry thoroughly.
4. **First Use (Burn-off):** Before cooking food, operate the oven empty for approximately 15 minutes to burn off any manufacturing residues.
    - Plug the power cord into a grounded electrical outlet.
    - Set the Temperature Control Knob to 250°C.
    - Set the Function Selector Knob to "Top + Bottom Heating".
    - Set the Timer Knob to 15 minutes.
    - A slight odor or smoke may be present during this initial operation; this is normal. Ensure the area is well-ventilated.
    - Once the timer rings, turn all knobs to "OFF" and unplug the appliance. Allow it to cool completely.

## 5. Operating Instructions

### 5.1. Oven Operation

1. Place food on the baking tray or wire rack.
2. Insert the tray/rack into the desired rack position inside the oven.
3. Close the oven door.
4. Turn the **Temperature Control Knob** to the desired cooking temperature (100-250°C).
5. Turn the **Function Selector Knob** to choose the desired heating mode:
    - **OFF:** Oven is off.
    - **Top Heating:** For grilling or browning the top of food.
    - **Bottom Heating:** For baking bases or gentle heating.
    - **Top + Bottom Heating:** Standard baking and roasting.
    - **Top Heating + Convection:** For faster, more even cooking and browning.
    - **Top + Bottom Heating + Convection:** Enhanced even cooking for larger items.
    - **Top + Bottom Heating + Rotisserie:** For roasting with the rotisserie function.
6. Turn the **Timer Knob** to the desired cooking time (up to 60 minutes). The oven will start operating, and the indicator light will illuminate.
7. When the set time elapses, the timer will ring, and the oven will turn off automatically.
8. Carefully remove cooked food using oven mitts.

### 5.2. Hot Plate Operation

The appliance features three hot plates on the top surface: a large (1200W), a medium (900W), and a small (350W) hot plate.

1. Place appropriate cookware on the desired hot plate.
2. Turn the **Hot Plate Selector Knob** to choose the desired hot plate combination:
    - **OFF:** All hot plates are off.
    - **Small Hot Plate:** Activates the small hot plate.
    - **Mid Hot Plate:** Activates the medium hot plate.
    - **Big Hot Plate:** Activates the large hot plate.

- **Big + Mid Hot Plate:** Activates both large and medium hot plates.
- **Big + Small Hot Plate:** Activates both large and small hot plates.
- **Mid + Small Hot Plate:** Activates both medium and small hot plates.

3. The indicator light will illuminate when a hot plate is active.
4. After cooking, turn the Hot Plate Selector Knob to "OFF" and allow the hot plates to cool.

*Note: The oven and hot plates can be used simultaneously, but this may affect overall power consumption and cooking efficiency.*

### 5.3. Rotisserie Function

1. Secure the food (e.g., whole chicken) onto the rotisserie spit using the forks provided. Ensure the food is centered and balanced.
2. Insert the pointed end of the rotisserie spit into the drive socket on the right side of the oven cavity.
3. Rest the square end of the spit onto the support on the left side.
4. Place a drip tray (baking tray) on the bottom rack to catch drippings.
5. Close the oven door.
6. Set the **Temperature Control Knob** to the desired temperature.
7. Set the **Function Selector Knob** to "Top + Bottom Heating + Rotisserie".
8. Set the **Timer Knob** to the desired cooking time. The rotisserie will begin to rotate.
9. Monitor cooking progress through the glass door.
10. Once cooking is complete, turn all knobs to "OFF". Use the rotisserie handle (if provided) to carefully remove the hot spit and food.

## 6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your appliance.

1. **Always unplug the appliance** from the power outlet and allow it to cool completely before cleaning.
2. **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
3. **Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, a non-abrasive oven cleaner designed for toaster ovens can be used, following the product instructions. Ensure all cleaner residue is removed.
4. **Crumb Tray:** Pull out the crumb tray from the bottom of the oven. Empty crumbs and wash the tray in warm soapy water. Rinse and dry thoroughly before replacing.
5. **Accessories:** Wash the baking tray, wire rack, and rotisserie spit in warm soapy water. Rinse and dry thoroughly.
6. **Hot Plates:** Wipe the hot plates with a damp cloth after they have cooled. Do not immerse the hot plates or the appliance in water.
7. **Storage:** Ensure the appliance is clean and dry before storing. Store in a cool, dry place.

## 7. Troubleshooting

If you encounter any issues with your Geepas Oven Toaster/Hot Plate, please refer to the table below for common problems and solutions.

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| Appliance does not turn on. | Not plugged in; power outlet malfunction; controls not set. | Ensure the power cord is securely plugged in. Check the wall outlet with another appliance. Ensure Temperature, Function, and Timer knobs are set correctly. |
| Oven not heating properly. | Incorrect temperature/function setting; faulty heating element. | Verify temperature and function settings. If problem persists, contact customer support. |
| Hot plates not heating. | Hot plate selector knob not set; faulty hot plate. | Ensure the Hot Plate Selector Knob is set to the desired hot plate. If problem persists, contact customer support. |
| Excessive smoke during operation. | Food spills or residue inside oven; first use burn-off. | Clean the oven interior and crumb tray thoroughly. If it's the first use, this is normal (ensure ventilation). If smoke persists, unplug and contact support. |
| Rotisserie not rotating. | Improper installation of spit; function not selected. | Ensure the rotisserie spit is correctly seated in both the drive socket and support. Verify the Function Selector Knob is set to a rotisserie mode. |

## 8. Technical Specifications

| Feature | Detail |
|---|---|
| **Brand:** | Geepas |
| **Model:** | GO2413 |
| **Capacity:** | 60 Liters |
| **Oven Power:** | 2000W |
| **Big Hot Plate Power:** | 1200W |
| **Mid Hot Plate Power:** | 900W |
| **Small Hot Plate Power:** | 350W |
| **Temperature Control:** | 100-250°C |
| **Timer:** | 60 minutes with bell |
| **Heating Elements:** | Stainless Steel |
| **Special Features:** | Rotisserie, Convection, Temperature Control, Timer |
| **Installation Type:** | Countertop Oven |
| **Material:** | Stainless Steel (body), Tempered Glass (door) |
| **Color:** | Silver |
| **Power Supply:** | AC 220-240V 50/60Hz |
| **Item Weight:** | 2 Kilograms (approx. 4.41 Pounds) |

| Feature | Detail |
|---|---|
| **Included Components:** | Grill (Wire Rack), Baking Tray, Rotisserie Spit |

## 9. Warranty and Customer Support

Geepas products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or visit the official Geepas website.
Should you require technical assistance, spare parts, or have any questions not covered in this manual, please contact Geepas customer support. Contact details can typically be found on the product packaging, warranty card, or the official Geepas website.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B07MQ9R2XZ**

More documents and user manuals: **https://manuals.plus/**