Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GEV5132

Geepas Electric Air Pot Flask GEV5132 Instruction Manual

Introduction

Thank you for choosing the Geepas Electric Air Pot Flask, Model GEV5132. This appliance is designed to provide hot water conveniently and safely. Please read this instruction manual thoroughly before first use to ensure proper operation, maintenance, and to maximize the lifespan of your product. Keep this manual for future reference.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to 'off', then remove the plug from the wall outlet.
- Do not use the appliance for other than intended use.
- Exercise extreme caution when dispensing hot water.
- Ensure the lid is securely closed during operation.
- This appliance is equipped with boil-dry protection and an auto power-off function for safety.

Product Overview

The Geepas Electric Air Pot Flask GEV5132 is a 5-liter capacity stainless steel water boiler and warmer. It features multiple functions for convenient hot water preparation.



Figure 1: Front view of the Geepas Electric Air Pot Flask GEV5132, showing the control panel, dispenser, and water level indicator.



Figure 2: Angled view of the Geepas Electric Air Pot Flask GEV5132, highlighting the water level gauge and overall design.



Figure 3: Rear view of the Geepas Electric Air Pot Flask GEV5132, showing the power cord connection point.



Figure 4: Top view of the Geepas Electric Air Pot Flask GEV5132 with the lid open, revealing the stainless steel interior.

Key Components:

- **Control Panel:** Buttons for UNLOCK, DISPENSE, REBOIL, and indicator lights for Boil, Dry-boil, Keep Warm.
- **Dispenser Spout:** For dispensing hot water.
- **Water Level Gauge:** Transparent window to monitor water volume.
- **Lid:** Removable for filling and cleaning.
- **Handle:** For carrying the appliance.
- **Power Cord:** Detachable for easy storage.

- **Stainless Steel Inner Pot:** Durable and easy to clean.

Setup

1. **Unpacking:** Carefully remove the air pot from its packaging. Retain packaging for future transport or storage.
2. **Initial Cleaning:** Before first use, wash the interior of the air pot with warm, soapy water. Rinse thoroughly and wipe the exterior with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the air pot on a stable, flat, heat-resistant surface, away from edges and out of reach of children. Ensure adequate ventilation around the unit.
4. **Power Connection:** Connect the detachable power cord to the appliance, then plug it into a standard 220V electrical outlet.

Operating Instructions

1. Filling with Water

- Open the lid.
- Fill the inner pot with water. Do not exceed the maximum fill line indicated on the water level gauge.
- Close the lid securely.

2. Boiling Water

- After filling, the appliance will automatically begin the boiling process. The 'Boil' indicator light will illuminate.
- Once boiling is complete, the 'Boil' light will turn off, and the appliance will switch to the 'Keep Warm' function.

3. Keep Warm Function and Temperature Settings

The air pot offers four adjustable keep warm temperature settings: 45°C, 55°C, 65°C, and 85°C. The appliance will maintain the selected temperature after boiling.

- The current water temperature is displayed on the unit.
- To adjust the keep warm temperature, refer to the control panel for specific temperature selection buttons or modes.

4. Auto Dechlorinate Mode

This mode reduces chlorine and musty odors from tap water by extending the boiling time. The appliance automatically activates this mode when boiling tap water.

5. Quick Temp Mode

The Quick Temp mode heats water directly to the selected keep warm temperature without reaching a full boil. This mode is suitable for bottled or purified water where dechlorination is not necessary, reducing steam and energy use.

- To activate, press the 'REBOIL/QUICK TEMP' button. The 'Boil' light will blink, indicating Quick Temp mode is active.

6. Dispensing Water

- Ensure the appliance is powered on and water is heated.
- Press the 'UNLOCK' button to disable the safety lock.
- Press the 'DISPENSE' button to release hot water from the spout.
- Release the 'DISPENSE' button to stop the flow.

- The safety dispense lock automatically re-engages after a short period of inactivity to prevent accidental dispensing.

Maintenance

Cleaning

- Always unplug the air pot and allow it to cool completely before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scourers.
- To clean the interior, open the lid and gently wipe the stainless steel pot with a soft sponge and mild detergent. Rinse thoroughly.
- Do not immerse the appliance in water.

Descaling

Over time, mineral deposits (limescale) may build up inside the pot, especially in hard water areas. Descale regularly to maintain performance.

- Fill the pot with a solution of water and white vinegar (e.g., 1 part vinegar to 2 parts water) or a commercial descaling agent according to its instructions.
- Allow the solution to soak for several hours or boil it briefly (if using vinegar, ensure good ventilation).
- Empty the pot and rinse thoroughly several times with fresh water to remove any residue and odor.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	No power supply.	Check if the power cord is securely plugged into the appliance and the wall outlet. Ensure the outlet is functional.
Water is not heating.	Insufficient water level or boil-dry protection activated.	Ensure water level is above the minimum mark. If boil-dry protection activated, unplug, let cool, then refill and restart.
Water dispensing is weak or slow.	Limescale buildup in the pump/spout.	Perform descaling procedure as described in the Maintenance section.
Water has an unusual taste or odor.	Chlorine in tap water or residue from previous use.	Use Auto Dechlorinate Mode. Ensure thorough rinsing after cleaning. Descale if necessary.

Specifications

- **Brand:** Geepas
- **Model Number:** GEV5132
- **Capacity:** 5 Liters
- **Material:** Stainless Steel
- **Power / Wattage:** 892 watts
- **Voltage:** 220 Volts
- **Product Dimensions:** 10 x 13.2 x 10.2 cm

- **Item Weight:** 900 g
- **Special Features:** Programmable, Boil Dry Protection, 4 Keep Warm Functions, Auto Chlorine Purify, Safety Dispense Lock, Auto Power Off

Warranty and Support

This Geepas Electric Air Pot Flask GEV5132 comes with a warranty. Please refer to the included Warranty Card for details regarding warranty terms, conditions, and duration. For technical support, service, or inquiries, please contact Geepas customer service through the contact information provided on your warranty card or the official Geepas website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MTSHSZ8

More documents and user manuals: **https://manuals.plus/**