Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GMS8444

Geepas Home Theater System GMS8444 User Manual

Model: GMS8444

Product Overview Safety Instructions Package Contents Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The Geepas GMS8444 is a powerful home theater system designed to deliver an immersive audio experience. It features a high output power of 40000W, integrated disco lights that synchronize with music, and versatile connectivity options including USB, SD card, FM radio, and a wireless microphone for karaoke. The system includes a remote control for convenient operation and a 7-band equalizer for sound customization.



Image 1.1: Front view of the Geepas GMS8444 Home Theater System, showcasing its main unit and speaker design.

2. Safety Instructions

Please read and understand all safety instructions before operating this product. Retain this manual for future reference.

- **Power Source:** Connect the unit only to an AC power outlet of 220-240V, 50/60Hz. Ensure the power cord is not damaged or pinched.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids, such as vases, on the apparatus.

- **Ventilation:** Ensure adequate ventilation. Do not block any ventilation openings. Maintain a minimum distance of 10 cm around the unit for sufficient airflow.
- **Heat:** Do not place the unit near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the unit from the wall outlet before cleaning. Use a dry cloth for cleaning. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel. Opening or removing covers may expose you to dangerous voltage or other hazards.
- **Lightning:** Unplug this apparatus during lightning storms or when unused for long periods of time.
- **Children:** Keep the unit out of reach of children. Small parts may pose a choking hazard.

3. Package Contents

Verify that all items listed below are included in your package:

- Geepas Home Theater System (Main Unit with integrated speakers)
- Wireless Microphone
- Remote Control
- Power Cable
- User Manual

4. Setup

4.1 Unpacking

Carefully remove all components from the packaging. Retain the packaging materials for future transport or storage.

4.2 Placement

Place the main unit on a stable, flat surface. Ensure there is sufficient space around the unit for proper ventilation. Avoid placing it in direct sunlight or near heat sources.

4.3 Connections

1. **Power Connection:** Insert the power cable into the AC IN port on the back of the main unit, then plug the other end into a standard 220-240V, 50/60Hz wall outlet.
2. **External Audio Devices (AUX):** To connect an external audio device (e.g., smartphone, MP3 player), use a 3.5mm audio cable (not included) to connect the device's headphone jack to the AUX IN port on the home theater system.
3. **USB/SD Card:** Insert a USB flash drive or SD card into the respective slots on the front panel for media playback.
4. **Microphone:** For karaoke, connect the wireless microphone receiver (if applicable) or a wired microphone to the microphone input jacks. The system supports two microphone inputs.



Image 4.1: Rear view of the Geepas GMS8444 Home Theater System, showing power and audio input ports.

5. Operating Instructions

5.1 Power On/Off

Press the **POWER** button on the front panel or the remote control to turn the system on or off.

5.2 Input Selection

Press the **MODE** button on the front panel or remote control repeatedly to cycle through available input sources: USB, SD, FM, AUX, and Bluetooth.

5.3 Volume Control

Rotate the **MASTER VOLUME** knob on the front panel or use the **VOL+** / **VOL-** buttons on the remote control to adjust the overall volume level.

5.4 Equalizer Adjustment

The system features a 7-band equalizer. Use the dedicated equalizer controls on the front panel to fine-tune the audio frequencies (bass, treble, etc.) to your preference.

5.5 Karaoke Function

Connect the wireless microphone or a wired microphone to the microphone input jacks. Adjust the microphone volume and echo effects using the dedicated knobs on the front panel for an enhanced karaoke experience.

5.6 Disco Lights

The integrated disco lights can be activated and will synchronize with the music playback. Refer to the front panel controls or remote for specific light mode adjustments.

5.7 FM Radio Operation

- Switch to FM mode using the **MODE** button.
- Press the **SCAN** button to automatically search and save available FM stations.
- Use the **PREV** / **NEXT** buttons to navigate between saved stations.

5.8 Remote Control

The remote control provides convenient access to all major functions, including power, mode selection, volume, track control (for USB/SD), FM tuning, and equalizer presets.

6. Maintenance

6.1 Cleaning

Always unplug the system from the power outlet before cleaning. Use a soft, dry cloth to wipe the exterior surfaces. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

6.2 Storage

If the system will not be used for an extended period, unplug it from the power outlet and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Before contacting customer support, please refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet faulty; Unit switched off.	Ensure power cable is securely connected. Test the outlet with another device. Press the POWER button.
No sound	Volume too low; Incorrect input mode selected; External device not connected properly.	Increase volume. Select the correct input mode. Check external device connections.
Microphone not working	Microphone not connected; Microphone volume too low; Batteries in wireless microphone are dead.	Ensure microphone is connected. Increase microphone volume. Replace batteries in wireless microphone.
Remote control not responding	Batteries are dead; Obstruction between remote and unit; Remote not pointed correctly.	Replace remote control batteries. Remove any obstructions. Point the remote directly at the unit's sensor.

8. Specifications

Feature	Detail
Model Number	GMS8444
Brand	Geepas
Output Power	40000W
Drivers	2 x 10-inch
Tweeter	3-inch
Frequency Response	40Hz - 20kHz
Impedance	4 Ohm

Feature	Detail
AC Power	220-240V, 50/60Hz
Connectivity	USB, SD Card, FM Radio, Wireless Microphone, AUX
Dimensions (L x W x H)	104 x 38 x 36 cm
Weight	9.88 kg

9. Warranty and Support

For warranty information, please refer to the warranty card included with your purchase or the retailer's policy where the product was acquired. Keep your proof of purchase for any warranty claims.
For technical support or service inquiries, please contact Geepas customer service through their official website or the contact information provided in your purchase documentation.

© 2026 Geepas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07N6N55GY

More documents and user manuals: **https://manuals.plus/**