Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta C3351

Konica Minolta BIZHUB C3351 Black Toner Cartridge User Manual

Model: C3351 (A95W130)

1. Product Overview

This manual provides essential information for the proper installation, handling, and maintenance of your Konica Minolta BIZHUB C3351 (A95W130) Black Toner Cartridge. This cartridge is designed to deliver high-quality black prints for compatible Konica Minolta BIZHUB C3351 series printers.



Image 1.1: The Konica Minolta BIZHUB C3351 Black Toner Cartridge, shown in its original packaging. The box displays the Konica Minolta logo, product model numbers (C3851/C3851FS/C3351), and the toner cartridge designation "TNP49K". The part number A95W130 is also visible.

2. Safety Information

Please read and follow these safety guidelines to ensure safe handling and operation:

- **Keep out of reach of children:** Toner powder can be harmful if ingested.
- **Avoid direct contact with toner:** If toner comes into contact with skin or eyes, wash immediately with soap and water. If irritation persists, seek medical attention.
- **Do not incinerate:** Toner cartridges contain flammable materials. Do not dispose of them by burning.
- **Store properly:** Keep the cartridge in its original packaging until ready for use, and store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handle with care:** Avoid dropping or shaking the cartridge excessively, as this may cause toner leakage.

3. Installation (Setup)

Follow these steps to install the toner cartridge in your Konica Minolta BIZHUB C3351 printer:

1. **Power Off:** Ensure your printer is powered off before beginning the installation process.
2. **Open Front Cover:** Locate and open the front cover of your Konica Minolta BIZHUB C3351 printer.
3. **Remove Old Cartridge:** If replacing an empty cartridge, carefully grasp the old toner cartridge and pull it straight out of the printer. Place it in a sealed bag for proper disposal.
4. **Unpack New Cartridge:** Remove the new Konica Minolta BIZHUB C3351 Black Toner Cartridge from its packaging. Gently rock the cartridge several times horizontally to distribute the toner evenly.
5. **Remove Protective Seals:** Carefully remove any protective tape or seals from the new cartridge. Do not touch the green drum surface or electrical contacts.
6. **Insert New Cartridge:** Align the new cartridge with the slot inside the printer and gently push it in until it clicks firmly into place. Ensure it is seated correctly.
7. **Close Front Cover:** Close the front cover of the printer.
8. **Power On:** Turn on your printer. The printer will typically perform a self-test and recognize the new toner cartridge.

4. Operating Instructions

Once the toner cartridge is installed, your printer is ready for operation. The printer will automatically detect the new cartridge and adjust settings as needed. You can now proceed with your printing tasks as usual.

- **Print Test Page:** It is recommended to print a test page after installation to verify print quality.
- **Monitor Toner Levels:** Your printer's display or software utility will indicate the remaining toner level. Replace the cartridge when the "Toner Low" or "Replace Toner" message appears.

5. Maintenance

Proper maintenance ensures the longevity and performance of your toner cartridge and printer:

- **Storage:** Store unused toner cartridges in their original sealed packaging in a cool, dry environment, away from direct sunlight and extreme temperatures.
- **Handling:** Always handle the cartridge by its body, avoiding contact with the drum or electrical contacts.
- **Disposal:** Dispose of empty toner cartridges responsibly. Many manufacturers and retailers offer recycling programs. Refer to local regulations for proper disposal methods.

6. Troubleshooting

If you encounter issues after installing the toner cartridge, consider the following common solutions:

- **Cartridge Not Recognized:**
  - Ensure the cartridge is fully seated in its slot. Remove and reinsert it firmly.
  - Check for any protective seals or tapes that may not have been fully removed.
  - Power cycle the printer (turn off, wait 30 seconds, then turn on).
- **Poor Print Quality (Streaks, Fades, Spots):**
  - Gently rock the cartridge horizontally to redistribute toner.
  - Perform a printer cleaning cycle or calibration from your printer's control panel or software.

- Ensure the paper type and settings are correct for your print job.

- **Toner Leakage:**
  - Carefully remove the cartridge and inspect for damage.
  - If damaged, replace the cartridge. Clean any spilled toner inside the printer with a dry, lint-free cloth.

If problems persist, consult your printer's specific user manual or contact Konica Minolta support.

7. Specifications

Feature	Detail
Brand	Konica Minolta
Model	BIZHUB C3351 (A95W130)
Color	Black
Page Yield	13,000 pages (approximate)
Item Weight	14.1 ounces
Package Dimensions	6.02 x 5.47 x 3.5 inches
UPC	768202274512
Compatible Printer Models	Konica Minolta bizhub C3351

8. Warranty and Support

For information regarding warranty coverage, returns, or technical support for your Konica Minolta BIZHUB C3351 Black Toner Cartridge, please refer to the official Konica Minolta website or contact their customer service directly. Keep your purchase receipt as proof of purchase.
Return Policy: This product typically has a 30-day return/replacement policy from the date of purchase, subject to the seller's terms and conditions.
Manufacturer: Konica Minolta

© 2024 Konica Minolta. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NJ9NFJD

More documents and user manuals: **https://manuals.plus/**