Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AIDITIYMI XRS321

AIDITIYMI XRS321 Replacement Remote Control User Manual

For Vizio Soundbar Sound Bar Speaker Systems

Introduction

This manual provides instructions for the AIDITIYMI XRS321 replacement remote control, designed for use with various Vizio Soundbar Sound Bar Speaker Systems. This remote control offers a direct replacement solution without the need for programming or pairing.

Compatible Vizio Soundbar Models:

- S2120W-E0, S2120W-E0D
- S2121w-D0
- S2920w-C0R, S2920w-C0
- S3820W-C0, S3821W-C0
- S4220W-E4
- S2120WE0, S2120WE0D
- S2121wD0
- S2920wC0R
- S3820WC0, S2920WC0, S3821WC0
- S4220WE4

Setup

The AIDITIYMI XRS321 remote control requires two AAA alkaline batteries for operation. No programming or pairing is necessary; simply insert the batteries, and the remote will be ready for use.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back view of the AIDITIYMI XRS321 remote control, showing the battery compartment with the cover removed and slots for two AAA batteries.

Operating Instructions

Once batteries are installed, point the remote control towards your Vizio Soundbar system to operate. The remote features standard functions for soundbar control.


INPUT
TVOL
TSHD
TREBLE
BASS



Image: Front view of the AIDITIYMI XRS321 remote control, displaying its buttons for input, power, volume, playback, treble, bass, and TSHD.

Button Functions

Button	Function
INPUT	Selects the audio input source for the soundbar.
Bluetooth Icon	Activates or pairs Bluetooth devices with the soundbar.
Power Icon	Turns the soundbar power on or off.
+ / - (Volume)	Increases (+) or decreases (-) the master volume.
Mute Icon	Mutes or unmutes the soundbar audio.
Play/Pause	Plays or pauses audio playback.
Skip Back / Skip Forward	Skips to the previous or next track during playback.
TREBLE	Adjusts the treble level of the soundbar.
BASS	Adjusts the bass level of the soundbar.
TVOL	Activates or adjusts TV Volume control (if supported by soundbar and TV).
TSHD	Activates or adjusts TruSurround HD or similar sound modes.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage. Store the remote in a cool, dry place.

Troubleshooting

If you experience issues with your AIDITIYMI XRS321 remote control, refer to the following common solutions:

Problem	Solution

Problem	Solution
Remote is not responding.	◦ Ensure batteries are inserted correctly with the correct polarity (+/-). ◦ Replace old batteries with new 1.5V AAA alkaline batteries. ◦ Check for any obstructions between the remote and the soundbar's IR receiver. ◦ Ensure you are within the maximum operating range (up to 32 feet) and pointing the remote directly at the soundbar.
Remote functions are intermittent.	◦ Replace batteries with new ones. Low battery power can cause inconsistent performance. ◦ Ensure there is no strong light source (like direct sunlight or bright fluorescent lights) interfering with the IR signal.
Remote requires programming.	The AIDITIYMI XRS321 is a direct replacement remote and does not require programming or pairing. If it's not working, refer to the "Remote is not responding" solutions.

Specifications

Feature	Detail
Brand	AIDITIYMI
Model Name	XRS321
Model Number	AIDITIYMI-XRS321-AD011
Connectivity Technology	Infrared (IR)
Compatible Devices	Vizio Soundbar Sound Bar Speaker Systems
Power Source	2 x AAA Batteries (not included)
Maximum Range	32 Feet
Button Quantity	13
Special Feature	Ergonomic design

Warranty Information

This AIDITIYMI XRS321 replacement remote control comes with a**1-Year Warranty** from the manufacturer. Please retain your purchase receipt for warranty claims. For specific warranty terms and conditions, refer to the documentation provided at the time of purchase or contact the seller.

Support

For further assistance or inquiries regarding your AIDITIYMI XRS321 remote control, please contact the seller or manufacturer directly. Ensure you have your product model number (XRS321) and purchase details available when seeking support.
You may also refer to the official Vizio soundbar user manual for detailed information on your specific soundbar model's features and functions, as this remote is designed to replicate the original remote's functionality.

© 2024 AIDITIYMI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NNL8S3W

More documents and user manuals: **https://manuals.plus/**