Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO AERSON

TRESKO AERSON 30 cm Floor Fan Instruction Manual

Model: AERSON (30 cm, Chrome)

1. Important Safety Instructions

Please read these instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the fan is placed on a stable, level, non-slip surface to prevent tipping.
- Do not operate the fan with a damaged cord or plug. If the cord or plug is damaged, contact qualified service personnel.
- Keep fingers and other objects away from the fan blades and grille during operation.
- Do not use the fan near water or in damp environments (e.g., bathrooms, laundry areas).
- Unplug the fan from the power outlet before cleaning, moving, or performing any maintenance.
- Do not cover the fan or obstruct its airflow during operation.
- This appliance is for indoor use only.
- Keep out of reach of children.

2. Product Overview

The TRESKO AERSON Floor Fan is designed to provide powerful airflow for cooling and ventilation in various indoor environments. Its robust metal construction and aluminum blades ensure durability and high performance. The fan features three speed settings and an adjustable tilt angle of up to 110 degrees for directional airflow.



Image: The TRESKO AERSON Floor Fan demonstrating customizable airflow and available sizes (30 cm, 40 cm, 50 cm, 60 cm) and three speed levels (Low, Medium, High).

Key Features:

- **Three Speed Levels:** Adjust airflow intensity to your preference.
- **110° Adjustable Tilt:** Direct the airflow precisely where needed.
- **Robust Metal Construction:** Durable design with aluminum rotor blades.
- **High-Performance Motor:** Engineered for long-lasting operation.
- **Integrated Carry Handle:** For easy portability.
- **No Assembly Required:** Ready to use out of the box.
- **Cable Winder:** Convenient storage for the 154 cm power cable.
- **Stable, Non-Slip Base:** Ensures secure placement.

3. Setup

The TRESKO AERSON Floor Fan requires no assembly and is ready for immediate use.

1. **Unpacking:** Carefully remove the fan from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the fan on a firm, level, and stable surface. Ensure there is adequate space around the fan for unobstructed airflow. Avoid placing it directly against walls or furniture that could block the air intake or output.
3. **Power Connection:** Unwind the power cable (154 cm) and plug the standard Schuko plug into a suitable 220-240V AC power outlet.



Image: The TRESKO AERSON Floor Fan highlighting its compact dimensions (13D x 37W x 38H cm), 1.54m cable length, 45W power consumption, and 38.97 m³/min airflow.

4. Operating Instructions

The fan is operated via a manual switch located on the unit.

1. **Power On/Off:** Locate the power switch on the fan. Turn the switch to the "ON" position to start the fan. Turn it to "OFF" to stop the fan.

2. **Adjusting Speed:** The fan has three speed settings. Use the speed control switch/knob to select your desired airflow intensity (Low, Medium, High).
3. **Adjusting Tilt Angle:** The fan head can be tilted up to 110 degrees. Loosen the adjustment knobs on the sides of the fan stand, position the fan head to the desired angle, and then securely tighten the knobs to fix it in place.



Image: The TRESKO AERSON Floor Fan demonstrating its continuous tilt adjustment capability, allowing the fan head to pivot up to 110 degrees.

Enhancing Cooling Effect:

For an enhanced cooling effect, especially in very warm conditions, you can place a large bowl or container of ice cubes in front of the fan. The fan will then circulate air over the ice, providing a cooler breeze similar to an air conditioning unit.



Image: The TRESKO AERSON Floor Fan illustrating a method to enhance cooling by placing ice cubes in front of the fan to circulate cooler air.

5. Maintenance

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your fan.

- **Before Cleaning:** Always unplug the fan from the power outlet before cleaning.
- **Exterior Cleaning:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Grille and Blades Cleaning:** The metal grille can be wiped clean. For thorough cleaning of the blades, the fan may be partially disassembled. Refer to the detailed view image for component identification. Use a soft brush or vacuum cleaner to remove dust and debris from the blades and inside the grille. Ensure all parts are dry before reassembling and operating.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging. Use the integrated cable winder for neat cable storage.



Image: Detailed views of the TRESKO AERSON Floor Fan, showing the control switches, motor housing, and protective grille, useful for maintenance and understanding internal components.

6. Troubleshooting

If you encounter any issues with your TRESKO AERSON Floor Fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	◦ Not plugged in. ◦ Power outlet not working. ◦ Power switch is off.	◦ Ensure the power cord is securely plugged into a working outlet. ◦ Test the outlet with another appliance. ◦ Turn the power switch to the "ON" position.

Problem	Possible Cause	Solution
Weak airflow.	◦ Fan speed set too low. ◦ Grille or blades are dirty. ◦ Obstruction blocking airflow.	◦ Increase the fan speed setting. ◦ Unplug the fan and clean the grille and blades as per maintenance instructions. ◦ Ensure no objects are blocking the front or rear grilles.
Unusual noise or vibration.	◦ Fan not on a stable surface. ◦ Loose parts or debris inside.	◦ Place the fan on a firm, level surface. ◦ Unplug the fan and inspect for any loose components or foreign objects. Do not attempt to disassemble the motor housing.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Brand:	TRESKO
Model Name:	AERSON
Model Number:	4260613490742
Size:	30 cm (Blade Length)
Color:	Chrome
Material:	Metal (Housing), Aluminum (Blades)
Product Dimensions (D x W x H):	13 cm x 37 cm x 38 cm
Item Weight:	3.6 Kilograms
Power Source:	Electric Cable
Voltage:	220-240 Volts
Power Consumption:	45 Watts
Number of Speeds:	3
Airflow:	38.97 Cubic meters per minute
Max Speed:	2500 rpm
Noise Level:	59 Decibels
Cable Length:	154 Centimeters
Tilt Angle:	Up to 110 degrees
Control Type:	Manual Switch
Installation:	No installation required

Indoor/Outdoor Use:	Indoor Use Only

8. Warranty and Support

For warranty information or technical support, please contact the manufacturer or your retailer. Keep your purchase receipt as proof of purchase.
Manufacturer: DWD-Company GmbH & Co. KG
For further assistance, please visit the TRESKO website or contact their customer service department.

© 2026 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NY3DVYF

More documents and user manuals: **https://manuals.plus/**