Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SHARDOR CG9406-UL2

SHARDOR Electric Coffee and Spice Grinder User Manual

Model: CG9406-UL2

Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your SHARDOR Electric Coffee and Spice Grinder. Designed for grinding coffee beans, spices, and other dry ingredients, this appliance features a powerful 200W motor and a removable stainless steel bowl for convenience. Please read this manual thoroughly before first use and retain it for future reference.

Important Safety Instructions

- Read all instructions before using the appliance.
- To protect against electrical hazards, do not immerse the motor base, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the lid is securely in place before operating the appliance.
- This appliance is ETL approved, ensuring safety standards are met.

Product Overview and Components

Your SHARDOR Electric Coffee and Spice Grinder is designed for ease of use and efficient grinding. It features a durable stainless steel housing and powerful blades.



Figure 1: Exploded View of Grinder Components
This image displays the disassembled parts of the SHARDOR grinder, including the lid, seal ring, removable bowl with blade, and the main body with the on/off mechanism.

- **Main Body:** Contains the motor and power cord.
- **Removable Grinding Bowl:** Stainless steel bowl with integrated blade for grinding. Features measurement markings and a 70g capacity, sufficient for approximately 12 cups of coffee.
- **Transparent Lid:** Secures the grinding bowl and activates the grinding mechanism when pressed down. Includes a sealing ring to prevent powder splashing.
- **2-in-1 Spoon with Brush:** A versatile tool for measuring ingredients and cleaning the grinding bowl.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the removable grinding bowl and lid with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main body with a damp cloth.

3. **Assemble:** Place the clean, dry removable grinding bowl into the main body of the grinder. Ensure it is seated correctly.



Figure 2: Grinder Setup and Operation Steps

This image illustrates the process of adding coffee beans to the grinding bowl, securing the lid, and initiating the grinding process by pressing down on the lid.

Operating Instructions

1. **Add Ingredients:** Fill the removable grinding bowl with your desired amount of coffee beans or spices. Do not exceed the "MAX" fill line (70g capacity).
2. **Secure Lid:** Place the transparent lid onto the grinding bowl, ensuring it is properly aligned and securely seated. The sealing ring helps prevent powder from escaping.
3. **Plug In:** Connect the power cord to a standard electrical outlet (110 Volts).
4. **Grind:** Press down firmly on the lid to activate the grinding mechanism. The grinder will operate as long as the lid is pressed.

5. **Monitor Grinding:** Observe the grinding process through the transparent lid. Release pressure on the lid to stop grinding.
6. **Achieve Desired Fineness:**
    - For **coarse powder** (e.g., French Press): Grind for approximately 5 seconds.
    - For **medium powder** (e.g., AeroPress): Grind for approximately 10 seconds.
    - For **fine powder** (e.g., Moka Pot): Grind for approximately 15 seconds.
    - For **very fine powder** (e.g., Espresso): Grind for approximately 20 seconds.
7. **Unplug:** Once grinding is complete, unplug the appliance from the outlet.
8. **Remove Ground Ingredients:** Carefully remove the lid, then lift the removable grinding bowl from the main body. Pour out the freshly ground coffee or spices.



Figure 3: Grinding Fineness Guide
This image illustrates the visual difference in coffee grind fineness achievable with varying grinding durations, from coarse to very fine.



Figure 4: Pouring Ground Coffee

This image demonstrates the ease of pouring freshly ground coffee from the removable stainless steel bowl into a cup.

Cleaning and Maintenance

1. **Unplug:** Always ensure the grinder is unplugged from the power outlet before cleaning.
2. **Remove Bowl:** Lift the removable grinding bowl from the main body.
3. **Clean Bowl and Lid:** Wash the removable grinding bowl and lid with warm, soapy water. Rinse thoroughly and dry immediately. The removable design facilitates easy cleaning.
4. **Clean Main Body:** Wipe the exterior of the main body with a soft, damp cloth. Do not immerse the main body in water or any other liquid.
5. **Use Cleaning Brush:** Utilize the included 2-in-1 spoon with brush to remove any residual grounds from the blades and interior of the grinding bowl.
6. **Storage:** Store the clean and dry grinder in a cool, dry place.



Figure 5: Cleaning the Removable Bowl

This image demonstrates the simple process of rinsing the removable grinding bowl under running water for easy cleaning.

Troubleshooting

Problem	Possible Cause	Solution
Grinder does not start.	Not plugged in; lid not properly secured.	Ensure power cord is firmly plugged into a working outlet. Verify the lid is correctly aligned and pressed down firmly.
Ingredients not grinding evenly.	Overfilling the bowl; insufficient grinding time.	Do not overfill the grinding bowl. Grind in smaller batches if necessary. Increase grinding time for finer results.
Powder splashing out.	Lid not properly sealed.	Ensure the lid is securely placed and the sealing ring is intact before operating.

Specifications

Feature	Detail
Brand	SHARDOR
Model Number	CG9406-UL2
Color	Silver
Product Dimensions	4.1"L x 4.1"W x 7.8"H
Capacity	2.5 ounces (approx. 70g)
Voltage	110 Volts
Item Weight	2.33 pounds
Safety Certification	ETL Approved

Warranty and Support

Your SHARDOR Electric Coffee and Spice Grinder comes with a 1-year hassle-free replacement warranty. For any product inquiries, technical support, or warranty claims, please contact SHARDOR customer service. Refer to the product packaging or the official SHARDOR website for the most up-to-date contact information.

© 2025 SHARDOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NYVDTQF

More documents and user manuals: **https://manuals.plus/**