Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun AS330

Braun AS330 Hair Styler Instruction Manual

Model: AS330

1. Introduction and Product Overview

Thank you for choosing the Braun AS330 Hair Styler. This manual provides essential information for the safe and effective use of your new appliance. Please read all instructions carefully before first use and keep this manual for future reference.

Product Features:

- **Power:** 400 Watts for efficient styling.
- **Heat Settings:** Two adjustable heat settings for various hair types and styling needs.
- **Attachments:** Includes three versatile attachments for different styles.
- **Coating:** Ceramic coating for even heat distribution and reduced hair damage.
- **Automatic Curl Release:** Button-activated release for easy styling and tangle prevention.

Package Contents:

- Braun AS330 Hair Styler Unit
- 18mm Styling Brush attachment
- 28mm Maxi Curl Brush attachment
- Volume Attachment
- Instruction Manual



Image: The Braun AS330 Hair Styler with its various styling attachments.

2. Important Safety Instructions

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep out of reach of children.
- **DANGER:** Do not use this appliance near water, such as in bathtubs, showers, basins, or other vessels containing water.
- **WARNING:** Be careful of high temperatures. The styling attachments and the styler itself can become very hot during use. Avoid direct contact with skin.
- **WARNING:** Do not use this appliance while bathing or showering.
- Always unplug the appliance immediately after use.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not reach for an appliance that has fallen into water. Unplug immediately.

- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Keep the cord away from heated surfaces.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- This appliance is for household use only.

3. Setup

Before using your Braun AS330 Hair Styler, ensure your hair is towel-dried and detangled. Follow these steps for initial setup:

1. **Select Attachment:** Choose the desired styling attachment (18mm styling brush, 28mm Maxi Curl brush, or volume attachment) based on your styling needs.
2. **Attach Securely:** Align the attachment with the main unit and push it firmly until it clicks into place. Ensure it is securely fastened before plugging in the device.
3. **Plug In:** Insert the power plug into a suitable electrical outlet. Ensure the voltage matches the specifications of the appliance (220-240V, 50/60Hz).

4. Operating Instructions

The Braun AS330 Hair Styler is designed for both drying and styling. Follow these guidelines for optimal results:

General Usage:

1. **Power On:** Turn the power switch to your desired heat setting. The styler has two heat settings. Start with the lower setting for fine or damaged hair, and use the higher setting for thicker or coarser hair.
2. **Section Hair:** Divide your hair into manageable sections.
3. **Styling:** Place the styler at the roots of a hair section and slowly glide it down to the ends, rotating the brush as you go to create curls or waves, or to smooth and add volume.
4. **Automatic Curl Release:** For easy removal of the brush from curled hair, press the automatic curl release button. This retracts the bristles, allowing the brush to slide out without tangling.
5. **Power Off:** After styling, turn the power switch to the 'off' position and unplug the appliance from the power outlet.
6. **Cool Down:** Allow the styler and attachments to cool completely before storing.

Using Specific Attachments:

- **18mm Styling Brush:** Ideal for creating tighter curls, waves, or adding definition to shorter hair.
- **28mm Maxi Curl Brush:** Perfect for creating larger, softer curls and voluminous waves.
- **Volume Attachment:** Use this attachment at the roots to lift and add significant volume to your hair.

5. Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your Braun AS330 Hair Styler.

1. **Unplug and Cool:** Always ensure the appliance is unplugged and completely cool before cleaning.
2. **Remove Attachments:** Detach all styling brushes and the volume attachment from the main unit.
3. **Clean Brushes:** Use a soft, dry brush or comb to gently remove any hair or debris from the bristles of the styling brushes.
4. **Wipe Unit:** Wipe the main unit and attachments with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing.
6. **Storage:** Store the appliance in a dry, safe place, away from moisture and direct sunlight. Do not wrap the cord around the appliance, as this can damage the cord.

6. Troubleshooting Guide

If you encounter any issues with your Braun AS330 Hair Styler, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; Power outlet malfunction; Appliance fault.	Ensure the plug is fully inserted. Test the outlet with another device. If still not working, contact customer support.
Attachments are difficult to remove or attach.	Incorrect alignment; Debris in connection point.	Ensure the attachment is aligned correctly before pushing/pulling. Check for and remove any hair or debris from the connection.
Hair gets tangled in the brush.	Hair section too large; Incorrect technique; Brush not released properly.	Use smaller hair sections. Ensure you are rotating the brush smoothly. Utilize the automatic curl release button to detangle.
Appliance is not heating up sufficiently.	Incorrect heat setting; Appliance fault.	Ensure the styler is set to the higher heat setting if needed. If the problem persists, contact customer support.

If the problem persists after trying these solutions, please contact Braun customer support for further assistance.

7. Technical Specifications

- **Model:** AS330
- **Power:** 400 Watts
- **Heat Settings:** 2
- **Speed Settings:** 2
- **Material:** Ceramic coating
- **Color:** Black
- **Power Source:** Corded Electric

- **Included Components:** 18mm Styling Brush, 28mm Maxi Curl Brush, Volume Attachment
- **Recommended Use:** Drying and Styling
- **Shipping Dimensions:** 34.6 x 14.6 x 6.2 cm
- **Weight:** Approximately 699.98 grams

8. Warranty and Customer Support

Your Braun AS330 Hair Styler comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or to inquire about replacement parts, please visit the official Braun website or contact your local Braun customer service center. Contact information can typically be found on the Braun website or on the product packaging.

Please have your model number (AS330) and proof of purchase ready when contacting customer support.

© 2026 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07P5QCR7S

More documents and user manuals: **https://manuals.plus/**